



TIC AEROSPACE, INC.

FAA Repair Station Number: 4S2R821C EASA

Repair Station Number: EASA.145.6720

6962 NW 50TH STREET, MIAMI, FL 33166

Phone: (305) 378-0523 Fax: (305) 384-7020 Toll Free: 1-866-378-6771

www.ticaerospace.com

E-mail: operations@ticaerospace.com

MRO CAPABILITY LIST

NORTH PERRY AIRPORT MAINTENANCE- AIRCRAFT

CESSNA - All 100, 200, 300, 400, 500 Series Aircraft.
PIPER SENECA II, III, V – PA-18, -28 -34 Series
BELL 212, 412, 222
ROBINSON HELICOPTER R22, R44, R66,
BEECHCRAFT A35, V35, V36, A36, B55, B58 Barron, K90, K100, K200.
ATR 42 / 72
HERCULES L-100 / L382 / L382J / C-130
CASA 212
ERJ 135 / ERJ145
CRJ 100 / CRJ 200
SAAB 340 SERIES
KING AIR 200 / KING AIR 90 / KING AIR 350
EUROCOPTER AS- 360 /365 DAUPHIN
C-295
CN-235
METROLINER III, IV FAIRCHILD AIRCRAFT SA227-BC / SA227-PC
EMBRAER EMB314/A29 SUPER TUCANO
BOEING 737 / 757 / 767 / 777 / 787
ROCKWELL COMMANDER 112 B/TC/TCA, 114 A/B/TC

ENGINES

Lycoming	IO-235 Series
Lycoming	IO-290 Series
Lycoming	IO-360 Series
Lycoming	O-360 Series
Lycoming	O-320 Series
Lycoming	HO-360 , HIO-360 Series
Lycoming	O -540 Series
Lycoming	IO-540 Series

ENGINES

Continental O-360 Series
Continental IO-360 Series
Continental O-470 Series
Continental IO-520 Series
Continental IO-470 Series
Honeywell LTS101-650C Series
Honeywell LTS101-750C-1 Series
Pratt & Whitney PT6A and PT6T

INSTRUMENTS

All Make and Model below 12500 Lbs.
METROLINER III, IV FAIRCHILD AIRCRAFT SA227-BC / SA227-PC

RADIO

All Make and Model below 12500 Lbs.
METROLINER III, IV FAIRCHILD AIRCRAFT SA227-BC / SA227-PC

AVIONICS

FAR 91.411 & 91.413 Certification Rates
ADS-B Systems

LINE MAINTENANCE

Line Maintenance Authorization at MIA
LIMITED LINE MAINTENANCE

COMPOSITE

LIMITED AIRFRAME	Authorization is limited to composite inspection, repair and overhaul of airframe parts consisting of: Primary & Secondary Flight Controls,
------------------	---

NONDESTRUCTIVE INSPECTION

Magnetic Particle Testing - All Makes and Models
Liquid Penetrant Testing - All Makes and Models
Eddy Current Inspection - All Makes and Models
Ultrasonic Inspection - All Makes and Models

NW FACILITY MRO - ACCESSORIES

OEM	PART NUMBER	DESCRIPTION
SAFRAN	GA30724	TUBE ASSY, TORQUE
SAFRAN	GA30728	TUBE ASSY, TORQUE
SAFRAN	A33963-1	TUBE, TORQUE
SAFRAN	A34474	TUBE, TORQUE
SAFRAN	A33963-2	TUBE, TORQUE
SAFRAN	A33969	PIN
SAFRAN	A34008	SCREW
SAFRAN	VS3069AR10-12	BOLT
SAFRAN	A33974	PLATE, LOCK
SAFRAN	GA30725	SHIELD, HEAT
SAFRAN	GA31557	PLATE THRUST
SAFRAN	GA3256	PLATE, REAR
SAFRAN	A33890	PLATE, RETAINING
SAFRAN	A35015	BOLT
SAFRAN	A35403	LINER
SAFRAN	A35404-1	PISTON
SAFRAN	A35404-2	PISTON
SAFRAN	D56700-0023	SPRING
SAFRAN	A35394	GUIDE
SAFRAN	A35393-1	PIN, ADJUSTER
SAFRAN	A35393-11	PIN, ADJUSTER
SAFRAN	HTE711-59V	FITTING ASSY, HYD
SAFRAN	VA3069AR10-12	BOLT
SAFRAN	A35442	RETAINER, PIN
SAFRAN	AA35393-1	PIN, ADJUSTER
GOODRICH	54-479	SLEEVE
GOODRICH	40-598-1	SPRING
GOODRICH	260-813	HOUSING, ADJUSTER
GOODRICH	43-1343	BOLT
GOODRICH	93-939	PLATE, PRESS
GOODRICH	93-983	PLATE, PRESS
GOODRICH	244-650-3	ROTOR
GOODRICH	133-952-1	STATOR
GOODRICH	184-870	TORQUE PLATE
GOODRICH	184-870-1	TORQUE PLATE

GOODRICH	54-483	SLEEVE, PISTON
GOODRICH	74-868	PISTON
GOODRICH	266-248-1	PISTON HSG ASSY
SAFRAN	A36598	SCREW
SAFRAN	A36731	SCREW
SAFRAN	A36730	PLATE, STOP
SAFRAN	GA31886	INSULATOR ASSY
SAFRAN	A35789	SPRING
SAFRAN	A36591	PIN, ADJUSTER
SAFRAN	A36587	SPRING
SAFRAN	A36586	PISTON
SAFRAN	A36585	SLEEVE, PISTON
SAFRAN	GA31875-1	PISTON
SAFRAN	A36573	TUBE, TORQUE
SAFRAN	GA32181	ROTOR ASSY
HONEYWELL	2609087	BOLT, MACHINE
HONEYWELL	2611964	GUIDE, SPRING
HONEYWELL	2612578	PIN, ADJUSTER
HONEYWELL	2612581	SPRING, HELICAL COM
HONEYWELL	2612725	PLATE, PRESSURE
HONEYWELL	2612875	PLATE, STATOR
HONEYWELL	2615533	PIN, ADJUSTER
HONEYWELL	2616999	PISTON
HONEYWELL	2612550-1	PISTON HSG & PLUG ASSY
HONEYWELL	2612555-580	ROTOR ASSY
HONEYWELL	2612555-620	ROTOR ASSY
HONEYWELL	S274A102-13	COUPLING HALF, BULKHEAD
HONEYWELL	2602509	RETAINER, BOLT
HONEYWELL	2602508	BOLT, MACHINE
HONEYWELL	2607849	BOLT, MACHINE
HONEYWELL	2602899	RETAINER, PIN
HONEYWELL	2605777	RETAINER, PIN
HONEYWELL	2603110	HOUSING, ADJUSTER
HONEYWELL	2606739	HOUSING, ADJUSTER
HONEYWELL	2607181-1	HOUSING, ADJUSTER
HONEYWELL	2607180-1	PIN, ADJUSTER
HONEYWELL	2601092	SPRING, HELICAL COMP
HONEYWELL	2608845	INSULATOR, PISTON
HONEYWELL	2604249	GUIDE, INSULATOR
HONEYWELL	2601076	PISTON

HONEYWELL	2609723-1	PISTON
HONEYWELL	2607394	PISTON
HONEYWELL	2609723-2	PISTON
HONEYWELL	2601073	PISTON HSG & PLUGS ASSY
HONEYWELL	2601073-1	PISTON HSG & PLUGS ASSY
HONEYWELL	2610879-1	PISTON HSG & PLUGS ASSY
HONEYWELL	2602921	PLATE, PRESSURE
HONEYWELL	2602087	ROTOR ASSY
HONEYWELL	2601105	PLATE, STATOR
HONEYWELL	2601838	TUBE, TORQUE
HONEYWELL	2601054	TUBE, TORQUE
HONEYWELL	2601054-1	TUBE, TORQUE
GOODRICH	MS21250H07012	BOLT 12 POINT
GOODRICH	93-927	PLATE, PRESSURE
GOODRICH	244-640	STATOR (POSITION 2,34)
GOODRICH	244-677	STATOR (POSITION 1 ONLY)
GOODRICH	20-552	PIN, ADJUSTER
GOODRICH	20-552-1	PIN, ADJUSTER
GOODRICH	40-620	SPRING
GOODRICH	113-130	GUIDE SPRING
GOODRICH	54-404	SLEEVE, PISTON
GOODRICH	54-509	SLEEVE, PISTON
GOODRICH	74-803-1	PISTON
BOEING	113T8314-1	FITTING ASSY, TRUNION DOOR
BOEING	113T8314-10	FITTING ASSY, TRUNION DOOR
BOEING	113T8314-17	FITTING ASSY, TRUNION DOOR
BOEING	113T8314-18	FITTING ASSY, TRUNION DOOR
BOEING	113T8314-2	FITTING ASSY, TRUNION DOOR
BOEING	113T8314-23	FITTING ASSY, TRUNION DOOR
BOEING	113T8314-24	FITTING ASSY, TRUNION DOOR
BOEING	113T8314-5	FITTING ASSY, TRUNION DOOR
BOEING	113T8314-6	FITTING ASSY, TRUNION DOOR
BOEING	113T8314-9	FITTING ASSY, TRUNION DOOR
HONEYWELL	2604333	RETAINER, ADJUSTER PIN
HONEYWELL	2606727	PLATE, PRESSURE
HONEYWELL	2607026	PISTON HSG & PLUG ASSY
HONEYWELL	2607029	SPRING, HELICAL COM
HONEYWELL	2607117	PISTON
HONEYWELL	2607583	PLATE, STATOR
HONEYWELL	2608842	INSULATOR, PISTON

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

HONEYWELL	2608843	INSULATOR, PISTON
HONEYWELL	2609566	SPRING, HELICAL COM
HONEYWELL	2610484	RETAINER, ADJUSTER PIN
HONEYWELL	2606810-660	ROTOR ASSY
HONEYWELL	2606810-700	ROTOR ASSY
HONEYWELL	2607026-1	PISTON HSG & PLUG ASSY
HONEYWELL	2607091-2	PIN, ADJUSTER
HONEYWELL	2609569-1	PISTON
HONEYWELL	2609569-2	PISTON
GOODRICH	49-279	PLUG, OVERINFLATION
GOODRICH	85-618	RING, RETAINING
GOODRICH	68-1270	SEAL, GREASE
GOODRICH	48385-20629	CONE, BEARING
GOODRICH	68-1271	SEAL, GREASE
GOODRICH	XC02638CB206 29	CONE, BEARING
GOODRICH	43-1334	BOLT
GOODRICH	60-869	SPACER
GOODRICH	300-835	WHEEL HALF ASSY, OUTER
GOODRICH	48320-20629	CUP, BEARING (OUTER)
GOODRICH	56-1029	RETAINER, GREASE
GOODRICH	300-834-2	WHEEL HALF ASSY, INNER
GOODRICH	49-332	PLUG, THERMAL RELIEF
GOODRICH	252-151	BAR, TORQUE
GOODRICH	245-245	RING, CHIN
GOODRICH	378-87	SHIELD ASSY, HEAT
GOODRICH	60-868	SPACER, HEAT SHIELD
GOODRICH	245-247	RING, RETAINING, INNER
GOODRICH	39-159	SEAL, GREASE, OUTER
GOODRICH	39-105	SEAL, GREASE, INNER
GOODRICH	LM229147C20629	CONE, BEARING OUTER
GOODRICH	LM330448- 20629	CONE, BEARING INNER
GOODRICH	43-1399	BOLT
GOODRICH	300-811	WHEEL HALF, ASSY OUTER
GOODRICH	56-998	RETAINER, GREASE OUTER
GOODRICH	LM229110- 20629	CUP, BEARING (OUTER)
GOODRICH	300-812	WHEEL HALF, ASSY INNER
GOODRICH	56-997	RETAINER, GREASE INNER
GOODRICH	LM330410- 20629	CUP, BEARING (INNER)
CASA	212-41200-02-1	LANDING GEAR TUBE
CASA	212-42112-3	STEERING ACTUATOR

CASA	212-42112-5	STEERING ACTUATOR
CASA	212-42112-7	STEERING ACTUATOR
CASA	212-42200-02-2	LANDING GEAR TUBE
CASA	212-42206	LANDING GEAR TUBE
CASA	CA19600A-1	4 WAY VALVE
CASA	CA23700-1	BRAKE VALVE
CASA	CA23700-3	BRAKE VALVE
CASA	CA23700-5	BRAKE LOCK
CASA	CA23800-1	HYD BRAKE LOCK
CASA	CA23800-3	HYD BRAKE LOCK
CASA	CA23800-5	HYD BRAKE LOCK
CASA	CA238200-3	CARGO RAMP ACTUATOR
CASA	CA238200-5	CARGO RAMP ACTUATOR
CASA	CA23900-1	RETURN CHECK LOCK
CASA	CA24000-1	HYD BRAKE VALVE
CASA	CA24100-1	THERMAL SAFETY VALVE
CASA	CA24200-1	ACCUMULATOR
CASA	CA24200-3	ACCUMULATOR
CASA	CA24600-1	RELEIF VALVE
CASA	CA24600-3	RELEIF VALVE
CASA	CA24700-1	HAND PUMP
CASA	CA24700-3	HAND PUMP
CASA	CA24800-3	PRESSURE VALVE
CASA	CA25000-3	HYDRAULIC ACTUATOR
CASA	CA25000-5	HYD ACT
CASA	CA25300-5	LIMITING VALVE
CASA	CA26500-3	HYD. SHUT OFF VALVE
CASA	CA26500-5	HYD. SHUT OFF VALVE
CASA	CA265010-0001	HYD. SHUT OFF VALVE
CASA	CA26600-1	SAFETY VALVE
CASA	CA26600-3	FUEL SELECTOR
CASA	CA26700-1	RESTRICTOR
CASA	CA26700-11	RESTRICTOR VALVE
CASA	CA26700-13	RESTRICTOR VALVE
CASA	CA26700-15	RESTRICTOR VALVE
CASA	CA26700-17	RESTRICTOR VALVE
CASA	CA26700-19	RESTRICTOR VALVE
CASA	CA26700-21	RESTRICTOR VALVE
CASA	CA26700-23	RESTRICTOR VALVE
CASA	CA26700-25	RESTRICTOR VALVE

CASA	CA26700-3	RESTRICTOR VALVE
CASA	CA26700-5	RESTRICTOR VALVE
CASA	CA26700-7	RESTRICTOR VALVE
CASA	CA26700-9	RESTRICTOR VALVE
CASA	CA36200-3	FLAP ACTUATOR
CASA	CA38200-3	HYD SHUT OFF VALVE
CASA	CA38200-5	HYD SHUT OFF VALVE
CASA	CA38700-1	UN.F.METERING PUMP
CASA	CA388001-1	NON RETURN VALVE
CASA	CA4600-0003	RELEIF VALVE
CASA	CA47200-1	CHECK VALVE
CASA	CA54500-0001	VALVE ASSY, SHUTTLE
CASA	CA54500-0003	VALVE ASSY, SHUTTLE
CASA	CA78100-0001	PRESS REGULATOR VALVE
CASA	CA82600	4 WAY VALVE
CASA	CA9700-1	DRAIN VALVE
MEGGITT	5000788	SEALBEARING,OUTBOARD
MEGGITT	5004884	SEALBEARING,INBOARD
MEGGITT	5005358	SHIELDSUBASSY
MEGGITT	5003330-3	WHEEL,SUBASSY,OUT
MEGGITT	5011169	WHEEL,SUBASSY,IN
MEGGITT	5008120	PLUG,SUBASSY
MEGGITT	5002213	DEFLECTOR,FUS PLUG
MEGGITT	5004488-1	KEY, DISK DRIVE
MEGGITT	5011170	KEY, DISK DRIVE
MEGGITT	5000638	PLUG,FUSIBLE
MEGGITT	5000981	BOLT
MEGGITT	42FBN1018N	NUT,BARREL
MEGGITT	42FBN1018AN	NUT,BARREL
MEGGITT	5001804	DISK,SUBASSY
MEGGITT	5006855	DISK,SUBASSY,ROT
MEGGITT	5003612-1	TORQUETUBE SUB
MEGGITT	5001904-1	TUBE,TORQUE
MEGGITT	5001807	PRESSUREPLATE
MEGGITT	5001807-1	PRESSUREPLATE
MEGGITT	5000836	HOUSING,SPRING
MEGGITT	5000837	HOLDER,SPRING
MEGGITT	5000838	SPRING,RETURN
MEGGITT	5009831	INSULATOR, PISTON
MEGGITT	5003366	SLEEVE,CYLINDER

MEGGITT	5003366-1	SLEEVE,CYLINDER
MEGGITT	5000831	PISTON,SLEEVE
MEGGITT	AE95613H	COUPLINGHALF, INLET
EATON	63240	ACTUATOR,THRUSTREV
EATON	63240-1	ACTUATOR,THRUSTREV
BOEING	3915180-5501	M&NSWIVELGLAND ASSY
BOEING	3915180-5503	M&NSWIVELGLAND ASSY
BOEING	3920208-501	NG DRAG LINK & UP. LOCK
BOEING	3920208-503	NG DRAG LINK & UP. LOCK
BOEING	3920208-505	NG DRAG LINK & UP. LOCK
BOEING	3920208-507	NG DRAG LINK & UP. LOCK
BOEING	3920208-509	NG DRAG LINK & UP. LOCK
BOEING	3920208-511	NG DRAG LINK & UP. LOCK
BOEING	3920208-513	NG DRAG LINK & UP. LOCK
BOEING	3920208-515	NG DRAG LINK & UP. LOCK
BOEING	3920208-517	NG DRAG LINK & UP. LOCK
BOEING	3920208-519	NG DRAG LINK & UP. LOCK
BOEING	3934689-5001	NW STEERING CYLINDER
BOEING	3934689-5501	NW STEERING CYLINDER
BOEING	3937033-5001	MLG BUNGEE CYL. ASSY
BOEING	3937033-5501	MLG BUNGEE CYL. ASSY
BOEING	3937033-5503	MLG BUNGEE CYL. ASSY
ZODIAC	4223448	LANDING & TAXILIGHT
ZODIAC	4385321	LANDING & TAXILIGHT
HONEYWELL	10-0067-7	EMERGENCY EXIT LIGHT
HONEYWELL	10-0067-9	EMERGENCY EXIT LIGHT
BOEING	10-60091-102	EMERGENCY EXIT LIGHT
BOEING	10-60091-101	EMERGENCY EXIT LIGHT
BOEING	5910094-3	NG DRAG LINK & UP. LOCK
BOEING	5910094-7	NG DRAG LINK & UP. LOCK
BOEING	5910446-11	NG DRAG LINK & UP. LOCK
BOEING	5910446-3	NG DRAG LINK & UP. LOCK
BOEING	5910446-7	NG DRAG LINK & UP. LOCK
BOEING	5914066-5501	RUDDER PWR CTRL & ACT
BOEING	5914066-5505	RUDDER PWR CTRL & ACT
BOEING	5914066-5507	RUDDER PWR CTRL & ACT
BOEING	5914066-5509	RUDDER PWR CTRL & ACT
BOEING	5914066-5511	RUDDER PWR CTRL & ACT
BOEING	5914066-5513	RUDDER PWR CTRL & ACT
BAE SYSTEM	L16-8	OIL COOLER DOOR ACTUATOR

BAE SYSTEM	L16-8-1	OIL COOLER DOOR ACTUATOR
BAE SYSTEM	L16-8-3	OIL COOLER DOOR ACTUATOR
BAE SYSTEM	L16-8-5	OIL COOLER DOOR ACTUATOR
BOEING	5910448-1	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-501	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-503	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-507	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-509	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-511	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-513	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-515	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-517	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-519	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-521	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-523	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-525	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-527	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-529	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-531	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-533	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-535	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-537	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-539	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-541	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-543	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-545	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-547	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-549	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-551	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-553	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-555	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-557	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-559	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-561	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-563	NOSE GEAR SHOCK STRUT ASSY
BOEING	5910448-565	NOSE GEAR SHOCK STRUT ASSY
BOEING	SR09320054-5	NOSE GEAR SHOCK STRUT ASSY
BOEING	SR09320056-11	NOSE GEAR SHOCK STRUT ASSY
BOEING	SR09320056-15	NOSE GEAR SHOCK STRUT ASSY
BOEING	SR09320056-3	NOSE GEAR SHOCK STRUT ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

www.ticaerospace.com

BOEING	SR09320056-5	NOSE GEAR SHOCK STRUT ASSY
BOEING	SR09320056-9	NOSE GEAR SHOCK STRUT ASSY
GOODRICH	260-889-1	HOUSING, PISTON
GOODRICH	266-263-1	PISTON HSG ASSY
GOODRICH	40-716	SPRING
GOODRICH	40-759	SPRING
GOODRICH	43-1390	BOLT
GOODRICH	5104-04E-E17	COUPLING, QUICK DISC
GOODRICH	54-624	SLEEVE, ADJUSTER
GOODRICH	74-979	PISTON
GOODRICH	113-163	GUIDE, SPRING
GOODRICH	20-746	PIN, ADJUSTER
GOODRICH	211-118	VALVE ASSY, SHUTTLE
GOODRICH	260-910-2	HOUSING, PISTON
GOODRICH	266-287-1	PISTON HSG ASSY
GOODRICH	43-1429	BOLT
GOODRICH	43-1429-1	BOLT
GOODRICH	4-389	TORQUE PLATE ASSY
GOODRICH	54-268	SLEEVE, ADJUSTER
GOODRICH	AE71882E	COUPLING, QUICK DISC
MEGGITT	5011454	INSULATOR, METAL
MEGGITT	90001196	VALVE, SHUTTLE
MEGGITT	90002341	BRAKE HOUSING
MEGGITT	90002347	TORQUE TUBE
MEGGITT	90002366	SLEEVE, CYLINDER
MEGGITT	90002367	PISTON
MEGGITT	90002368	HOLDER, SPRING
MEGGITT	90002369	PIN, BRAKE RETURN
MEGGITT	90004459	BRACKET, BRAKE HSG
MEGGITT	90000649-1	RET, BRAKE RETURN
MEGGITT	AE74593G	QUICK DISCONNECT,
MEGGITT	MS21250H08012	BOLT, 12 POINT
MEGGITT	50FK1018	NUT, SELF LOCKING HEX
BOEING	5920603-503	PISTON ASSY
BOEING	5923142-5001	DAMPER ASSY
BOEING	5923142-5501	DAMPER ASSY
BOEING	5923142-5503	DAMPER ASSY
BOEING	5923142-5505	DAMPER ASSY
BOEING	5923142-5507	DAMPER ASSY
BOEING	5923142-5509	DAMPER ASSY

BOEING	5923142-5511	DAMPER ASSY
BOEING	5923142-5513	DAMPER ASSY
BOEING	SR09320057-7009	DAMPER ASSY
BOEING	5937036-5001	MLG RETRACT CYL
BOEING	5937036-5501	MLG RETRACT CYL
BOEING	5937036-5503	MLG RETRACT CYL ASSY
BOEING	5937036-5505	MLG RETRACT CYL ASSY
BOEING	5937036-5507	MLG RETRACT CYL
BOEING	5956101-5501	NW STEER BYPASS
BOEING	5965065-1	NG DRAG LINK & UP. LOCK ASSY
BOEING	5965065-505	NG DRAG LINK & UP.
BOEING	5965065-507	NG DRAG LINK & UP. LOCK ASSY
BOEING	5965065-509	NG DRAG LINK & UP.
BOEING	5965065-511	NG DRAG LINK & UP. LOCK ASSY
BOEING	5914066-5515	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5517	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5519	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5521	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5523	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5525	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5527	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5529	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5531	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5533	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5535	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5537	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5539	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5541	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5543	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5545	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5547	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5549	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5559	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5561	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5563	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5565	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5567	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5569	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5571	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5573	RUDDER PWR CTRL & ACT ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	5914066-5575	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5577	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5581	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5583	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-15	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-17	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-19	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-21	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-23	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-25	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-43	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-45	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-47	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-63	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-31	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-33	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-35	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-37	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-39	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270281-41	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-33	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-35	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-37	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-39	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-41	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-43	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-45	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-47	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-49	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-51	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-53	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-57	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-59	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-61	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-65	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270290-67	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-129	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-13	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-15	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-17	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-19	RUDDER PWR CTRL & ACT ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	SB09270301-21	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-23	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-25	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-27	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-29	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-51	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-53	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-55	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-57	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-59	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-61	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-63	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-65	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-67	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-69	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270301-71	RUDDER PWR CTRL & ACT ASSY
BOEING	SB09270360-7	RUDDER PWR CTRL & ACT ASSY
BOEING	5920605-11	LEVER
CRANE	40-625	TRANSDUCER ASSY
CRANE	40-625-2	TRANSDUCER ASSY
CRANE	40-625-4	TRANSDUCER ASSY
CRANE	40-625-4A	TRANSDUCER ASSY
CRANE	40-625-5	TRANSDUCER ASSY
CRANE	40-625-6	TRANSDUCER ASSY
CRANE	40-625-7	TRANSDUCER ASSY
CRANE	40-625-8	TRANSDUCER ASSY
CRANE	40-62575	TRANSDUCER SUBASSY
WOODWARD	1U1171-2	BODY GEAR STEERING ACTUATOR
WOODWARD	1U1171-3	BODY GEAR STEERING ACTUATOR
WOODWARD	1U1171-4	BODY GEAR STEERING ACTUATOR
WOODWARD	1U1171-5	BODY GEAR STEERING ACTUATOR
BOEING	60B00223-1	BODY GEAR STEERING ACTUATOR
BOEING	60B00223-3	BODY GEAR STEERING ACTUATOR
HONEYWELL	3505448-3-1	AIR TURBINE ENGINE STARTER
GENERAL ELECTRIC	9281M79P01	AIR TURBINE ENGINE STARTER
HONEYWELL	3505448-5-1	AIR TURBINE ENGINE STARTER
GENERAL ELECTRIC	9281M79P03	AIR TURBINE ENGINE STARTER
SAFRAN	C5116-03	STARTER MOTOR
SAFRAN	C5116-04	STARTER MOTOR
SAFRAN	C5116-05	STARTER MOTOR
SAFRAN	C5116-06	STARTER MOTOR

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

SAFRAN	C5116-07	STARTER MOTOR
SAFRAN	C5116-08	STARTER MOTOR
SAFRAN	C5116-09	STARTER MOTOR
SAFRAN	C5116-10	STARTER MOTOR
SAFRAN	C5116-11	STARTER MOTOR
P&WC	3900276	STARTER MOTOR
P&WC	3900357	STARTER MOTOR
P&WC	3900377	STARTER MOTOR
P&WC	3900460	STARTER MOTOR
P&WC	3900616	STARTER MOTOR
P&WC	3911993-01	STARTER MOTOR
P&WC	3912086-01	STARTER MOTOR
P&WC	3912086-02	STARTER MOTOR
P&WC	3912086-03	STARTER MOTOR
DONALLCO	AG34	TACHOMETER
HONEYWELL	3290050-1	DS CONTROL VALVE
CCSWITCHES	42D115	PRESSURE SWITCH
EATON	D2405-3	PUSH-P LINEAR ACTUATOR
EATON	D2405-4	PUSH-P LINEAR ACTUATOR
EATON	D2405-5	PUSH-P LINEAR ACTUATOR
BOEING	60B80020-3	PUSH-P LINEAR ACTUATOR
BOEING	60B80020-4	PUSH-P LINEAR ACTUATOR
BOEING	60B80020-5	PUSH-P LINEAR ACTUATOR
HONEYWELL	3275538-2 1477M56P02	BALLSCREW GEARBOX ASSY
HONEYWELL	3275538-3 1477M56P03	BALLSCREW GEARBOX ASSY
HONEYWELL	3238329-1	ACTUATOR BALLSCREW
HONEYWELL	3238329-2	ACTUATOR BALLSCREW
BOEING	5913900-5505	FLIGHT SPOILER ACTUATOR ASSY
BOEING	5913900-5507	FLIGHT SPOILER ACTUATOR ASSY
BOEING	5913900-5509	FLIGHT SPOILER ACTUATOR ASSY
BOEING	5913900-5511	FLIGHT SPOILER ACTUATOR ASSY
BOEING	5913900-5513	FLIGHT SPOILER ACTUATOR ASSY
BOEING	5913900-5515	FLIGHT SPOILER ACTUATOR ASSY
BOEING	5913900-5517	FLIGHT SPOILER ACTUATOR ASSY
BOEING	5913900-5519	FLIGHT SPOILER ACTUATOR ASSY
BOEING	5913900-5521	FLIGHT SPOILER ACTUATOR ASSY
BOEING	5913900-5523	FLIGHT SPOILER ACTUATOR ASSY
BOEING	5913900-5525	FLIGHT SPOILER ACTUATOR ASSY
BOEING	SB09270274-11	FLIGHT SPOILER ACTUATOR ASSY
BOEING	SB09270274-13	FLIGHT SPOILER ACTUATOR ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	SB09270274-15	FLIGHT SPOILER ACTUATOR ASSY
BOEING	SB09270274-17	FLIGHT SPOILER ACTUATOR ASSY
BOEING	5971330-5001	MLG RETRACT CYL ASSY
BOEING	5971330-5501	MLG RETRACT CYL ASSY
BOEING	SR09320063-11	MLG RETRACT CYL ASSY
BOEING	SR09320063-13	MLG RETRACT CYL ASSY
BOEING	SR09320063-17	MLG RETRACT CYL ASSY
TELAIR	1051T100-9	APU AIR INLET DOOR ACTUATOR
TELAIR	1051T100-11	APU AIR INLET DOOR ACTUATOR
TELAIR	1051T100-13	APU AIR INLET DOOR ACTUATOR
TELAIR	1051T100-17	APU AIR INLET DOOR ACTUATOR
PARKER HANNIFIN	2670005M2	NOSE WHEEL METERING VALVE ASSY
PARKER HANNIFIN	2670005M21	NOSE WHEEL METERING VALVE ASSY
PARKER HANNIFIN	2670005M4	NOSE WHEEL METERING VALVE ASSY
PARKER HANNIFIN	2670005M5	NOSE WHEEL METERING VALVE ASSY
PARKER HANNIFIN	2670005M6	NOSE WHEEL METERING VALVE ASSY
PARKER HANNIFIN	2670005M7	NOSE WHEEL METERING VALVE ASSY
PARKER HANNIFIN	60B00210-2	NOSE WHEEL METERING VALVE ASSY
PARKER HANNIFIN	60B00210-4	NOSE WHEEL METERING VALVE ASSY
BOEING	60B00210-5	NOSE WHEEL METERING VALVE ASSY
PARKER HANNIFIN	60B00210-6	NOSE WHEEL METERING VALVE ASSY
PARKER HANNIFIN	60B00210-7	NOSE WHEEL METERING VALVE ASSY
MEGGITT	5001120	ADAPTER, SENSOR
ROHR	224-2301-509	CORE COWL ASSY
ROHR	224-2301-513	CORE COWL ASSY
ROHR	224-2301-517	CORE COWL ASSY
ROHR	224-2301-523	CORE COWL ASSY
ROHR	224-2302-509	CORE COWL ASSY
ROHR	224-2302-533	CORE COWL ASSY
ROHR	224-2302-541	CORE COWL ASSY
ROHR	224-2302-547	CORE COWL ASSY
ROHR	238-2101-503	CORE COWL ASSY
ROHR	238-0101-505	CORE COWL ASSY
BOEING	015T0805-10	PRIMARY NOZZLE ASSY
BOEING	015T0805-11	PRIMARY NOZZLE ASSY
BOEING	015T0805-12	PRIMARY NOZZLE ASSY
BOEING	015T0805-05	PRIMARY NOZZLE ASSY
BOEING	015T0805-06	PRIMARY NOZZLE ASSY
BOEING	015T0805-07	PRIMARY NOZZLE ASSY
BOEING	015T0805-08	PRIMARY NOZZLE ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	015T0805-09	PRIMARY NOZZLE ASSY
BOEING	015U1547-11	PRIMARY NOZZLE ASSY
BOEING	015U1547-111	PRIMARY NOZZLE ASSY
BOEING	015U1547-112	PRIMARY NOZZLE ASSY
BOEING	015U1547-27	PRIMARY NOZZLE ASSY
BOEING	015U1547-271	PRIMARY NOZZLE ASSY
BOEING	015U1547-272	PRIMARY NOZZLE ASSY
BOEING	015U1547-31	PRIMARY NOZZLE ASSY
BOEING	015U1547-311	PRIMARY NOZZLE ASSY
BOEING	015U1547-312	PRIMARY NOZZLE ASSY
BOEING	015U1547-43	PRIMARY NOZZLE ASSY
BOEING	015U1547-431	PRIMARY NOZZLE ASSY
BOEING	015U1547-432	PRIMARY NOZZLE ASSY
BOEING	015U1547-46	PRIMARY NOZZLE ASSY
BOEING	314U2100-1	PRIMARY NOZZLE ASSY
BOEING	314U2100-27	PRIMARY NOZZLE ASSY
BOEING	314U2100-30	PRIMARY NOZZLE ASSY
BOEING	314U2100-31	PRIMARY NOZZLE ASSY
BOEING	314U2100-43	PRIMARY NOZZLE ASSY
BOEING	314U2100-46	PRIMARY NOZZLE ASSY
BOEING	314U2100-47	PRIMARY NOZZLE ASSY
BOEING	314U2100-53	PRIMARY NOZZLE ASSY
BOEING	314U2100-57	PRIMARY NOZZLE ASSY
BOEING	314U2100-70	PRIMARY NOZZLE ASSY
BOEING	314U2100-71	PRIMARY NOZZLE ASSY
BOEING	314U2100-72	PRIMARY NOZZLE ASSY
BOEING	314U2100-82	PRIMARY NOZZLE ASSY
GOODRICH	224-2302-517	RH CORE COWL
GOODRICH	224-2302-521	RH CORE COWL
GOODRICH	224-2302-523	RH CORE COWL
GOODRICH	224-2302-525	RH CORE COWL
GOODRICH	224-2302-527	RH CORE COWL
GOODRICH	224-2302-529	RH CORE COWL
GOODRICH	224-2302-531	RH CORE COWL
GOODRICH	224-2302-545	RH CORE COWL
GOODRICH	224-2302-537	RH CORE COWL
GOODRICH	224-2302-539	RH CORE COWL
GOODRICH	224-2302-551	RH CORE COWL
GOODRICH	224M4761-517	RH CORE COWL
GOODRICH	224M4761-521	RH CORE COWL

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

GOODRICH	224M4761-523	RH CORE COWL
GOODRICH	224M4761-525	RH CORE COWL
GOODRICH	224M4761-527	RH CORE COWL
GOODRICH	224M4761-529	RH CORE COWL
GOODRICH	224M4761-545	RH CORE COWL
GOODRICH	224M4761-537	RH CORE COWL
GOODRICH	224M4761-539	RH CORE COWL
GOODRICH	224-2201-507	LH FAN COWL
GOODRICH	224-2201-509	LH FAN COWL
GOODRICH	224-2280-501	LH FAN COWL
GOODRICH	224-2280-503	LH FAN COWL
BOEING	015T0109-43	CORE COWL ASSY
BOEING	015T0132-3	CORE COWL ASSY
BOEING	015T0132-4	CORE COWL ASSY
BOEING	015T0412-4	CORE COWL ASSY
BOEING	015T0412-5	CORE COWL ASSY
BOEING	015T0412-6	CORE COWL ASSY
BOEING	015T0412-7	CORE COWL ASSY
BOEING	015T0437-47	CORE COWL ASSY
BOEING	015T0437-48	CORE COWL ASSY
BOEING	015T0437-49	CORE COWL ASSY
BOEING	015T0437-50	CORE COWL ASSY
BOEING	015T0437-51	CORE COWL ASSY
BOEING	015T0437-52	CORE COWL ASSY
BOEING	015T0540-28	CORE COWL ASSY
BOEING	015T0540-29	CORE COWL ASSY
BOEING	015T0540-30	CORE COWL ASSY
BOEING	015T0540-31	CORE COWL ASSY
BOEING	015T0540-32	CORE COWL ASSY
BOEING	015T0540-33	CORE COWL ASSY
BOEING	314T1001-10	CORE COWL ASSY
BOEING	314T1001-3	CORE COWL ASSY
BOEING	314T1001-4	CORE COWL ASSY
BOEING	314T1001-5	CORE COWL ASSY
BOEING	314T1001-8	CORE COWL ASSY
BOEING	314T1001-9	CORE COWL ASSY
BOEING	314T1210-1	CORE COWL ASSY
BOEING	314T1210-2	CORE COWL ASSY
BOEING	314T1210-247	CORE COWL ASSY
BOEING	314T1210-248	CORE COWL ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	314T1210-365	CORE COWL ASSY
BOEING	314T1210-366	CORE COWL ASSY
BOEING	314T1210-408	CORE COWL ASSY
BOEING	301A1067-3	THRUST REVERSER
BOEING	301A1067-30	THRUST REVERSER
BOEING	301A1067-31	THRUST REVERSER
BOEING	301A1067-32	THRUST REVERSER
BOEING	301A1067-33	THRUST REVERSER
BOEING	301A1067-34	THRUST REVERSER
BOEING	301A1067-35	THRUST REVERSER
BOEING	301A1067-36	THRUST REVERSER
BOEING	301A1067-37	THRUST REVERSER
BOEING	301A1067-38	THRUST REVERSER
BOEING	301A1067-40	THRUST REVERSER
BOEING	301A1067-41	THRUST REVERSER
BOEING	301A1067-42	THRUST REVERSER
BOEING	301A1067-43	THRUST REVERSER
BOEING	301A1067-44	THRUST REVERSER
BOEING	301A1067-45	THRUST REVERSER
BOEING	301A1067-46	THRUST REVERSER
BOEING	301A1067-47	THRUST REVERSER
BOEING	301A1067-48	THRUST REVERSER
BOEING	301A1067-49	THRUST REVERSER
BOEING	301A1067-50	THRUST REVERSER
BOEING	301A1067-51	THRUST REVERSER
BOEING	301A1067-52	THRUST REVERSER
BOEING	301A1067-53	THRUST REVERSER
BOEING	301A1067-54	THRUST REVERSER
BOEING	301A1067-55	THRUST REVERSER
BOEING	301A1067-56	THRUST REVERSER
BOEING	301A1067-57	THRUST REVERSER
BOEING	301A1067-58	THRUST REVERSER
BOEING	301A1067-63	THRUST REVERSER
BOEING	301A1067-64	THRUST REVERSER
BOEING	301A1067-65	THRUST REVERSER
BOEING	301A1067-66	THRUST REVERSER
BOEING	314A1502-50	SLEEVE ASSY
BOEING	314A1502-51	SLEEVE ASSY
BOEING	314A1502-57	SLEEVE ASSY
BOEING	314A1502-58	SLEEVE ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	314A1502-59	SLEEVE ASSY
BOEING	314A1502-71	SLEEVE ASSY
BOEING	314A2610-1	PRIMARY NOZZLE ASSY
BOEING	314A2610-62	PRIMARY NOZZLE ASSY
BOEING	314A2610-68	PRIMARY NOZZLE ASSY
BOEING	314A2630-100	PRIMARY NOZZLE ASSY
BOEING	314A2630-101	PRIMARY NOZZLE ASSY
BOEING	314A2630-102	PRIMARY NOZZLE ASSY
BOEING	314A2630-103	PRIMARY NOZZLE ASSY
BOEING	314A2630-104	PRIMARY NOZZLE ASSY
BOEING	314A2630-105	PRIMARY NOZZLE ASSY
BOEING	315A1001-10SP	THRUST REVERSER
BOEING	315A1001-11SP	THRUST REVERSER
BOEING	315A1001-12SP	THRUST REVERSER
BOEING	315A1001-13	THRUST REVERSER
BOEING	315A1001-14	THRUST REVERSER
BOEING	315A1001-15	THRUST REVERSER
BOEING	315A1001-16	THRUST REVERSER
BOEING	315A1001-17	THRUST REVERSER
BOEING	315A1001-18	THRUST REVERSER
BOEING	315A1001-19	THRUST REVERSER
BOEING	315A1001-1SP	THRUST REVERSER
BOEING	315A1001-20	THRUST REVERSER
BOEING	315A1001-25	THRUST REVERSER
BOEING	315A1001-26	THRUST REVERSER
BOEING	315A1001-27	THRUST REVERSER
BOEING	315A1001-28	THRUST REVERSER
BOEING	315A1001-29	THRUST REVERSER
BOEING	315A1002-1	THRUST REVERSER
BOEING	315A1701-10	THRUST REVERSER
BOEING	315A2295-219	FAN DUCT COWL AND T/R
BOEING	315A2295-220	FAN DUCT COWL AND T/R
HONEYWELL	3605812-1	STARTER
HONEYWELL	GTCP36-280D	APU
HONEYWELL	GTCP36-280A	APU
HONEYWELL	GTCP36-280B	APU
HONEYWELL	GTCP85-129(H)	APU
HONEYWELL	GTCP85-129(J)	APU
HONEYWELL	GTCP85-129(K)	APU
SAFRAN	745-0002-505	THRUST REVERSER ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

SAFRAN	745-0002-517	THRUST REVERSER ASSY
MRAS	533A00000	THRUST REVERSER
MRAS	533A00000-501	THRUST REVERSER
MRAS	533A00000-503	THRUST REVERSER
MRAS	533A00000-505	THRUST REVERSER
MRAS	533A00000-507	THRUST REVERSER
MRAS	683L136G01	THRUST REVERSER
MRAS	683L136G02	THRUST REVERSER
MRAS	683L136G03	THRUST REVERSER
MRAS	683L136G04	THRUST REVERSER
MRAS	683L136G05	THRUST REVERSER
MRAS	683L136G06	THRUST REVERSER
MRAS	683L136G07	THRUST REVERSER
MRAS	683L136G08	THRUST REVERSER
MRAS	683L136G09	THRUST REVERSER
MRAS	683L136G10	THRUST REVERSER
MRAS	683L136G11	THRUST REVERSER
MRAS	683L136G13	THRUST REVERSER
MRAS	683L136G14	THRUST REVERSER
MRAS	683L136G15	THRUST REVERSER
MRAS	683L137G01	THRUST REVERSER
MRAS	683L137G02	THRUST REVERSER
MRAS	683L137G03	THRUST REVERSER
MRAS	683L137G04	THRUST REVERSER
MRAS	683L137G05	THRUST REVERSER
MRAS	683L137G06	THRUST REVERSER
MRAS	683L137G07	THRUST REVERSER
MRAS	683L137G08	THRUST REVERSER
MRAS	683L137G09	THRUST REVERSER
MRAS	683L137G10	THRUST REVERSER
MRAS	683L137G11	THRUST REVERSER
MRAS	683L137G13	THRUST REVERSER
MRAS	683L137G14	THRUST REVERSER
MRAS	683L137G15	THRUST REVERSER
MRAS	683L180G01	THRUST REVERSER
MRAS	683L180G02	THRUST REVERSER
MRAS	683L180G03	THRUST REVERSER
MRAS	683L180G04	THRUST REVERSER
MRAS	683L180G05	THRUST REVERSER
MRAS	683L180G06	THRUST REVERSER

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

MRAS	683L180G07	THRUST REVERSER
MRAS	683L180G08	THRUST REVERSER
MRAS	683L180G09	THRUST REVERSER
MRAS	683L180G10	THRUST REVERSER
MRAS	683L181G01	THRUST REVERSER
MRAS	683L181G02	THRUST REVERSER
MRAS	683L181G03	THRUST REVERSER
MRAS	683L181G04	THRUST REVERSER
MRAS	683L181G05	THRUST REVERSER
MRAS	683L181G06	THRUST REVERSER
MRAS	683L181G07	THRUST REVERSER
MRAS	683L181G08	THRUST REVERSER
MRAS	683L181G09	THRUST REVERSER
MRAS	683L181G10	THRUST REVERSER
MRAS	683L213G02	THRUST REVERSER
MRAS	683L213G03	THRUST REVERSER
MRAS	683L213G04	THRUST REVERSER
MRAS	683L213G05	THRUST REVERSER
MRAS	683L214G02	THRUST REVERSER
MRAS	683L214G04	THRUST REVERSER
MRAS	683L214G05	THRUST REVERSER
MRAS	683L214G06	THRUST REVERSER
MRAS	683L215G02	THRUST REVERSER
MRAS	683L215G03	THRUST REVERSER
MRAS	683L215G04	THRUST REVERSER
MRAS	683L215G05	THRUST REVERSER
MRAS	683L293G01	THRUST REVERSER
MRAS	683L293G02	THRUST REVERSER
MRAS	683L294G01	THRUST REVERSER
MRAS	683L294G02	THRUST REVERSER
GOODRICH	224-2202-507	FAN COWL
GOODRICH	224-2202-509	FAN COWL
GOODRICH	224-2101-513	INLET COWL
GOODRICH	224-2101-527	INLET COWL
GOODRICH	224-2101-531	INLET COWL
GOODRICH	224-2101-543	INLET COWL
GOODRICH	224-2101-563	INLET COWL
GOODRICH	224-2101-571	INLET COWL
GOODRICH	224-2101-573	INLET COWL
HARTWELL CORP	H2927-1	TOGGLE HOOK LATCH ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

HARTWELL CORP	H2927-3	TOGGLE HOOK LATCH ASSY
HARTWELL CORP	H2927-7	TOGGLE HOOK LATCH ASSY
MARATHON NARCO	A2785-12	FAN COWL HOLD ROD
MARATHON NARCO	A2785-14	FAN COWL HOLD ROD
MARATHON NARCO	A2785-15	FAN COWL HOLD ROD
MARATHON NARCO	A2785-16	FAN COWL HOLD ROD
CASA	212-41200-1	MLG SHOCK ABSORBER
CASA	212-41000.1	MLG SHOCK ABSORBER
CASA	212-41000.3	MLG SHOCK ABSORBER
CASA	212-42210.5	NLG SHOCK ABSORBER
CASA	212-42210.7	NLG SHOCK ABSORBER
CASA	212-42210.0009	NLG SHOCK ABSORBER
CASA	212-42200-1	NLG SHOCK ABSORBER
CASA	212-42200-3	NLG SHOCK ABSORBER
CASA	212-42200-5	NLG SHOCK ABSORBER
CASA	212-42200-7	NLG SHOCK ABSORBER
CASA	212-42100.1	NLG SHOCK ABSORBER
CASA	CA.23700.1	HYD. POWER BRAKE VALVE
CASA	CA.23700.3	HYD. POWER BRAKE VALVE
CASA	CA.23700.5	HYD. POWER BRAKE VALVE
CASA	CA.24000.1	HYD. BRAKE SHUTT. VALVE
CASA	CA.24000.3	HYD. BRAKE SHUTT. VALVE
CASA	CA.24200.1	PNEUDRALIC
CASA	CA.24200.3	PNEUDRALIC
CASA	CA.23800.1	HYD.POWER BRAKE VALVE
CASA	CA.23800.3	HYD.POWER BRAKE VALVE
CASA	CA.23800.5	HYD.POWER BRAKE VALVE
CASA	CA.24600.1	¼" HYDR. RELIEF VALVE
CASA	CA.24600.3	¼" HYDR. RELIEF VALVE
CASA	CA45000-0001	VALVE NON RETURN
CASA	CA-46000-0003	VALVE DISCHARGE
CASA	CA-46000-0005	VALVE DISCHARGE
CASA	212-42112.3	HYDR. STEERING
CASA	212-42112.5	HYDR. STEERING
CASA	212-42112.7	HYDR. STEERING
CASA	CA.24800.3	HYDR. DIRECTIONAL VALVE
CASA	CA.25300.1	HYDR. PRESS.
CASA	CA.25300.3	HYDR. PRESS.
CASA	CA.25300.5	HYDR. PRESS.
CASA	CA.78100	PRESS. REDUC.VALVE

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	119U0020-1	WINGLET ASSY
BOEING	119U0020-2	WINGLET ASSY
BOEING	119U0020-55	WINGLET ASSY
BOEING	119U0020-56	WINGLET ASSY
BOEING	119U0020-59	WINGLET ASSY
BOEING	119U0020-60	WINGLET ASSY
BOEING	119U0020-61	WINGLET ASSY
BOEING	119U0020-62	WINGLET ASSY
BOEING	119U0020-63	WINGLET ASSY
BOEING	119U0020-64	WINGLET ASSY
BOEING	119U0020-65	WINGLET ASSY
BOEING	119U0020-66	WINGLET ASSY
BOEING	119U0020-67	WINGLET ASSY
BOEING	119U0020-68	WINGLET ASSY
BOEING	119U0020-75	WINGLET ASSY
BOEING	119U0020-76	WINGLET ASSY
BOEING	119U0020-81	WINGLET ASSY
BOEING	119U0020-82	WINGLET ASSY
BOEING	161U1000-1	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-10	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-100	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-101	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-102	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-103	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-104	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-105	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-106	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-107	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-108	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-109	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-11	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-110	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-111	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-112	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-113	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-114	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-115	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-116	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-117	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-118	WING LANDING GEAR BUILDUP ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	161U1000-119	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-12	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-120	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-13	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-135	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-136	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-14	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-15	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-16	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-19	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-2	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-20	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-23	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-24	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-25	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-26	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-27	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-28	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-29	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-30	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-31	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-32	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-33	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-34	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-35	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-36	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-37	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-38	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-39	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-40	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-41	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-42	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-5	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-53	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-54	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-55	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-56	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-57	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-58	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-59	WING LANDING GEAR BUILDUP ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	161U1000-6	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-60	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-61	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-62	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-63	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-64	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-65	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-66	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-69	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-7	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-70	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-71	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-72	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-73	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-74	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-75	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-76	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-8	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-89	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-9	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-90	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-91	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-92	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-93	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-94	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-95	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-96	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-97	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-98	WING LANDING GEAR BUILDUP ASSY
BOEING	161U1000-99	WING LANDING GEAR BUILDUP ASSY
BOEING	65B11669-1	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-115	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-116	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-117	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-118	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-119	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-120	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-123	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-124	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-125	WING LANDING GEAR INBOARD DOOR ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	65B11669-126	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-129	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-130	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-131	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-132	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-133	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-134	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-135	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-136	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-137	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-138	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-181	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-182	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-183	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-184	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-185	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-186	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-195SP	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-196SP	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-2	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-241SP	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-242SP	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-45	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-46	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-47	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-48	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-73	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B11669-74	WING LANDING GEAR INBOARD DOOR ASSY
BOEING	65B01468-4	BRAKE ROD ASSY
BOEING	65B01468-6	BRAKE ROD ASSY
BOEING	65B01468-2	BRAKE ROD
BOEING	65B01468-7	BRAKE ROD
BOEING	65B05319-1	PRESSURE GAUGE VALVE ASSY
BOEING	65B05478-4	BOLT, BRAKE ROD
BOEING	65B05478-5	BOLT, BRAKE ROD
BOEING	65B05480-3	BOLT, BRAKE ROD
BOEING	65B05480-5	BOLT, BRAKE ROD
BOEING	65B05480-6	BOLT, BRAKE ROD
BOEING	160U0100-11	MLG BRAKE ROD LOAD SENSOR ASSY
BOEING	160U0100-6	BRAKE ROD SUB ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	160U0100-13	BRAKE ROD SUB ASSY
BOEING	65B13644-5	ACTUATOR FITTING ASSY
BOEING	65B13644-6	ACTUATOR FITTING ASSY
BOEING	65B13644-7	FITTING
BOEING	65B13644-8	FITTING
BOEING	69B12599-3	CLEVIS ASSY
BOEING	69B12599-4	CLEVIS ASSY
BOEING	161U0071-1	BOLT, BRAKE ROD
BOEING	168U0104-1	MOUNTING RING ASSY
BOEING	168U0104-2	RING
BOEING	65B13638-3	ROD ASSY
BOEING	163U6001-1	HUBCAP ASSY
BOEING	163U6001-5	HUBCAP ASSY
COLLINS AERO	976J449-1	AC GENERATOR
COLLINS AERO	976J498-1	AC GENERATOR
COLLINS AERO	976J498-1R	AC GENERATOR
COLLINS AERO	976J498-2	AC GENERATOR
COLLINS AERO	976J598-1	AC GENERATOR
EATON	503-1-06680-003	AC GENERATOR
COLLINS AERO	976J063-2	AC GENERATOR
COLLINS AERO	976J119-6	AC GENERATOR
COLLINS AERO	976J119-8	AC GENERATOR
COLLINS AERO	976J119-11	AC GENERATOR
COLLINS AERO	976J119-12	AC GENERATOR
HONEYWELL	28B263-13A	AC GENERATOR
HONEYWELL	28B263-13B	AC GENERATOR
HONEYWELL	60B00010-17	AC GENERATOR
HONEYWELL	60B00010-24	AC GENERATOR
HONEYWELL	384022-4-2	AIR TURBINE ENGINE STARTER
HONEYWELL	384022-5-1	AIR TURBINE ENGINE STARTER
GOODRICH	238-2101-501	COWL ASSY INLET
SAFRAN	201399007	MLG ENHANCED HARNESS
SAFRAN	201399008	MLG ENHANCED HARNESS
SAFRAN	201400005	MLG ENHANCED HARNESS
SAFRAN	201400006	MLG ENHANCED HARNESS
SAFRAN	201399005	MLG ENHANCED HARNESS
SAFRAN	20139906	MLG ENHANCED HARNESS
SAFRAN	201400003	MLG ENHANCED HARNESS
SAFRAN	201400004	MLG ENHANCED HARNESS
SAFRAN	201399200	MLG ENHANCED HARNESS

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

SAFRAN	201399201	MLG ENHANCED HARNESS
SAFRAN	201400200	MLG ENHANCED HARNESS
SAFRAN	201400201	MLG ENHANCED HARNESS
SAFRAN	10-451301	MLG ENHANCED HARNESS
SAFRAN	10-451501	MLG ENHANCED HARNESS
SAFRAN	10-451501-000	MLG ENHANCED HARNESS
SAFRAN	10-451401-000	MLG ENHANCED HARNESS
SAFRAN	10-451401	MLG ENHANCED HARNESS
SAFRAN	10-451601-000	MLG ENHANCED HARNESS
SAFRAN	10-451601	MLG ENHANCED HARNESS
ULTRA ELECTRONICS	201134007	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201134008	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201134015	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201134016	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201158001	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201158002	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201158003	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201158004	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201159001	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201159002	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201159003	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201159004	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201159007	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201159008	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201168007	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201168008	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201168015	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201168014	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201168018	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201168019	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201168020	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201168021	HARNESS MAIN LANDING GEAR
ULTRA ELECTRONICS	201168022	HARNESS MAIN LANDING GEAR
SAFRAN	201401200	MLG AXLE HARNESS 1M & 2M
SAFRAN	201402200	MLG AXLE HARNESS 1M & 2M
SAFRAN	4305990050	PRESSURE SENSOR
BOEING	S283U006-7	PRESSURE SENSOR
HARCO LLC	HAD19669	EGT HARNESS AND JUNCTION BOX
HARCO LLC	HAD19824	EGT HARNESS AND JUNCTION BOX
HARCO LLC	25975-000	EGT HARNESS AND JUNCTION BOX

HARCO LLC	30040-000	EGT HARNESS AND JUNCTION BOX
HARCO LLC	30558-000	EGT HARNESS AND JUNCTION BOX
CFM	320-392-901-0	ELECTRICAL HARNESS J8
CFM	320-392-902-0	ELECTRICAL HARNESS J8
OTC AEROSPACE SYSTEMS	636W5704-505	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W5703-505	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W5701-505	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W5702-505	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W5707-503	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W5705-507	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W5708-503	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W5709-505	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W2952-503	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W2952-505	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W2954-501	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W2954-503	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W1605-503	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W3961-503	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W3960-503	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W2953-503	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W3952-501	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W3956-501	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W3950-501	ELECTRICAL HARNESS
OTC AEROSPACE SYSTEMS	636W3954-501	ELECTRICAL HARNESS
IAE	2A1380	EGT HARNESS AND JUNCTION BOX
IAE	2A1609	EGT HARNESS AND JUNCTION BOX
IAE	2A3580	EGT HARNESS AND JUNCTION BOX
IAE	2A4337	EGT HARNESS AND JUNCTION BOX
IAE	2A4524	EGT HARNESS AND JUNCTION BOX
BOMBARDIER	3505953-2	Air Turbine Starter
BOMBARDIER	3505953-1	Air Engine Starter
BOMBARDIER	3505953-4	Air Engine Starter
BOMBARDIER	540-1148-4	Nose Cowl Anti-Ice
BOMBARDIER	540-1148-5	Nose Cowl Anti-Ice
BOMBARDIER	3291339-2	Starter Control Valve
BOMBARDIER	3291339-3	Starter Control Valve
BOMBARDIER	2704554-2	Starter Motor
SELL GMBH	8101-28-0000B	SINGLE OVEN
SELL GMBH	8101-11-0000	SINGLE OVEN
ACME AEROSPACE	263BA101-2	47AH BATTERY ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

ACME AEROSPACE	263BC101-3	BATTERY CHARGER
ACME AEROSPACE	312BS101-1	ISDF -BATTERY CHARGER
BOEING	S282T005-1	ISDF-BATTERY CHARGER
CRANE ELDEC CORPORATION	8-930-03 (Boeing S282T003-3)	BATTERY CHARGER
CRANE ELDEC CORPORATION	4-254-02	BATTERY CHARGER
CRANE ELDEC CORPORATION	4-254-03	BATTERY CHARGER
CRANE ELDEC CORPORATION	4-254-04	BATTERY CHARGER
BOEING	S282T002-2	BATTERY CHARGER
BOEING	S282T002-4	BATTERY CHARGER
BOEING	S282T002-5	BATTERY CHARGER
BOEING	S282T002-6	BATTERY CHARGER
BOEING	S282T003-3	BATTERY CHARGER
CRANE ELDEC	8-930-03	BATTERY CHARGER
RADIANT POWER CORP	BPS7-2	BATTERY POWER SUPPLY
RADIANT POWER CORP	BPS7-3	BATTERY POWER SUPPLY
BOEING	S283T014-2	BATTERY POWER SUPPLY
BOEING	S283T014-3	BATTERY POWER SUPPLY
SAFT	2758	AC BATTERY
SAFT	4579	AC BATTERY
ELDEC	BA06-01	AC BATTERY
BOEING	S282T002-1	AC BATTERY
SAFT	018550-000	AC BATTERY
SAFT	539CH-1	AC BATTERY
SAFT	5319CH1	AC BATTERY
SAFT	024147-000	AC BATTERY
SAFT	1656-6	AC BATTERY
SAFT	023964-000	NICKEL CADMIUM BATTERY
SAFT	405CH	NICKEL CADMIUM BATTERY
SAFT	414361	NICKEL CADMIUM BATTERY
SAFT	025920-000	AC BATTERY
ELDEC	BA35-01	AC BATTERY
ELDEC	BA35-02	AC BATTERY
BOEING	S282T003-1	AC BATTERY
BOEING	S282T003-4	AC BATTERY
RADIANT POWER	2012-1	CHARGER
B/E AEROSPACE	416-1001-1	COFFEE MAKER
B/E AEROSPACE	416-1001-1P	COFFEE MAKER
B/E AEROSPACE	416-1001-3	COFFEE MAKER
B/E AEROSPACE	416-1001-5	COFFEE MAKER
B/E AEROSPACE	416-1001-7	COFFEE MAKER

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

B/E AEROSPACE	416-1001-9	COFFEE MAKER
B/E AEROSPACE	416-1001-13	COFFEE MAKER
B/E AEROSPACE	416-1001-17	COFFEE MAKER
B/E AEROSPACE	416-1001-19	COFFEE MAKER
B/E AEROSPACE	416-1001-21	COFFEE MAKER
B/E AEROSPACE	416-1001-23	COFFEE MAKER
B/E AEROSPACE	416-1001-25	COFFEE MAKER
B/E AEROSPACE	416-1001-29	COFFEE MAKER
B/E AEROSPACE	416-1001-41	COFFEE MAKER
B/E AEROSPACE	416-1001-45	COFFEE MAKER
B/E AEROSPACE	416-1001-47	COFFEE MAKER
B/E AEROSPACE	416-1001-49	COFFEE MAKER
B/E AEROSPACE	3510-0044-03	COFFEE MAKER
B/E AEROSPACE	3510-0044-13	COFFEE MAKER
B/E AEROSPACE	411-0001-135	COFFEE MAKER
B/E AEROSPACE	411-0001-137	COFFEE MAKER
B/E AEROSPACE	411-0001-139	COFFEE MAKER
B/E AEROSPACE	411-0001-139A	COFFEE MAKER
B/E AEROSPACE	411-0001-141	COFFEE MAKER
B/E AEROSPACE	411-0001-143	COFFEE MAKER
B/E AEROSPACE	411-0001-147	COFFEE MAKER
B/E AEROSPACE	467-0001-1	COFFEE MAKER
B/E AEROSPACE	467-0001-7	COFFEE MAKER
B/E AEROSPACE	3510-0053-01	COFFEE MAKER
B/E AEROSPACE	4383100-00-66-00	OVEN CONTROL MODULE
ZODIAC AEROSPACE	64753	COFFEE MAKER
ZODIAC AEROSPACE	64753-001-003	COFFEE MAKER
ZODIAC AEROSPACE	64753-001-005	COFFEE MAKER
GOODRICH	24E507040G01	WATER HEATER
GOODRICH	24E507040G02	WATER HEATER
GOODRICH	24E507040G03	WATER HEATER
GOODRICH	24E507040G04	WATER HEATER
GOODRICH	24E507040G05	WATER HEATER
GOODRICH	24E507040G06	WATER HEATER
BOEING	60B50064-2	WATER HEATER
BOEING	60B50064-3	WATER HEATER
BOEING	17B1B2416-1	WATER HEATER
BOEING	60B50064-4	WATER HEATER
BOEING	60B50064-5	WATER HEATER
BOEING	60B50064-8	WATER HEATER

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

AMETEK	33638	FAN ASSY BLOWER
ROCKWELL COLLINS	1167015-140	AUDIO CONTROL PANEL
ROCKWELL COLLINS	1167015-141	AUDIO CONTROL PANEL
ROCKWELL COLLINS	1167014-140	AUDIO MANAGEMENT UNIT
ROCKWELL COLLINS	1167014-141	AUDIO MANAGEMENT UNIT
ROCKWELL COLLINS	1167014-142	AUDIO MANAGEMENT UNIT
ROCKWELL COLLINS	1167014-143	AUDIO MANAGEMENT UNIT
ROCKWELL COLLINS	1167014-144	AUDIO MANAGEMENT UNIT
HONEYWELL	3283086-1	LOCK BRAKE
HONEYWELL	3283086-3	LOCK BRAKE
HONEYWELL	3283086-30	LOCK BRAKE
HONEYWELL	3283086-32	LOCK BRAKE
HONEYWELL	645172-1	VACUUM BLOWER
HONEYWELL	645172-2	VACUUM BLOWER
GENERAL ELECTRIC	1806M46P01	LOCK BRAKE
GENERAL ELECTRIC	1806M46P05	LOCK BRAKE
GENERAL ELECTRIC	1806M46P02	LOCK BRAKE
GENERAL ELECTRIC	1806M46P06	LOCK BRAKE
BAE SYSTEMS	233A3204-1	AC SYSTEM GEN APU CONTROL MODULE ASSY
BAE SYSTEMS	233A3204-2	AC SYSTEM GEN APU CONTROL MODULE ASSY
BAE SYSTEMS	233A3204-3	AC SYSTEM GEN APU CONTROL MODULE ASSY
BAE SYSTEMS	233A3204-3 MOD A	AC SYSTEM GEN APU CONTROL MODULE ASSY
BAE SYSTEMS	233A3204-4	AC SYSTEM GEN APU CONTROL MODULE ASSY
BAE SYSTEMS	233A3204-4 MOD A	AC SYSTEM GEN APU CONTROL MODULE ASSY
STRATOFLEX	G831-8-10A	HYDRAULIC FUSE
DE HAVILLAND	7SC0110	HYDRAULIC FUSE
ENVIROVAC, INC	7800052	FLUSH CONTROL UNIT
ENVIROVAC, INC	7800088	FLUSH CONTROL UNIT
BOEING	284U4029-1	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-10	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-11	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-12	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-13	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-14	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-15	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-2	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-3	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-301	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-302	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-303	OUTFLOW VALVE PANEL ASSEMBLY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	284U4029-304	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-4	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-5	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-6	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-8	OUTFLOW VALVE PANEL ASSEMBLY
BOEING	284U4029-9	OUTFLOW VALVE PANEL ASSEMBLY
UTC AEROSPACE	742868-1	RAM AIR VALVE ACTUATOR
UTC AEROSPACE	742868-2	RAM AIR VALVE ACTUATOR
UTC AEROSPACE	742868-3	RAM AIR VALVE ACTUATOR
UTC AEROSPACE	742868-4	RAM AIR VALVE ACTUATOR
UTC AEROSPACE	742868-5	RAM AIR VALVE ACTUATOR
GOODRICH	D717-01-001	EMERGENCY POWER SUPPLY
GOODRICH	D717-02-001	EMERGENCY POWER SUPPLY
BOEING	S283W603-01	EMERGENCY POWER SUPPLY
BOEING	S283W603-2	EMERGENCY POWER SUPPLY
BOEING	SB09270274-3	FLIGHT SPOILER ACTUATOR ASSY
BOEING	SB09270274-5	FLIGHT SPOILER ACTUATOR ASSY
BOEING	SB09270274-7	FLIGHT SPOILER ACTUATOR ASSY
BOEING	SB09270274-9	FLIGHT SPOILER ACTUATOR ASSY
SAFRAN	10-451301-000	MLG ENHANCED HARNESS
ULTRA ELECTRONICS	201158007	MLG HARNESS
ULTRA ELECTRONICS	201158008	MLG HARNESS
ULTRA ELECT	201399006	MLG HARNESS
BOEING	65B10919-15	DOOR ASSY AFT MLG
BOEING	65B10919-16	DOOR ASSY AFT MLG
BOEING	65B10919-19	DOOR ASSY AFT MLG
BOEING	65B10919-20	DOOR ASSY AFT MLG
BOEING	65B10919-21	DOOR ASSY AFT MLG
BOEING	65B10919-22	DOOR ASSY AFT MLG
BOEING	65B10919-27	DOOR ASSY AFT MLG
BOEING	65B10919-28	DOOR ASSY AFT MLG
BOEING	65B10919-29	DOOR ASSY AFT MLG
BOEING	65B10919-30	DOOR ASSY AFT MLG
BOEING	65B10919-31	DOOR ASSY AFT MLG
BOEING	65B10919-32	DOOR ASSY AFT MLG
BOEING	65B10919-33	DOOR ASSY AFT MLG
BOEING	65B10919-34	DOOR ASSY AFT MLG
BOEING	65B10919-35	DOOR ASSY AFT MLG
BOEING	65B10919-36	DOOR ASSY AFT MLG
BOEING	65B10919-39	DOOR ASSY AFT MLG

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	65B10919-40	DOOR ASSY AFT MLG
BOEING	65B10919-49	DOOR ASSY AFT MLG
BOEING	65B10919-50	DOOR ASSY AFT MLG
BOEING	65B10919-51	DOOR ASSY AFT MLG
BOEING	65B10919-52	DOOR ASSY AFT MLG
BOEING	65B10919-53	DOOR ASSY AFT MLG
BOEING	65B10919-54	DOOR ASSY AFT MLG
BOEING	65B10919-55	DOOR ASSY AFT MLG
BOEING	65B10919-56	DOOR ASSY AFT MLG
BOEING	65B10919-57	DOOR ASSY AFT MLG
BOEING	65B10919-58	DOOR ASSY AFT MLG
BOEING	65B10919-59	DOOR ASSY AFT MLG
BOEING	65B10919-60	DOOR ASSY AFT MLG
BOEING	65B13299-10	DOOR ASSY AFT MLG
BOEING	65B13299-9	DOOR ASSY AFT MLG
BOEING	3928137-5001	NOSEGEAR RETRACT CYLINDER ASSEMBLY
GOODRICH	XC02638CB20629	CONE, BEARING
GOODRICH	LM229110-20629	CUP, BEARING (OUTER)
GOODRICH	LM330410-20629	CUP, BEARING(INNER)
GOODRICH	LM330448-20629	CONE, BEARING INNER
GOODRICH	184-968	TORQUEPLATE
GOODRICH	184-968-1	TORQUEPLATE
GOODRICH	211-109	VALVEASSY, SHUTTLE
BOEING	5935812-503	MLG FITTING LINK STRUT
BOEING	5935812-504	MLG FITTING LINK STRUT
BOEING	5935812-505	MLG FITTING LINK STRUT
BOEING	5935812-506	MLG FITTING LINK STRUT
BOEING	5935812-507	MLG FITTING LINK STRUT
BOEING	5935812-508	MLG FITTING LINK STRUT
BOEING	5935812-509	MLG FITTING LINK STRUT
BOEING	5935812-510	MLG FITTING LINK STRUT
BOEING	5935812-511	MLG FITTING LINK STRUT
BOEING	5935812-512	MLG FITTING LINK STRUT
BOEING	5935812-513	MLG FITTING LINK STRUT
BOEING	5935812-514	MLG FITTING LINK STRUT
BOEING	5935812-515	MLG FITTING LINK STRUT
BOEING	5935812-516	MLG FITTING LINK STRUT
BOEING	5935812-517	MLG FITTING LINK STRUT
BOEING	5935812-518	MLG FITTING LINK STRUT
BOEING	5935812-519	MLG FITTING LINK STRUT
BOEING	5935812-520	MLG FITTING LINK STRUT

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	5935812-521	MLG FITTING LINK STRUT
BOEING	5935812-522	MLG FITTING LINK STRUT
BOEING	5935812-523	MLG FITTING LINK STRUT
BOEING	5935812-524	MLG FITTING LINK STRUT
BOEING	5935848-1	MLG FITTING LINK STRUT
BOEING	5935848-501	MLG FITTING LINK STRUT
BOEING	SB09570158-10	MLG FITTING LINK STRUT
BOEING	SB09570158-11	MLG FITTING LINK STRUT
BOEING	SB09570158-12	MLG FITTING LINK STRUT
BOEING	SB09570158-13	MLG FITTING LINK STRUT
BOEING	SB09570158-14	MLG FITTING LINK STRUT
BOEING	SB09570158-15	MLG FITTING LINK STRUT
BOEING	SB09570158-16	MLG FITTING LINK STRUT
BOEING	SB09570158-17	MLG FITTING LINK STRUT
BOEING	SB09570158-18	MLG FITTING LINK STRUT
BOEING	SB09570158-9	MLG FITTING LINK STRUT
GOODRICH	238-0101-501	COWL ASSY INLET
GOODRICH	238-0101-503	COWL ASSY INLET
GOODRICH	238-2102-501	COWL ASSY INLET
BOEING	314T1001-6	CORE COWL ASSY
BOEING	314T1001-7	CORE COWL ASSY
GOODRICH	224-2301-521	RH CORE COWL
GOODRICH	224-2301-527	RH CORE COWL
GOODRICH	224M4761-513	RH CORE COWL
GOODRICH	(224M4761-517)	RH CORE COWL
GOODRICH	(224M4761-521)	RH CORE COWL
GOODRICH	(224M4761-523)	RH CORE COWL
GOODRICH	(224M4761-525)	RH CORE COWL
GOODRICH	(224M4761-527)	RH CORE COWL
GOODRICH	(224M4761-529)	RH CORE COWL
GOODRICH	(224M4761-537)	RH CORE COWL
GOODRICH	(224M4761-539)	RH CORE COWL
GOODRICH	(224M4761-545)	RH CORE COWL
M NORCO	A2979-1	FAN COWL HOLD ROD
M NORCO	A2979-3	FAN COWL HOLD ROD
HARCO LLC	HAD19669	EGT HARNESS AND JUNCTION BOX
HARCO LLC	HAD19824	EGT HARNESS AND JUNCTION BOX
MRAS	1291M28G04	DOOR ASSY BLOCKER
MRAS	1291M28G05	DOOR ASSY BLOCKER
MRAS	1291M28G06	DOOR ASSY BLOCKER
MRAS	1291M28G08	DOOR ASSY BLOCKER
MRAS	1291M28G12	DOOR ASSY BLOCKER

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

MRAS	1291M28G13	DOOR ASSY BLOCKER
MRAS	1291M28G14	DOOR ASSY BLOCKER
MRAS	1291M28G15	DOOR ASSY BLOCKER
MRAS	1291M28G16	DOOR ASSY BLOCKER
MRAS	1291M28G17	DOOR ASSY BLOCKER
BOEING	315T4014	THRUST REVERSER
BOEING	315T4014-100SP	THRUST REVERSER
BOEING	315T4014-101SP	THRUST REVERSER
BOEING	315T4014-102SP	THRUST REVERSER
BOEING	315T4014-103SP	THRUST REVERSER
BOEING	315T4014-104SP	THRUST REVERSER
BOEING	315T4014-105SP	THRUST REVERSER
BOEING	315T4014-106SP	THRUST REVERSER
BOEING	315T4014-107SP	THRUST REVERSER
BOEING	315T4014-108SP	THRUST REVERSER
BOEING	315T4014-109SP	THRUST REVERSER
BOEING	315T4014-10SP	THRUST REVERSER
BOEING	315T4014-110SP	THRUST REVERSER
BOEING	315T4014-111SP	THRUST REVERSER
BOEING	315T4014-112SP	THRUST REVERSER
BOEING	315T4014-113SP	THRUST REVERSER
BOEING	315T4014-114SP	THRUST REVERSER
BOEING	315T4014-115SP	THRUST REVERSER
BOEING	315T4014-116SP	THRUST REVERSER
BOEING	315T4014-117SP	THRUST REVERSER
BOEING	315T4014-118SP	THRUST REVERSER
BOEING	315T4014-119SP	THRUST REVERSER
BOEING	315T4014-11SP	THRUST REVERSER
BOEING	315T4014-120SP	THRUST REVERSER
BOEING	315T4014-121SP	THRUST REVERSER
BOEING	315T4014-122SP	THRUST REVERSER
BOEING	315T4014-123SP	THRUST REVERSER
BOEING	315T4014-124SP	THRUST REVERSER
BOEING	315T4014-125SP	THRUST REVERSER
BOEING	315T4014-126SP	THRUST REVERSER
BOEING	315T4014-127SP	THRUST REVERSER
BOEING	315T4014-128SP	THRUST REVERSER
BOEING	315T4014-129SP	THRUST REVERSER
BOEING	315T4014-12SP	THRUST REVERSER
BOEING	315T4014-130SP	THRUST REVERSER
BOEING	315T4014-131SP	THRUST REVERSER
BOEING	315T4014-132SP	THRUST REVERSER

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	315T4014-133SP	THRUST REVERSER
BOEING	315T4014-134SP	THRUST REVERSER
BOEING	315T4014-135SP	THRUST REVERSER
BOEING	315T4014-136SP	THRUST REVERSER
BOEING	315T4014-137SP	THRUST REVERSER
BOEING	315T4014-138SP	THRUST REVERSER
BOEING	315T4014-139SP	THRUST REVERSER
BOEING	315T4014-140SP	THRUST REVERSER
BOEING	315T4014-141SP	THRUST REVERSER
BOEING	315T4014-142SP	THRUST REVERSER
BOEING	315T4014-143SP	THRUST REVERSER
BOEING	315T4014-144SP	THRUST REVERSER
BOEING	315T4014-145SP	THRUST REVERSER
BOEING	315T4014-146SP	THRUST REVERSER
BOEING	315T4014-147SP	THRUST REVERSER
BOEING	315T4014-148SP	THRUST REVERSER
BOEING	315T4014-149SP	THRUST REVERSER
BOEING	315T4014-150SP	THRUST REVERSER
BOEING	315T4014-151SP	THRUST REVERSER
BOEING	315T4014-152SP	THRUST REVERSER
BOEING	315T4014-153SP	THRUST REVERSER
BOEING	315T4014-154SP	THRUST REVERSER
BOEING	315T4014-155SP	THRUST REVERSER
BOEING	315T4014-156SP	THRUST REVERSER
BOEING	315T4014-157SP	THRUST REVERSER
BOEING	315T4014-158SP	THRUST REVERSER
BOEING	315T4014-159SP	THRUST REVERSER
BOEING	315T4014-160SP	THRUST REVERSER
BOEING	315T4014-161SP	THRUST REVERSER
BOEING	315T4014-162SP	THRUST REVERSER
BOEING	315T4014-163SP	THRUST REVERSER
BOEING	315T4014-164SP	THRUST REVERSER
BOEING	315T4014-165SP	THRUST REVERSER
BOEING	315T4014-166SP	THRUST REVERSER
BOEING	315T4014-167SP	THRUST REVERSER
BOEING	315T4014-168SP	THRUST REVERSER
BOEING	315T4014-169SP	THRUST REVERSER
BOEING	315T4014-170SP	THRUST REVERSER
BOEING	315T4014-171SP	THRUST REVERSER
BOEING	315T4014-172SP	THRUST REVERSER
BOEING	315T4014-173SP	THRUST REVERSER
BOEING	315T4014-174SP	THRUST REVERSER

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	315T4014-175SP	THRUST REVERSER
BOEING	315T4014-176SP	THRUST REVERSER
BOEING	315T4014-177SP	THRUST REVERSER
BOEING	315T4014-178SP	THRUST REVERSER
BOEING	315T4014-179SP	THRUST REVERSER
BOEING	315T4014-180SP	THRUST REVERSER
BOEING	315T4014-181SP	THRUST REVERSER
BOEING	315T4014-182SP	THRUST REVERSER
BOEING	315T4014-183SP	THRUST REVERSER
BOEING	315T4014-184SP	THRUST REVERSER
BOEING	315T4014-185SP	THRUST REVERSER
BOEING	315T4014-186SP	THRUST REVERSER
BOEING	315T4014-187SP	THRUST REVERSER
BOEING	315T4014-188SP	THRUST REVERSER
BOEING	315T4014-189SP	THRUST REVERSER
BOEING	315T4014-190SP	THRUST REVERSER
BOEING	315T4014-191SP	THRUST REVERSER
BOEING	315T4014-192SP	THRUST REVERSER
BOEING	315T4014-193SP	THRUST REVERSER
BOEING	315T4014-194SP	THRUST REVERSER
BOEING	315T4014-195SP	THRUST REVERSER
BOEING	315T4014-196SP	THRUST REVERSER
BOEING	315T4014-197SP	THRUST REVERSER
BOEING	315T4014-198SP	THRUST REVERSER
BOEING	315T4014-207SP	THRUST REVERSER
BOEING	315T4014-208SP	THRUST REVERSER
BOEING	315T4014-209SP	THRUST REVERSER
BOEING	315T4014-210SP	THRUST REVERSER
BOEING	315T4014-25SP	THRUST REVERSER
BOEING	315T4014-26SP	THRUST REVERSER
BOEING	315T4014-27SP	THRUST REVERSER
BOEING	315T4014-28SP	THRUST REVERSER
BOEING	315T4014-29SP	THRUST REVERSER
BOEING	315T4014-30SP	THRUST REVERSER
BOEING	315T4014-31SP	THRUST REVERSER
BOEING	315T4014-32SP	THRUST REVERSER
BOEING	315T4014-33SP	THRUST REVERSER
BOEING	315T4014-34SP	THRUST REVERSER
BOEING	315T4014-35SP	THRUST REVERSER
BOEING	315T4014-36SP	THRUST REVERSER
BOEING	315T4014-37SP	THRUST REVERSER
BOEING	315T4014-38SP	THRUST REVERSER

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	315T4014-39SP	THRUST REVERSER
BOEING	315T4014-40SP	THRUST REVERSER
BOEING	315T4014-41SP	THRUST REVERSER
BOEING	315T4014-42SP	THRUST REVERSER
BOEING	315T4014-47SP	THRUST REVERSER
BOEING	315T4014-48SP	THRUST REVERSER
BOEING	315T4014-49SP	THRUST REVERSER
BOEING	315T4014-50SP	THRUST REVERSER
BOEING	315T4014-51SP	THRUST REVERSER
BOEING	315T4014-52SP	THRUST REVERSER
BOEING	315T4014-53SP	THRUST REVERSER
BOEING	315T4014-54SP	THRUST REVERSER
BOEING	315T4014-55SP	THRUST REVERSER
BOEING	315T4014-56SP	THRUST REVERSER
BOEING	315T4014-57SP	THRUST REVERSER
BOEING	315T4014-58SP	THRUST REVERSER
BOEING	315T4014-59SP	THRUST REVERSER
BOEING	315T4014-60SP	THRUST REVERSER
BOEING	315T4014-61SP	THRUST REVERSER
BOEING	315T4014-62SP	THRUST REVERSER
BOEING	315T4014-63SP	THRUST REVERSER
BOEING	315T4014-64SP	THRUST REVERSER
BOEING	315T4014-65SP	THRUST REVERSER
BOEING	315T4014-66SP	THRUST REVERSER
BOEING	315T4014-67SP	THRUST REVERSER
BOEING	315T4014-68SP	THRUST REVERSER
BOEING	315T4014-69SP	THRUST REVERSER
BOEING	315T4014-70SP	THRUST REVERSER
BOEING	315T4014-71SP	THRUST REVERSER
BOEING	315T4014-72SP	THRUST REVERSER
BOEING	315T4014-73SP	THRUST REVERSER
BOEING	315T4014-74SP	THRUST REVERSER
BOEING	315T4014-75SP	THRUST REVERSER
BOEING	315T4014-76SP	THRUST REVERSER
BOEING	315T4014-77SP	THRUST REVERSER
BOEING	315T4014-78SP	THRUST REVERSER
BOEING	315T4014-79SP	THRUST REVERSER
BOEING	315T4014-80SP	THRUST REVERSER
BOEING	315T4014-81SP	THRUST REVERSER
BOEING	315T4014-82SP	THRUST REVERSER
BOEING	315T4014-83SP	THRUST REVERSER
BOEING	315T4014-84SP	THRUST REVERSER

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	315T4014-85SP	THRUST REVERSER
BOEING	315T4014-86SP	THRUST REVERSER
BOEING	315T4014-87SP	THRUST REVERSER
BOEING	315T4014-88SP	THRUST REVERSER
BOEING	315T4014-89SP	THRUST REVERSER
BOEING	315T4014-90SP	THRUST REVERSER
BOEING	315T4014-95SP	THRUST REVERSER
BOEING	315T4014-96SP	THRUST REVERSER
BOEING	315T4014-97SP	THRUST REVERSER
BOEING	315T4014-98SP	THRUST REVERSER
BOEING	315T4014-99SP	THRUST REVERSER
BOEING	315T4014-9SP	THRUST REVERSER
BOEING	315T4701-10SP	THRUST REVERSER
BOEING	315T4701-11SP	THRUST REVERSER
BOEING	315T4701-12SP	THRUST REVERSER
BOEING	315T4701-13SP	THRUST REVERSER
BOEING	315T4701-14SP	THRUST REVERSER
BOEING	315T4701-15SP	THRUST REVERSER
BOEING	315T4701-16SP	THRUST REVERSER
BOEING	315T4701-17SP	THRUST REVERSER
BOEING	315T4701-18SP	THRUST REVERSER
BOEING	315T4701-19SP	THRUST REVERSER
BOEING	315T4701-20SP	THRUST REVERSER
BOEING	315T4701-21SP	THRUST REVERSER
BOEING	315T4701-22SP	THRUST REVERSER
BOEING	315T4701-23SP	THRUST REVERSER
BOEING	315T4701-24SP	THRUST REVERSER
BOEING	315T4701-5SP	THRUST REVERSER
BOEING	315T4701-6SP	THRUST REVERSER
BOEING	315T4701-7SP	THRUST REVERSER
BOEING	315T4701-8SP	THRUST REVERSER
BOEING	315T4701-9SP	THRUST REVERSER
MRAS	D52B1000	THRUST R TRANS COWL
MRAS	D52B1000-23	THRUST R TRANS COWL
MRAS	491B1613000	THRUST R TRANS COWL
HONEYWELL	1477M56P02	BALLSCREW GEARBOX ASSY
HONEYWELL	3275538-2	BALLSCREW GEARBOX ASSY
HONEYWELL	3275538-3	BALLSCREW GEARBOX ASSY
MEGGITT	7101-01	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-02	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-03	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-04	FIRE/OVERHEAT DETECTOR

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

MEGGITT	7101-05	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-06	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-07	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-08	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-09	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-10	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-11	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-12	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-13	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-14	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-15	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-16	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-17	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-18	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-19	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-20	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-21	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-22	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-23	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-24	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-25	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-26	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-27	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-28	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-29	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-30	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-31	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-32	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-33	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-34	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-35	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-36	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-37	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-38	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-39	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-40	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-41	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-42	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-43	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-44	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-45	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-46	FIRE/OVERHEAT DETECTOR

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

MEGGITT	7101-47	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-48	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-49	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-50	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-51	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-52	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-53	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-54	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-55	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-56	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-57	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-58	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-60	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-61	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-62	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-63	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-64	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-65	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-66	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-67	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-68	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-69	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-70	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-71	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-72	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-73	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-77	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-78	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-80	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-81	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-129	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-135	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-136	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-137	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-138	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-148	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-149	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-155	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-236	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-237	FIRE/OVERHEAT DETECTOR
MEGGITT	7101-265	FIRE/OVERHEAT DETECTOR
WHITTAKER CONTROLS	340275	ROTARY SHUT-OFF VALVE MOTOR ACTUATED

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

WHITTAKER CONTROLS	340565	ROTARY SHUT-OFF VALVE MOTOR ACTUATED
BOEING	S271N501-2	ROTARY SHUT-OFF VALVE MOTOR ACTUATED
SHIMADZU CORP	732-13870-02	ACTUATOR ASSY AIR INTAKE AUXILIARY POWER SYSTEM
SHIMADZU CORP	732-13870-03	ACTUATOR ASSY AIR INTAKE AUXILIARY POWER SYSTEM
SHIMADZU CORP	732-13870-05	ACTUATOR ASSY AIR INTAKE AUXILIARY POWER SYSTEM
SHIMADZU CORP	732-13870-07	ACTUATOR ASSY AIR INTAKE AUXILIARY POWER SYSTEM
SHIMADZU CORP	732-13870-09	ACTUATOR ASSY AIR INTAKE AUXILIARY POWER SYSTEM
SHIMADZU CORP	732-13870-14	ACTUATOR ASSY AIR INTAKE AUXILIARY POWER SYSTEM
BOEING	S353T010-2	ACTUATOR ASSY AIR INTAKE AUXILIARY POWER SYSTEM
BOEING	S353T010-3	ACTUATOR ASSY AIR INTAKE AUXILIARY POWER SYSTEM
BOEING	S353T010-5	ACTUATOR ASSY AIR INTAKE AUXILIARY POWER SYSTEM
BOEING	S353T010-7	ACTUATOR ASSY AIR INTAKE AUXILIARY POWER SYSTEM
BOEING	S353T010-10	ACTUATOR ASSY AIR INTAKE AUXILIARY POWER SYSTEM
HONEYWELL	158935-1	OIL TEMPERATURE CONTROL VALVE
HONEYWELL	158935-2	OIL TEMPERATURE CONTROL VALVE
HONEYWELL	158935-3	OIL TEMPERATURE CONTROL VALVE
UTC AEROSPACE	775550-2	PNEUMATIC STARTER
UTC AEROSPACE	775550-3	PNEUMATIC STARTER
UTC AEROSPACE	775550-4	PNEUMATIC STARTER
UTC AEROSPACE	775550-5	PNEUMATIC STARTER
UTC AEROSPACE	775550-6	PNEUMATIC STARTER
UTC AEROSPACE	775550-7	PNEUMATIC STARTER
ARKWIN INDUSTRIES INC	1211350-001	COWL DOOR ACTUATOR
GENERAL ELECTRIC	9191M34P02	COWL DOOR ACTUATOR
MEGGITT	292-13	STROBE LIGHTS
HONEYWELL	3214960-3	PRESSURE REG AND S/O VALVE
ITT CORPORATION	642017-2	PRESSURE SWITCH
CRANE	140-071	WHEEL SPEED TRANSD ASSY
NEC AERO	301-3100	EMERGENCY POWER SUPPLY
COLLINS AERO	3033509	PULSE PROBE
THALES	49310-31	CABIN PRESSURE INDICATOR
TECHNOFAN	VST170	VALVE
INTERTECHNIQUE	784-717-2	OVERTEMP SWITCH
SAFT	416541	AIRCRAFT BATTERY
BOEING	S281W205-1	AIRCRAFT BATTERY
RUMBOLD	64790	COFFEE MAKER ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

LOCKHEED	R73-2004-42-00	CABLE TENSION REGULATORS
LOCKHEED	R73-2004-42-1A	CABLE TENSION REGULATORS
LOCKHEED	R73-2004-42-2A	CABLE TENSION REGULATORS
LOCKHEED	R73-2004-42-3A	CABLE TENSION REGULATORS
LOCKHEED	R73-2004-18-00	CABLE TENSION REGULATORS
PACIFIC SCIENTIFIC	R73-2008-42-00	CABLE TENSION REGULATORS
PACIFIC SCIENTIFIC	R73-2008-42-1A	CABLE TENSION REGULATORS
PACIFIC SCIENTIFIC	3C90007-101	CABLE TENSION REGULATORS
ADAMS RITE AEROSPACE	400300-1	MOTOR ACTUATED SHUT-OFF VALVE
ADAMS RITE AEROSPACE	400300-2	MOTOR ACTUATED SHUT-OFF VALVE
ADAMS RITE AEROSPACE	400300-3	MOTOR ACTUATED SHUT-OFF VALVE
ADAMS RITE AEROSPACE	400300-4	MOTOR ACTUATED SHUT-OFF VALVE
ADAMS RITE AEROSPACE	BAC 60B50341-1	MOTOR ACTUATED SHUT-OFF VALVE
ADAMS RITE AEROSPACE	BAC 60B50341-2	MOTOR ACTUATED SHUT-OFF VALVE
MARATHON	42060-001	NICKEL CADMIUM BATTERY
GULFSTREAM	25w191008-501	LINK ATTACHMENT FITTING
GULFSTREAM	25w311316-003	BUSHING LUB. FITTING
GOODRICH	22-843-5-1	2ND BREAK- TO-TIP DE- ICER, LH
GOODRICH	22-843-5-2	2ND BREAK- TO-TIP DE- ICER, LH
GULFSTREAM	CYLB-9676-1	3 DIAMETER ALUMINUM CHECK VALVE
GULFSTREAM	CYLB-50858-1	3 DIAMETER ALUMINUM CHECK VALVE
GULFSTREAM	DYLZ-6616-1	3.50 DIAMETER ALUMINUM BUTTERFLY VALVE AND ACTUATOR ASSEMBLY
GULFSTREAM	106354-1	AC POWER CONTROLLER - 115/230
GULFSTREAM	106354-2	AC POWER CONTROLLER - 115/230
HAMILTON	759970B	ACTUATOR
HAMILTON	759984B	ACTUATOR
GULFSTREAM	HP964500-9	ACTUATOR ASSEMBLY (NOSE WHEEL STEERING ASSEMBLY)
GULFSTREAM	HP964500-5	ACTUATOR ASSEMBLY (NOSE WHEEL STEERING ASSEMBLY)
GULFSTREAM	HP964500-3	ACTUATOR ASSEMBLY (NOSE WHEEL STEERING ASSEMBLY)
GULFSTREAM	HP964500-7	ACTUATOR ASSEMBLY (NOSE WHEEL STEERING ASSEMBLY)
GULFSTREAM	HP964500-10	ACTUATOR ASSEMBLY (NOSE WHEEL STEERING ASSEMBLY)
GULFSTREAM	HP964500-8	ACTUATOR ASSEMBLY (NOSE WHEEL STEERING ASSEMBLY)
GULFSTREAM	HP964500-1	ACTUATOR ASSEMBLY (NOSE WHEEL STEERING ASSEMBLY)
MOOG	CA49710-002	ACTUATOR ASSEMBLY GROUND
GULFSTREAM	83C83614	ACTUATOR ASSEMBLY HYD, NOSE LANDING GEAR
GULFSTREAM	7630A0001-01	ACTUATOR ASSEMBLY, LINEAR FLAP INBOARD
GULFSTREAM	7633A0001-01	ACTUATOR ASSEMBLY, LINEAR FLAP INBOARD
GULFSTREAM	7634A0001-01	ACTUATOR ASSEMBLY, LINEAR FLAP MIDWING
GULFSTREAM	7634A0001-02	ACTUATOR ASSEMBLY, LINEAR FLAP MIDWING
GULFSTREAM	7631A0001-01	ACTUATOR ASSEMBLY, LINEAR FLAP MIDWING
GULFSTREAM	7631B0001-02	ACTUATOR ASSEMBLY, LINEAR FLAP MIDWING
GULFSTREAM	7631B0001-01	ACTUATOR ASSEMBLY, LINEAR FLAP MIDWING

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

GULFSTREAM	CA66067-001	ACTUATOR GS
GULFSTREAM	CA48495-003	ACTUATOR MFS
GULFSTREAM	CA48495-004	ACTUATOR MFS, LH INBOARD
GULFSTREAM	25W176026-503	ACTUATOR NO.3 OUTBD HOUSING ASSEMBLY
GULFSTREAM	25W176026-504	ACTUATOR NO.3 OUTBD HOUSING ASSEMBLY
HONEYWELL	541972-11	ACTUATOR OUTLINE MECHANICAL LINEAR, INBOARD
HONEYWELL	541916-5	ACTUATOR OUTLINE, ELECTRO-MECHANICAL, ROTARY
HONEYWELL	541916-2	ACTUATOR OUTLINE, ELECTRO-MECHANICAL, ROTARY
GULFSTREAM	CA51121-001	ACTUATOR, AILERON TRIM
GULFSTREAM	CA51121-002	ACTUATOR, AILERON TRIM
GULFSTREAM	CA49494-002	ACTUATOR, ELEVATOR SERVO (DUAL), LH
GULFSTREAM	CA50298-002	ACTUATOR, ELEVATOR SERVO (DUAL), LH
GULFSTREAM	541972-1-1	ACTUATOR, INBOARD
EATON	1114D100-1	ACTUATOR, INBOARD FLAP
EATON	1117D100-1	ACTUATOR, INBOARD SLAT
HONEYWELL	2741624-1	ACTUATOR, LINEAR
HONEYWELL	2741624-2	ACTUATOR, LINEAR
GULFSTREAM	70721400-1	ACTUATOR, LINEAR
TEXTRON	4E3271-1	AIR COMPRESSOR
HONEYWELL	2205590-1	AIR CYCLE MACHINE
HONEYWELL	3506062-2	AIR TURBINE STARTER
HONEYWELL	3202782-1	COMPRESSOR BYPASS CHECK VALVE
HONEYWELL	3291954-2	FAN AIR VALVE
HONEYWELL	147240-1	FILTER
GULFSTREAM	3202754-1	GROUND CONNECTION CHECK VALVE
HONEYWELL	3291826-1	ISOLATION VALVE
HONEYWELL	3291284-1	LOW LIMIT VALVE
HONEYWELL	3215662-2	MANIFOLD PRESSURE REGULATOR VALVE
HONEYWELL	3202908-1	MID STAGE CHECK VALVE
HONEYWELL	3202776-1	RAM AIR CHECK VALVE
HONEYWELL	3215634-3	SERVO PRESSURE REGULATOR
HONEYWELL	4088468-902	ANTENNA ASSEMBLY
GULFSTREAM	LSM-500-444-69	BALLAST ASSY
GULFSTREAM	LSM-500-444 -149	BALLAST BRACKET
GULFSTREAM	LSM-501-103-5	BALLAST FINISH REMOVAL GUIDE
GULFSTREAM	LSM-500-444-65	CENTER TAXI LIGHT ASSY
GULFSTREAM	400-2195-01Z	COFFEE BREWER
MRAS	491B1200036-001	FLEXIBLE SHAFT ASSY
MRAS	491B1200036-002	FLEXIBLE SHAFT ASSY
AIRBUS	D2727000800-200	SPRING ROD
AIRBUS	D2727000800-400	SPRING ROD
COLLINS AERO	FE171-000	CABLE TENSION REGULATOR

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

www.ticaerospace.com

COLLINS AERO	FE197-000	CABLE TENSION REGULATOR
COLLINS AERO	90EGS31G	GENERATOR CONTROL UNIT
COLLINS AERO	90EGS33G	GENERATOR CONTROL UNIT
COLLINS AERO	767584F	GENERATOR CONTROL UNIT
COLLINS AERO	767584G	GENERATOR CONTROL UNIT
COLLINS AERO	767584H	GENERATOR CONTROL UNIT
COLLINS AERO	767584J	GENERATOR CONTROL UNIT
COLLINS AERO	767584K	GENERATOR CONTROL UNIT
COLLINS AERO	767584L	GENERATOR CONTROL UNIT
COLLINS AERO	767584M	GENERATOR CONTROL UNIT
COLLINS AERO	768510G	GENERATOR CONTROL UNIT
COLLINS AERO	768510H	GENERATOR CONTROL UNIT
SAFRAN	BA03603A	AC GENERATOR
SAFRAN	BA03604	AC GENERATOR
SAFRAN	D24157000	SELECTOR VALVE MANIFOLD ASSY
UTC AEROSPACE	811390-4	STARTER CONTROL VALVE
UTC AEROSPACE	C144875-1	STARTER CONTROL VALVE
HONEYWELL	3291466-1	SURGE CONTROL VALVE
HONEYWELL	3291466-2	SURGE CONTROL VALVE
COLLINS AERO	PS700-5	PNEUMATIC STARTER
COLLINS AERO	774860A1	PNEUMATIC STARTER
COLLINS AERO	774860A2	PNEUMATIC STARTER
COLLINS AERO	774860A3	PNEUMATIC STARTER
COLLINS AERO	774860A4	PNEUMATIC STARTER
COLLINS AERO	774860A5	PNEUMATIC STARTER
COLLINS AERO	774860A6	PNEUMATIC STARTER
COLLINS AERO	774860A7	PNEUMATIC STARTER
COLLINS AERO	774860A8	PNEUMATIC STARTER
COLLINS AERO	774860A9	PNEUMATIC STARTER
COLLINS AERO	774860A10	PNEUMATIC STARTER
COLLINS AERO	774860A11	PNEUMATIC STARTER
MOOG	B55968-1	SERVOACTUATOR ASSEMBLY
MOOG	B55968-2	SERVOACTUATOR ASSEMBLY
MOOG	B55968-003	SERVOACTUATOR ASSEMBLY
MOOG	B55968-004	SERVOACTUATOR ASSEMBLY
HONEYWELL	3886188-1	SERVOACTUATOR ASSEMBLY
HONEYWELL	3886188-2	SERVOACTUATOR ASSEMBLY
HONEYWELL	3886188-3	SERVOACTUATOR ASSEMBLY
HONEYWELL	3888217-2	STARTER
THALES	1303-1	STARTER
HONEYWELL	3888217-3	STARTER
THALES	1303-2	STARTER

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

HONEYWELL	3888217-4	STARTER
THALES	1303-3	STARTER
SAFRAN	C24736000	HYDRAULIC CONTROL UNIT
SAFRAN	C24736001	HYDRAULIC CONTROL UNIT
SAFRAN	C24736000-0-1	HYDRAULIC CONTROL UNIT
SAFRAN	C24736001-0-1	HYDRAULIC CONTROL UNIT
SAFRAN	C24736000-0-2	HYDRAULIC CONTROL UNIT
SAFRAN	C24736001-0-2	HYDRAULIC CONTROL UNIT
SAFRAN	C24736000-1	HYDRAULIC CONTROL UNIT
SAFRAN	C24736001-1	HYDRAULIC CONTROL UNIT
SAFRAN	C24736000-2	HYDRAULIC CONTROL UNIT
SAFRAN	C24736001-2	HYDRAULIC CONTROL UNIT
SAFRAN	C24736000-3	HYDRAULIC CONTROL UNIT
SAFRAN	C24736001-3	HYDRAULIC CONTROL UNIT
SAFRAN	C24736100-1	HYDRAULIC CONTROL UNIT
AIRBUS	D5288016500000	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500095	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500096	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500100	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500195	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500196	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500200	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500296	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500300	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500396	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500400	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500500	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500600	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288016500700	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288025000000	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288025000100	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288025000200	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	D5288025000300	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	DH602A1AAAAA	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	DH602A1AAAAAB	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	DH602A1AAAAAE	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	DH602A1AAAAAF	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	DH602A1AAAAAH	DOOR - MAIN LANDING GEAR, COMMON RAMP
AIRBUS	DH602A1AAAAAJ	DOOR - MAIN LANDING GEAR, COMMON RAMP
ZODIAC	S5411060900000	DUCT ASSY
ZODIAC	S5411060900011	DUCT ASSY
ZODIAC	S5411060900040	DUCT ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

ZODIAC	S5411265600000	DUCT ASSY
ZODIAC	S5411265600200	DUCT ASSY
ZODIAC	S5411265600400	DUCT ASSY
ZODIAC	S5411265600600	DUCT ASSY
ZODIAC	S5411265600700	DUCT ASSY
ZODIAC	S5411265600800	DUCT ASSY
ZODIAC	S5411265600900	DUCT ASSY
ZODIAC	S5411267000000	DUCT ASSY
ZODIAC	S5411267000200	DUCT ASSY
ZODIAC	S5411267000600	DUCT ASSY
ZODIAC	S5411267001000	DUCT ASSY
ZODIAC	S5411267001100	DUCT ASSY
ZODIAC	S5411267001200	DUCT ASSY
ZODIAC	S5411267001300	DUCT ASSY
AOA APPARATEBAU GAUTING	VD3810	MIXED FLOW FAN
AOA APPARATEBAU GAUTING	VD3900-03	RECIRCULATION FAN
AOA APPARATEBAU GAUTING	VD3920	EXTRACTION FAN
SAFT	4059	AIRCRAFT BATTERY
SAFT	4078-2	AIRCRAFT BATTERY
SAFT	40678-2	AIRCRAFT BATTERY
SAFT	1658-6	AIRCRAFT BATTERY
THALES AUXILEC SA	2432-30	GENERATOR CONTROL UNIT
THALES AUXILEC SA	2432-11	GENERATOR CONTROL UNIT
THALES AUXILEC SA	102-003-11	BUS POWER CONTROL UNIT
THALES AUXILEC SA	105-003-1	BUS POWER CONTROL UNIT
THALES AUXILEC SA	105-003-2	BUS POWER CONTROL UNIT
THALES AUXILEC SA	20032-2	AC ALTERNATOR
HONEYWELL COMMUTER DIVISION	7004544-412	SYMBOL GENERATOR UNIT
HONEYWELL COMMUTER DIVISION	7004544-712	SYMBOL GENERATOR UNIT
HONEYWELL COMMUTER DIVISION	7004544-713	SYMBOL GENERATOR UNIT
HONEYWELL COMMUTER DIVISION	7004544-714	SYMBOL GENERATOR UNIT
HONEYWELL COMMUTER DIVISION	7004544-715	SYMBOL GENERATOR UNIT
AIR PRECISION	292-12	STROBE LIGHT
AIR PRECISION	292-13	STROBE LIGHT
AIR PRECISION	292-22	STROBE LIGHT POWER SUPPLY UNIT
AIR PRECISION	292-23	STROBE LIGHT POWER SUPPLY UNIT
AIR PRECISION	292-24	STROBE
AIR PRECISION	292-25	STROBE LIGHT POWER SUPPLY
LOGIC SPA	APS30-1	ANTI COLLISION POWER SUPPLY
LOGIC SPA	APS32-1	ANTI COLLISION POWER SUPPLY
LOGIC SPA	APS40-1	ANTI COLLISION POWER SUPPLY
LOGIC SPA	R25-1-1	POWER SUPPLY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

LOGIC SPA	R25-1-1A	ANTICOLLISION POWER SUPPLY
LOGIC SPA	R25-1M2BR	ANTICOLLISION LIGHT
LOGIC SPA	R25-1M2BW	ANTICOLLISION LIGHT
LOGIC SPA	R25-1M2CW	ANTICOLLISION LIGHT
ZODIAC	4315542	RETRACTABLE LIGHT
ZODIAC	4191695	RETRACTABLE LIGHT
ZODIAC	4331772	RETRACTABLE LIGHT
ZODIAC AERO ELECTRIC	4213989	LANDING LIGHT
ZODIAC AERO ELECTRIC	4292915	LANDING LIGHT
ZODIAC AERO ELECTRIC	4319586	LANDING LIGHT
UTC AEROSPACE SYSTEMS	24E507009G01	LAVATORY WATER HEATER
UTC AEROSPACE SYSTEMS	24E507009G02	LAVATORY WATER HEATER
UTC AEROSPACE SYSTEMS	24E507009G03	LAVATORY WATER HEATER
BARRY CONTROLS AEROSPACE / HUTCHINSON	94830-09	APU ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94830-10	APU ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94830-11	APU ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94830-04	APU ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94830-05	APU ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94830-06	APU ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94423-05	BRACKET ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94423-15	BRACKET ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94796-01	ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94796-02	FORWARD ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94796-03	ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94796-04	ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94796-06	ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94796-07	ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94796-10	ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94796-13	ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94796-17	ISOLATOR ASSEMBLY
BARRY CONTROLS AEROSPACE / HUTCHINSON	96019-01	FORWARD VIBRATION ISOLATOR
BARRY CONTROLS AEROSPACE / HUTCHINSON	96019-02	AFT VIBRATION ISOLATOR
BARRY CONTROLS AEROSPACE / HUTCHINSON	96043-01	APU ISOLATOR ASSEMBLY, FWD, RH
BARRY CONTROLS AEROSPACE / HUTCHINSON	96043-02	APU ISOLATOR ASSEMBLY, AFT, RH
BARRY CONTROLS AEROSPACE / HUTCHINSON	96043-03	APU ISOLATOR ASSEMBLY, AFT, LH
BARRY CONTROLS AEROSPACE / HUTCHINSON	96043-04	APU ISOLATOR ASSEMBLY, FWD, RH
BARRY CONTROLS AEROSPACE / HUTCHINSON	96043-05	APU ISOLATOR ASSEMBLY, AFT, RH
BARRY CONTROLS AEROSPACE / HUTCHINSON	96043-06	APU ISOLATOR ASSEMBLY, AFT, LH
BARRY CONTROLS AEROSPACE / HUTCHINSON	96227-04	ISOLATOR ASSY, APU FWD LH
BARRY CONTROLS AEROSPACE / HUTCHINSON	96227-05	ISOLATOR ASSY, APU FWD RH
BARRY CONTROLS AEROSPACE / HUTCHINSON	96227-06	ISOLATOR ASSY, APU AFT
BARRY CONTROLS AEROSPACE / HUTCHINSON	95394-04	APU ISOLATOR ASSEMBLY, FWD,LEFT

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BARRY CONTROLS AEROSPACE / HUTCHINSON	95394-05	APU ISOLATOR ASSEMBLY, FWD, RIGHT
BARRY CONTROLS AEROSPACE / HUTCHINSON	95394-06	APU ISOLATOR ASSEMBLY, REAR
BARRY CONTROLS AEROSPACE / HUTCHINSON	9619103-01	ISOLATOR, APU, AFT, LH
BARRY CONTROLS AEROSPACE / HUTCHINSON	9619102-01	ISOLATOR ASSY, FWD
BARRY CONTROLS AEROSPACE / HUTCHINSON	9619101-02	ISOLATOR ASSY, FWD
BARRY CONTROLS AEROSPACE / HUTCHINSON	9619101-01	ISOLATOR ASSY, FWD
BARRY CONTROLS AEROSPACE / HUTCHINSON	9619117-00	ISOLATOR, APU, AFT RH
BARRY CONTROLS AEROSPACE / HUTCHINSON	96102-08	ISOLATOR, FWD
BARRY CONTROLS AEROSPACE / HUTCHINSON	96102-11	ISOLATOR, AFT
BARRY CONTROLS AEROSPACE / HUTCHINSON	96102-02	BRACKET, FWD
BARRY CONTROLS AEROSPACE / HUTCHINSON	96102-10	ISOLATOR, AFT
BARRY CONTROLS AEROSPACE / HUTCHINSON	95791-01	ISOLATOR ASSEMBLY, FWD, RIGHT
BARRY CONTROLS AEROSPACE / HUTCHINSON	95791-02	ISOLATOR ASSEMBLY, FWD LEFT
BARRY CONTROLS AEROSPACE / HUTCHINSON	95791-03	ISOLATOR ASSEMBLY, AFT
BARRY CONTROLS AEROSPACE / HUTCHINSON	94444-01	ISOLATOR ASSY, TOP, FWD
BARRY CONTROLS AEROSPACE / HUTCHINSON	94444-02	ISOLATOR ASSY, SIDE, FWD, RIGHT
BARRY CONTROLS AEROSPACE / HUTCHINSON	94444-08	ISOLATOR ASSY, SIDE, AFT
BARRY CONTROLS AEROSPACE / HUTCHINSON	94444-06	ISOLATOR ASSY, TORQUE TUBE
BARRY CONTROLS AEROSPACE / HUTCHINSON	94444-07	ISOLATOR ASSY, SIDE, FWD, LEFT
BARRY CONTROLS AEROSPACE / HUTCHINSON	94755-192	CANISTER ASSY
BARRY CONTROLS AEROSPACE / HUTCHINSON	94755-201	CANISTER ASSY
BARRY CONTROLS AEROSPACE / HUTCHINSON	95054-05	ISOLATOR ASSEMBLY, AFT
BARRY CONTROLS AEROSPACE / HUTCHINSON	95054-06	ISOLATOR ASSEMBLY, FWD
BARRY CONTROLS AEROSPACE / HUTCHINSON	95666-01	ISOLATOR ASSEMBLY, FORWARD, TOP
BARRY CONTROLS AEROSPACE / HUTCHINSON	95666-02	ISOLATOR ASSEMBLY, SIDE FORWARD RIGHT HAND
BARRY CONTROLS AEROSPACE / HUTCHINSON	95666-03	ISOLATOR ASSEMBLY, SIDE FORWARD LEFT HAND
BARRY CONTROLS AEROSPACE / HUTCHINSON	95666-04	ISOLATOR ASSEMBLY, SIDE AFT
BARRY CONTROLS AEROSPACE / HUTCHINSON	95666-05	ISOLATOR ASSEMBLY, TORQUE TUBE
ADAMS RITE AEROSPACE	AR4714-1	ELECTRICALLY OPERATED STRIKE ASSEMBLY
ADAMS RITE AEROSPACE	AR4714-3	ELECTRICALLY OPERATED STRIKE ASSEMBLY
ADAMS RITE AEROSPACE	AR4714-7	ELECTRICALLY OPERATED STRIKE ASSEMBLY
ADAMS RITE AEROSPACE	AR4714-9	ELECTRICALLY OPERATED STRIKE ASSEMBLY
ADAMS RITE AEROSPACE	AR4714-11	ELECTRICALLY OPERATED STRIKE ASSEMBLY
ADAMS RITE AEROSPACE	AR4714-201	ELECTRICALLY OPERATED STRIKE ASSEMBLY
ADAMS RITE AEROSPACE	AR4714-203	ELECTRICALLY OPERATED STRIKE ASSEMBLY
ZODIAC	S5517200000400	HORIZONTAL STABILIZER LEADING EDGE
ZODIAC	S5517200000500	HORIZONTAL STABILIZER LEADING EDGE
ZODIAC	S5517200000600	HORIZONTAL STABILIZER LEADING EDGE
ZODIAC	S5517200000651	HORIZONTAL STABILIZER LEADING EDGE
ZODIAC	S5517200000700	HORIZONTAL STABILIZER LEADING EDGE
ZODIAC	S5517200000751	HORIZONTAL STABILIZER LEADING EDGE
ZODIAC	S5517200000851	HORIZONTAL STABILIZER LEADING EDGE LH

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

ZODIAC	S551720000900	HORIZONTAL STABILIZER LEADING EDGE
ZODIAC	S551720000951	HORIZONTAL STABILIZER LEADING EDGE RH
ZODIAC	35S55172000-007	AL STABILIZER LEADING EDGE (MANUFACTURING NUMBER), RELEASE S551
ZODIAC	35S55172000-008	AL STABILIZER LEADING EDGE (MANUFACTURING NUMBER), RELEASE S551
ZODIAC	35S55172000-009	AL STABILIZER LEADING EDGE (MANUFACTURING NUMBER), RELEASE S551
ZODIAC	S0041012200000	LEADING EDGE
ZODIAC	S0041012200100	LEADING EDGE
ZODIAC	S0041012300000	LEADING EDGE
ZODIAC	S0041012300100	LEADING EDGE
ZODIAC	S5741003400200	LEADING EDGE
ZODIAC	S5741003800095	LEADING EDGE
ZODIAC	S5741003800195	LEADING EDGE
ZODIAC	S5741003800495	LEADING EDGE
ZODIAC	S5741003800595	LEADING EDGE
ZODIAC	S5741003800600	LEADING EDGE
ZODIAC	S5741003800695	LEADING EDGE
ZODIAC	S5741003800700	LEADING EDGE
ZODIAC	S5741003800795	LEADING EDGE
ZODIAC	S5741003800800	LEADING EDGE
ZODIAC	S5741003800895	LEADING EDGE
ZODIAC	S5741003800900	LEADING EDGE
ZODIAC	S5741003800995	LEADING EDGE
ZODIAC	S5741003801000	LEADING EDGE
ZODIAC	S5741003801100	LEADING EDGE
ZODIAC	S5741200600700	LEADING EDGE
ZODIAC	S5741200600710	LEADING EDGE
ZODIAC	S5741200600795	LEADING EDGE
ZODIAC	S5741201600010	LEADING EDGE
ZODIAC	S5741201600095	LEADING EDGE
ZODIAC	S5741201600100	LEADING EDGE
ZODIAC	S5741201600110	LEADING EDGE
ZODIAC	S5741201600195	LEADING EDGE
ZODIAC	S5741201600210	LEADING EDGE
ZODIAC	S5741201600310	LEADING EDGE
ZODIAC	S5741201600401	LEADING EDGE
ZODIAC	S5741201600501	LEADING EDGE
ZODIAC	S5741201600601	LEADING EDGE
ZODIAC	S5741201600701	LEADING EDGE
ZODIAC	S5741211400000	LEADING EDGE
ZODIAC	S5741211400095	LEADING EDGE
ZODIAC	S5741211400200	LEADING EDGE
ZODIAC	S5741211400210	LEADING EDGE

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

ZODIAC	S5741211400310	LEADING EDGE
ZODIAC	S5741211700010	LEADING EDGE
ZODIAC	S5741211700110	LEADING EDGE
ZODIAC	S5741211700210	LEADING EDGE
ZODIAC	S5741211700310	LEADING EDGE
ZODIAC	S5741504600000	LEADING EDGE
ZODIAC	S5741504600100	LEADING EDGE
ZODIAC	S5741504600195	LEADING EDGE
ZODIAC	S5741504600200	LEADING EDGE
ZODIAC	S5741504600300	LEADING EDGE
ZODIAC	S5741504800000	LEADING EDGE
ZODIAC	S5741504800100	LEADING EDGE
ZODIAC	S5741504800200	LEADING EDGE
ZODIAC	S5741504800300	LEADING EDGE
HONEYWELL INTERNATIONAL INC	2204400-4	TURBINE COOLING
HONEYWELL INTERNATIONAL INC	2204400-5	TURBINE COOLING
HONEYWELL INTERNATIONAL INC	2205120-1	TURBINE COOLING
HONEYWELL INTERNATIONAL INC	1600D00	TURBINE COOLING
HONEYWELL INTERNATIONAL INC	2205120-1SR1	TURBINE COOLING
HONEYWELL INTERNATIONAL INC	2205120-3	TURBINE COOLING
HONEYWELL INTERNATIONAL INC	1600D00-002	TURBINE COOLING
HONEYWELL INTERNATIONAL INC	2205120-3SR1	TURBINE COOLING
HONEYWELL INTERNATIONAL INC	2205120-4	TURBINE COOLING
HONEYWELL INTERNATIONAL INC	1600D00-003	TURBINE COOLING
HONEYWELL INTERNATIONAL INC	2205120-4SR1	TURBINE COOLING
HONEYWELL AEROSPACE	3500800-1	AIR TURBINE STARTER
HONEYWELL AEROSPACE	3500800-2	AIR TURBINE STARTER
HONEYWELL AEROSPACE	3500800-3	AIR TURBINE STARTER
HONEYWELL AEROSPACE	3500800-4	AIR TURBINE STARTER
SAFRAN	8236-2	TRIM ACTUATOR
SAFRAN	8236-3	TRIM ACTUATOR
HONEYWELL AEROSPACE	4083935-901	IN/OUT AILERON DEFLECT. ACTUATOR
HONEYWELL AEROSPACE	MPC 2A4204A	IN/OUT AILERON DEFLECT. ACTUATOR
HONEYWELL AEROSPACE	4083935-902	IN/OUT AILERON DEFLECT. ACTUATOR
HONEYWELL AEROSPACE	MPC 2A4205A	IN/OUT AILERON DEFLECT. ACTUATOR
HONEYWELL AEROSPACE	4083935-903	IN/OUT AILERON DEFLECT. ACTUATOR
HONEYWELL AEROSPACE	MPC 2A4204B	IN/OUT AILERON DEFLECT. ACTUATOR
HONEYWELL AEROSPACE	4083935-904	IN/OUT AILERON DEFLECT. ACTUATOR
HONEYWELL AEROSPACE	MPC 2A4205B	IN/OUT AILERON DEFLECT. ACTUATOR
BOEING	5914066-5551	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5553	RUDDER PWR CTRL & ACT ASSY
BOEING	5914066-5555	RUDDER PWR CTRL & ACT ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	5914066-5557	RUDDER PWR CTRL & ACT ASSY
MOOG	3180131-1	SPHERICAL ACCUMULATOR ASSEMBLY
MOOG	3180131-2	SPHERICAL ACCUMULATOR ASSEMBLY
MOOG	3180131-3	SPHERICAL ACCUMULATOR ASSEMBLY
ADAMS RITE AEROSPACE	AR9042-3	WATER HEATER ASSEMBLY
ADAMS RITE AEROSPACE	AR9042-11	WATER HEATER ASSEMBLY
38-15-11	28823-0	POTABLE WATER SYSTEM
38-15-11	28823-1	POTABLE WATER SYSTEM
38-15-11	28823-2	POTABLE WATER SYSTEM
38-15-11	28823-5	POTABLE WATER SYSTEM
38-30-01	60B50341-1	MOTOR ACTUATED SHUT-OFF VALVE ASSEMBLY
38-30-01	60B50341-2	MOTOR ACTUATED SHUT-OFF VALVE ASSEMBLY
71-11-16	224-2101-579	INLET COWL
72-22-02	1288M99G06	ACOUSTIC LINER SEGMENTS
72-22-02	1288M99G07	ACOUSTIC LINER SEGMENTS
72-22-02	1288M99G08	ACOUSTIC LINER SEGMENTS
72-22-02	1288M99G09	ACOUSTIC LINER SEGMENTS
72-22-02	1288M99G10	ACOUSTIC LINER SEGMENTS
72-22-02	1288M99G11	ACOUSTIC LINER SEGMENTS
72-22-02	1288M99G12	ACOUSTIC LINER SEGMENTS
72-22-02	1288M99G13	ACOUSTIC LINER SEGMENTS
72-22-02	1288M99G14	ACOUSTIC LINER SEGMENTS
72-22-02	1288M99G15	ACOUSTIC LINER SEGMENTS
72-22-02	1288M99G16	ACOUSTIC LINER SEGMENTS
72-22-02	1340M58G04	ACOUSTIC LINER SEGMENTS
72-22-02	1340M58G05	ACOUSTIC LINER SEGMENTS
72-22-02	1375M37G01	ACOUSTIC LINER SEGMENTS
72-22-02	1375M37G02	ACOUSTIC LINER SEGMENTS
72-22-02	1753M39G01	ACOUSTIC LINER SEGMENTS
72-22-02	1753M39G03	ACOUSTIC LINER SEGMENTS
72-23-11	9046M49G03	BEARING STATIONARY AIR/OIL SEAL
72-23-11	9046M49G04	BEARING STATIONARY AIR/OIL SEAL
72-23-11	9046M49G08	BEARING STATIONARY AIR/OIL SEAL
73-22-78	320-296-801-0	ELECTRICAL HARNESS J12
78-30-00	1291M28G SERIES	DOOR ASSY BLOCKER
78-30-00	683L137G SERIES	THRUST REVERSER
78-31-20	121248-2	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121248-3	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121248-4	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121248-5	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121248-6	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121248-8	FLEXIBLE SHAFT ASSEMBLY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

www.ticaerospace.com

78-31-20	121282-2	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-3	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-8	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-9	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-10	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-11	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-14	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-15	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-17	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-18	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-23	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-24	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-25	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-26	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-29	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121282-30	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121378-3	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121380-3	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121552-2	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121554-2	FLEXIBLE SHAFT ASSEMBLY
78-31-20	121750-1	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9039M90P02	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9039M90P03	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9039M90P04	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9039M90P05	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9126M65P01	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9126M65P02	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9041 M47P01	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9041M67P02	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9280M82P01	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9280M82P02	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9280M82P03	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9280M82P04	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9041M47P03	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9041M67P04	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9041M47P01	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9066M16P04	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9066M30P04	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9118M60P02	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9118M59P02	FLEXIBLE SHAFT ASSEMBLY
78-31-20	9303M69P01	FLEXIBLE SHAFT ASSEMBLY
78-31-24	315A2535-1	BATWING BLOCKER DOOR ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

78-31-24	315A2535-2	BATWING BLOCKER DOOR ASSY
78-31-24	315A2535-3	BATWING BLOCKER DOOR ASSY
78-31-24	315A2535-4	BATWING BLOCKER DOOR ASSY
78-31-24	315A2510-3	BLOCKER DOOR ASSY
78-31-24	315A2510-4	BLOCKER DOOR ASSY
78-31-24	315A2510-5	BLOCKER DOOR ASSY
78-31-24	315A2510-6	BLOCKER DOOR ASSY
78-31-24	315A2510-7	BLOCKER DOOR ASSY
78-31-24	315A2510-8	BLOCKER DOOR ASSY
78-31-24	315A2510-9	BLOCKER DOOR ASSY
78-31-24	315A2510-10	BLOCKER DOOR ASSY
78-31-24	315A2512-3	BLOCKER DOOR ASSY
78-31-24	315A2512-4	BLOCKER DOOR ASSY
78-31-24	315A2512-5	BLOCKER DOOR ASSY
78-31-24	315A2512-6	BLOCKER DOOR ASSY
78-31-24	315A2512-7	BLOCKER DOOR ASSY
78-31-24	315A2512-8	BLOCKER DOOR ASSY
78-31-24	315A2512-9	BLOCKER DOOR ASSY
78-31-24	315A2512-10	BLOCKER DOOR ASSY
78-31-24	315A2512-11	BLOCKER DOOR ASSY
78-31-24	315A2512-12	BLOCKER DOOR ASSY
78-31-24	315A2512-13	BLOCKER DOOR ASSY
78-31-24	315A2512-14	BLOCKER DOOR ASSY
78-31-24	315A2512-15	BLOCKER DOOR ASSY
78-31-24	315A2512-16	BLOCKER DOOR ASSY
78-31-24	315A2512-17	BLOCKER DOOR ASSY
78-31-24	315A2512-18	BLOCKER DOOR ASSY
78-31-24	315A2533-1	BLOCKER DOOR ASSY
78-31-24	315A2530-11	COMMON DIAPHRAGM HINGE FITTING ASSY
78-31-24	315A2530-12	COMMON DIAPHRAGM HINGE FITTING ASSY
78-31-24	315A2530-17	COMMON DIAPHRAGM HINGE FITTING ASSY
78-31-24	315A2530-18	COMMON DIAPHRAGM HINGE FITTING ASSY
78-31-24	315A2530-21	COMMON DIAPHRAGM HINGE FITTING ASSY
78-31-24	315A2530-22	COMMON DIAPHRAGM HINGE FITTING ASSY
78-31-24	315A2514-1	CONTROL LINK ASSY
78-31-24	315A2534-2	DOOR
78-31-24	315A2536-3	DOOR
78-31-24	315A2536-4	DOOR
78-31-24	315A2536-7	DOOR
78-31-24	315A2536-8	DOOR
78-31-24	315A2534-1	DOOR ASSY
78-31-24	315A2536-1	DOOR ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

78-31-24	315A2536-2	DOOR ASSY
78-31-24	315A2536-5	DOOR ASSY
78-31-24	315A2536-6	DOOR ASSY
78-31-24	315A2523-1	DRAG FITTING ASSY
78-31-24	315A2523-2	DRAG FITTING ASSY
78-31-24	315A2514-2	FITTING
78-31-24	315A2519-2	FITTING
78-31-24	315A2519-5	FITTING
78-31-24	315A2519-1	FITTING ASSY
78-31-24	315A2519-4	FITTING ASSY
78-31-24	315A2519-6	FITTING ASSY
78-31-24	315A2519-7	FITTING ASSY
78-31-24	315A2500-10	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-11	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-12	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-13	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-14	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-15	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-16	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-17	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-18	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-19	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-20	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-21	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-22	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-23	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-24	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-25	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-26	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-27	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-28	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-29	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-3	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-30	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-31	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-32	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-4	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-5	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-6	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2500-9	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-10	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-11	THRUST REVERSER SLEEVE ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

78-31-24	315A2501-12	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-13	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-14	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-15	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-16	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-17	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-18	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-19	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-20	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-21	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-23	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-24	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-25	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-26	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-3	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-4	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-5	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-6	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2501-9	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2505-3	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2505-4	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2505-5	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2505-6	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2505-7	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2505-8	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-1	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-10	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-11	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-12	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-13	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-14	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-15	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-16	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-2	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-21	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-22	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-23	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-24	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-3	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-4	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-5	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-6	THRUST REVERSER SLEEVE ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

www.ticaerospace.com

78-31-24	315A2509-7	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-8	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2509-9	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-1	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-10	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-11	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-12	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-13	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-14	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-15	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-16	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-17	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-18	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-19	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-2	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-20	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-3	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-4	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-5	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-6	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-7	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-8	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2521-9	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2565-1	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2565-2	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2565-3	THRUST REVERSER SLEEVE ASSY
78-31-24	315A2565-4	THRUST REVERSER SLEEVE ASSY
78-32-00	491B1200026-009	ROD ASSY-OUT STRUT
78-32-00	533A00000-SERIES	THRUST REVERSER
78-32-00	683L1SERIES	THRUST REVERSER
78-32-00	683L2SERIES	THRUST REVERSER
78-32-31	491B1613000SERIES	THRUST R TRANS COWL
78-32-32	D52B1000SERIES	THRUST R TRANS COWL
LIEBHERR	9069A1015-01	ACTUATOR
LIEBHERR	9069A1018-01	ACTUATOR
LIEBHERR	9069A1001-01	ACTUATOR
LIEBHERR	9069A1002-01	ACTUATOR
LIEBHERR	9069A1003-01	ACTUATOR
LIEBHERR	9069B1018-01	ACTUATOR
UNKNOWN	106-1-1100-03	ACTUATOR APU
UNKNOWN	106-1-1100-02	ACTUATOR APU ASSY
UNKNOWN	A08000	ACTUATOR ASSEMBLY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	S5411052500000	AIR INTAKE
UNKNOWN	S5411052500002	AIR INTAKE
UNKNOWN	S5411275900001	AIR INTAKE
UNKNOWN	S5411275900200	AIR INTAKE
UNKNOWN	S5411275900201	AIR INTAKE
UNKNOWN	S5411275900300	AIR INTAKE
UNKNOWN	S5411275900401	AIR INTAKE
UNKNOWN	S5411275900601	AIR INTAKE
UNKNOWN	S5411275900801	AIR INTAKE
UNKNOWN	S5411275901001	AIR INTAKE
UNKNOWN	S5411561900000	AIR INTAKE
UNKNOWN	S5411561900100	AIR INTAKE
UNKNOWN	285CH	AIRCRAFT BATTERY
UNKNOWN	416526	AIRCRAFT BATTERY
UNKNOWN	416487	AIRCRAFT BATTERY
UNKNOWN	447CH8	AIRCRAFT BATTERY
UNKNOWN	AH2542BA01	ATTENDANT HANDSET
UNKNOWN	AH2542BA02	ATTENDANT HANDSET
UNKNOWN	AH2542BA03	ATTENDANT HANDSET
UNKNOWN	AH2542CA01	ATTENDANT HANDSET
UNKNOWN	AH2542CA02	ATTENDANT HANDSET
UNKNOWN	AH2542CB01	ATTENDANT HANDSET
UNKNOWN	945-11	BUS POWER CONTROL UNIT
UNKNOWN	945-12	BUS POWER CONTROL UNIT
UNKNOWN	V2T127B	BUTTERFLY AIR VALVE
UNKNOWN	V2T127D	BUTTERFLY AIR VALVE
UNKNOWN	V2T152B	BUTTERFLY AIR VALVE
UNKNOWN	V2T152BAMDTA	BUTTERFLY AIR VALVE
UNKNOWN	V2T152D	BUTTERFLY AIR VALVE
UNKNOWN	1312B0000-01	BYPASS VALVE
UNKNOWN	1312B0000-02	BYPASS VALVE
UNKNOWN	3958A0000-01	BYPASS VALVE
UNKNOWN	814759-1	Brush Block Assembly
UNKNOWN	814759-2	Brush Block Assembly
UNKNOWN	817537-1	Brush Block Assembly
UNKNOWN	817537-2	Brush Block Assembly
UNKNOWN	820539-1	Brush Block Assembly
UNKNOWN	820546-1	Brush Block Assembly
UNKNOWN	820513-1	Brush Block Assembly
UNKNOWN	TAAI1-404000-03	CAPTAIN ARMREST ASSIST ASSY
UNKNOWN	TAAI4-404000-01	CAPTAIN ARMREST ASSIST ASSY
UNKNOWN	2290B010000	CHECK VALVE

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	2290B020000	CHECK VALVE
UNKNOWN	2293A010000	CHECK VALVE
UNKNOWN	2293B010000	CHECK VALVE
UNKNOWN	2293B020000	CHECK VALVE
UNKNOWN	41173C010000	CHECK VALVE
UNKNOWN	756A0000-05	CONDENSER
UNKNOWN	756A0000-06	CONDENSER
UNKNOWN	756B0000-01	CONDENSEUR
UNKNOWN	756B0000-07	CONDENSEUR
UNKNOWN	1600D000-004	COOLING TURBINE
UNKNOWN	3289704-1	SHUTOFF VALVE
UNKNOWN	HTE200002	SINGLE MOTOR ACTUATOR
UNKNOWN	HTE200002-1	SINGLE MOTOR ACTUATOR
UNKNOWN	VFT210B00	SKIN AIR VALVE
UNKNOWN	VFT300B00	SKIN AIR VALVE
UNKNOWN	2214805-2	TEMPERATURE CONTROL VALVE
UNKNOWN	2214805-3	TEMPERATURE CONTROL VALVE
UNKNOWN	2214805-4	TEMPERATURE CONTROL VALVE
UNKNOWN	2214805-5	TEMPERATURE CONTROL VALVE
UNKNOWN	3214958-1	TEMPERATURE CONTROL VALVE
UNKNOWN	3214958-2	TEMPERATURE CONTROL VALVE
UNKNOWN	5618C000-003	TEMPERATURE CONTROL VALVE
UNKNOWN	1394A0000-01	TEMPERATURE CONTROL VALVE
UNKNOWN	957A0000-02	TEMPERATURE CONTROL VALVE
UNKNOWN	957B0000-01	TEMPERATURE CONTROL VALVE
UNKNOWN	8236-3AE	TRIM ACTUATOR (8236-3 AMDT AE)
UNKNOWN	1320A0000-01	TRIM AIR VALVE
UNKNOWN	1320A0000-02	TRIM AIR VALVE
UNKNOWN	HTE190001-1	TWIN MOTOR ACTUATOR
UNKNOWN	HTE190001-2	TWIN MOTOR ACTUATOR
UNKNOWN	AE1502U01	UNIVERSAL BRAKE COOLING FAN
UNKNOWN	AE1502U02	UNIVERSAL BRAKE COOLING FAN
UNKNOWN	14330-350	VACUUM GENERATOR
UNKNOWN	14330-375	VACUUM GENERATOR ASSEMBLY
UNKNOWN	J540AI4-100	VACUUM GENERATOR ASSEMBLY
UNKNOWN	979990-1	VALVE CONTROL TEMPERATURE
UNKNOWN	B47CA1090	VALVE DE ICING SHUTOFF
UNKNOWN	B14GF1502	VALVE DE ICING PRESS REG
LIEBHERR AEROSPACE	1303A0000-01	VALVE-FLOW CONTROL
LIEBHERR AEROSPACE	1303A0000-02	VALVE-FLOW CONTROL
LIEBHERR AEROSPACE	1303A0000-03	VALVE-FLOW CONTROL
LIEBHERR AEROSPACE	1303A0000-04	VALVE-FLOW CONTROL

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	3217-100	RAIN REPELENT
UNKNOWN	3217-200	RAIN REPELENT
UNKNOWN	976A0000-02	RAM AIR OUTLET ACTUATOR
UNKNOWN	VD3901-00	RECIRCULATION FAN
UNKNOWN	3214558-1	REGULATING VALVE
UNKNOWN	3214558-2	REGULATING VALVE
UNKNOWN	3214560-1	REGULATING VALVE
UNKNOWN	3214560-2	REGULATING VALVE
UNKNOWN	3214560-3	REGULATING VALVE
UNKNOWN	3214960-1	REGULATING VALVE
UNKNOWN	3214960-2	REGULATING VALVE
UNKNOWN	3214960-3	REGULATING VALVE
UNKNOWN	B14GF1503	REGULATOR AND SHUT-OFF VALVE
UNKNOWN	RMC1002	REGULATOR ASSEMBLY
UNKNOWN	RMC1005	REGULATOR ASSEMBLY
UNKNOWN	RMC1005-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1006	REGULATOR ASSEMBLY
UNKNOWN	RMC1006-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1007	REGULATOR ASSEMBLY
UNKNOWN	RMC1007-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1007-2	REGULATOR ASSEMBLY
UNKNOWN	RMC1007-3	REGULATOR ASSEMBLY
UNKNOWN	RMC1007-4	REGULATOR ASSEMBLY
UNKNOWN	RMC1007-5	REGULATOR ASSEMBLY
UNKNOWN	RMC1007-6	REGULATOR ASSEMBLY
UNKNOWN	RMC1007-7	REGULATOR ASSEMBLY
UNKNOWN	RMC1008	REGULATOR ASSEMBLY
UNKNOWN	RMC1008-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1008-2	REGULATOR ASSEMBLY
UNKNOWN	RMC1011-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1012	REGULATOR ASSEMBLY
UNKNOWN	RMC1013	REGULATOR ASSEMBLY
UNKNOWN	RMC1016	REGULATOR ASSEMBLY
UNKNOWN	RMC1016-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1016-2	REGULATOR ASSEMBLY
UNKNOWN	RMC1018	REGULATOR ASSEMBLY
UNKNOWN	RMC1018-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1018-2	REGULATOR ASSEMBLY
UNKNOWN	RMC1018-3	REGULATOR ASSEMBLY
UNKNOWN	RMC1018-5	REGULATOR ASSEMBLY
UNKNOWN	RMC1019	REGULATOR ASSEMBLY
UNKNOWN	RMC1019-1	REGULATOR ASSEMBLY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	RMC1019-2	REGULATOR ASSEMBLY
UNKNOWN	RMC1019-3	REGULATOR ASSEMBLY
UNKNOWN	RMC1020	REGULATOR ASSEMBLY
UNKNOWN	RMC1020-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1022	REGULATOR ASSEMBLY
UNKNOWN	RMC1022-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1022-2	REGULATOR ASSEMBLY
UNKNOWN	RMC1022-3	REGULATOR ASSEMBLY
UNKNOWN	RMC1022-4	REGULATOR ASSEMBLY
UNKNOWN	RMC1022-5	REGULATOR ASSEMBLY
UNKNOWN	RMC1022-6	REGULATOR ASSEMBLY
UNKNOWN	RMC1022-7	REGULATOR ASSEMBLY
UNKNOWN	RMC1022-8	REGULATOR ASSEMBLY
UNKNOWN	RMC1027	REGULATOR ASSEMBLY
UNKNOWN	RMC1027-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1027-3	REGULATOR ASSEMBLY
UNKNOWN	RMC1029	REGULATOR ASSEMBLY
UNKNOWN	RMC1029-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1030	REGULATOR ASSEMBLY
UNKNOWN	RMC1035	REGULATOR ASSEMBLY
UNKNOWN	RMC1036-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1052	REGULATOR ASSEMBLY
UNKNOWN	RMC1105	REGULATOR ASSEMBLY
UNKNOWN	RMC1106	REGULATOR ASSEMBLY
UNKNOWN	RMC1106-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1106-2	REGULATOR ASSEMBLY
UNKNOWN	RMC1107-2	REGULATOR ASSEMBLY
UNKNOWN	RMC1108-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1116	REGULATOR ASSEMBLY
UNKNOWN	RMC1116-2	REGULATOR ASSEMBLY
UNKNOWN	RMC1118-3	REGULATOR ASSEMBLY
UNKNOWN	RMC1119-3	REGULATOR ASSEMBLY
UNKNOWN	RMC1122	REGULATOR ASSEMBLY
UNKNOWN	RMC1122-3	REGULATOR ASSEMBLY
UNKNOWN	RMC1122-8	REGULATOR ASSEMBLY
UNKNOWN	RMC1127	REGULATOR ASSEMBLY
UNKNOWN	RMC1127-3	REGULATOR ASSEMBLY
UNKNOWN	RMC1129	REGULATOR ASSEMBLY
UNKNOWN	RMC1129-1	REGULATOR ASSEMBLY
UNKNOWN	RMC1130	REGULATOR ASSEMBLY
UNKNOWN	RMC1135	REGULATOR ASSEMBLY
UNKNOWN	RMC1135-1	REGULATOR ASSEMBLY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	RMC1137	REGULATOR ASSEMBLY
UNKNOWN	RMC2002	REGULATOR ASSEMBLY
UNKNOWN	RMC2005	REGULATOR ASSEMBLY
UNKNOWN	RMC2005-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2006	REGULATOR ASSEMBLY
UNKNOWN	RMC2006-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2007	REGULATOR ASSEMBLY
UNKNOWN	RMC2007-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2007-2	REGULATOR ASSEMBLY
UNKNOWN	RMC2007-3	REGULATOR ASSEMBLY
UNKNOWN	RMC2007-4	REGULATOR ASSEMBLY
UNKNOWN	RMC2007-5	REGULATOR ASSEMBLY
UNKNOWN	RMC2007-6	REGULATOR ASSEMBLY
UNKNOWN	RMC2007-7	REGULATOR ASSEMBLY
UNKNOWN	RMC2008	REGULATOR ASSEMBLY
UNKNOWN	RMC2008-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2008-2	REGULATOR ASSEMBLY
UNKNOWN	RMC2011-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2012	REGULATOR ASSEMBLY
UNKNOWN	RMC2016	REGULATOR ASSEMBLY
UNKNOWN	RMC2016-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2016-2	REGULATOR ASSEMBLY
UNKNOWN	RMC2018	REGULATOR ASSEMBLY
UNKNOWN	RMC2018-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2018-2	REGULATOR ASSEMBLY
UNKNOWN	RMC2018-3	REGULATOR ASSEMBLY
UNKNOWN	RMC2018-5	REGULATOR ASSEMBLY
UNKNOWN	RMC2018-6	REGULATOR ASSEMBLY
UNKNOWN	RMC2018-7	REGULATOR ASSEMBLY
UNKNOWN	RMC2019	REGULATOR ASSEMBLY
UNKNOWN	RMC2019-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2019-2	REGULATOR ASSEMBLY
UNKNOWN	RMC2019-3	REGULATOR ASSEMBLY
UNKNOWN	RMC2020	REGULATOR ASSEMBLY
UNKNOWN	RMC2020-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2022	REGULATOR ASSEMBLY
UNKNOWN	RMC2022R	REGULATOR ASSEMBLY
UNKNOWN	RMC2022-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2022-2	REGULATOR ASSEMBLY
UNKNOWN	RMC2022-3	REGULATOR ASSEMBLY
UNKNOWN	RMC2022-4	REGULATOR ASSEMBLY
UNKNOWN	RMC2022-5	REGULATOR ASSEMBLY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	RMC2022-6	REGULATOR ASSEMBLY
UNKNOWN	RMC2022-7	REGULATOR ASSEMBLY
UNKNOWN	RMC2022-8	REGULATOR ASSEMBLY
UNKNOWN	RMC2022-9	REGULATOR ASSEMBLY
UNKNOWN	RMC2026	REGULATOR ASSEMBLY
UNKNOWN	RMC2026-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2027	REGULATOR ASSEMBLY
UNKNOWN	RMC2027-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2027-3	REGULATOR ASSEMBLY
UNKNOWN	RMC2029	REGULATOR ASSEMBLY
UNKNOWN	RMC2029-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2030	REGULATOR ASSEMBLY
UNKNOWN	RMC2035	REGULATOR ASSEMBLY
UNKNOWN	RMC2036-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2036-2	REGULATOR ASSEMBLY
UNKNOWN	RMC2036-2R	REGULATOR ASSEMBLY
UNKNOWN	RMC2036-3R	REGULATOR ASSEMBLY
UNKNOWN	RMC2052	REGULATOR ASSEMBLY
UNKNOWN	RMC2053	REGULATOR ASSEMBLY
UNKNOWN	RMC2105	REGULATOR ASSEMBLY
UNKNOWN	RMC2106	REGULATOR ASSEMBLY
UNKNOWN	RMC2106-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2106-2	REGULATOR ASSEMBLY
UNKNOWN	RMC2106-3	REGULATOR ASSEMBLY
UNKNOWN	RMC2107-2	REGULATOR ASSEMBLY
UNKNOWN	RMC2108-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2116	REGULATOR ASSEMBLY
UNKNOWN	RMC2116R	REGULATOR ASSEMBLY
UNKNOWN	RMC2116-2	REGULATOR ASSEMBLY
UNKNOWN	RMC2118-3	REGULATOR ASSEMBLY
UNKNOWN	RMC2119-3	REGULATOR ASSEMBLY
UNKNOWN	RMC2122	REGULATOR ASSEMBLY
UNKNOWN	RMC2122-3	REGULATOR ASSEMBLY
UNKNOWN	RMC2122-3R	REGULATOR ASSEMBLY
UNKNOWN	RMC2122-8	REGULATOR ASSEMBLY
UNKNOWN	RMC2122-8R	REGULATOR ASSEMBLY
UNKNOWN	RMC2126-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2126-2	REGULATOR ASSEMBLY
UNKNOWN	RMC2127	REGULATOR ASSEMBLY
UNKNOWN	RMC2127-3	REGULATOR ASSEMBLY
UNKNOWN	RMC2127-3R	REGULATOR ASSEMBLY
UNKNOWN	RMC2129	REGULATOR ASSEMBLY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	RMC2129-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2130	REGULATOR ASSEMBLY
UNKNOWN	RMC2131	REGULATOR ASSEMBLY
UNKNOWN	RMC2135	REGULATOR ASSEMBLY
UNKNOWN	RMC2135-1	REGULATOR ASSEMBLY
UNKNOWN	RMC2131-2R	REGULATOR ASSEMBLY
UNKNOWN	RMC2136-2R	REGULATOR ASSEMBLY
UNKNOWN	RMC2137	REGULATOR ASSEMBLY
UNKNOWN	RMC2137R	REGULATOR ASSEMBLY
UNKNOWN	RMC2140	REGULATOR ASSEMBLY
UNKNOWN	RMC2140R	REGULATOR ASSEMBLY
UNKNOWN	RMC2147	REGULATOR ASSEMBLY
UNKNOWN	RMC2148R	REGULATOR ASSEMBLY
UNKNOWN	RMC3002	REGULATOR ASSEMBLY
UNKNOWN	RMC3005	REGULATOR ASSEMBLY
UNKNOWN	RMC3005-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3006	REGULATOR ASSEMBLY
UNKNOWN	RMC3006-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3007	REGULATOR ASSEMBLY
UNKNOWN	RMC3007-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3007-2	REGULATOR ASSEMBLY
UNKNOWN	RMC3007-3	REGULATOR ASSEMBLY
UNKNOWN	RMC3007-4	REGULATOR ASSEMBLY
UNKNOWN	RMC3007-5	REGULATOR ASSEMBLY
UNKNOWN	RMC3007-6	REGULATOR ASSEMBLY
UNKNOWN	RMC3007-7	REGULATOR ASSEMBLY
UNKNOWN	RMC3008	REGULATOR ASSEMBLY
UNKNOWN	RMC3008-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3008-2	REGULATOR ASSEMBLY
UNKNOWN	RMC3011-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3012	REGULATOR ASSEMBLY
UNKNOWN	RMC3016	REGULATOR ASSEMBLY
UNKNOWN	RMC3016-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3016-2	REGULATOR ASSEMBLY
UNKNOWN	RMC3018	REGULATOR ASSEMBLY
UNKNOWN	RMC3018-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3018-2	REGULATOR ASSEMBLY
UNKNOWN	RMC3018-2R	REGULATOR ASSEMBLY
UNKNOWN	RMC3018-3	REGULATOR ASSEMBLY
UNKNOWN	RMC3018-5	REGULATOR ASSEMBLY
UNKNOWN	RMC3018-6	REGULATOR ASSEMBLY
UNKNOWN	RMC3018-7	REGULATOR ASSEMBLY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	RMC3019	REGULATOR ASSEMBLY
UNKNOWN	RMC3019-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3019-2	REGULATOR ASSEMBLY
UNKNOWN	RMC3019-3	REGULATOR ASSEMBLY
UNKNOWN	RMC3020	REGULATOR ASSEMBLY
UNKNOWN	RMC3020-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3022	REGULATOR ASSEMBLY
UNKNOWN	RMC3022R	REGULATOR ASSEMBLY
UNKNOWN	RMC3022-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3022-2	REGULATOR ASSEMBLY
UNKNOWN	RMC3022-3	REGULATOR ASSEMBLY
UNKNOWN	RMC3022-4	REGULATOR ASSEMBLY
UNKNOWN	RMC3022-5	REGULATOR ASSEMBLY
UNKNOWN	RMC3022-6	REGULATOR ASSEMBLY
UNKNOWN	RMC3022-7	REGULATOR ASSEMBLY
UNKNOWN	RMC3022-8	REGULATOR ASSEMBLY
UNKNOWN	RMC3022-9	REGULATOR ASSEMBLY
UNKNOWN	RMC3026	REGULATOR ASSEMBLY
UNKNOWN	RMC3026-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3027	REGULATOR ASSEMBLY
UNKNOWN	RMC3027-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3027-3	REGULATOR ASSEMBLY
UNKNOWN	RMC3029	REGULATOR ASSEMBLY
UNKNOWN	RMC3029-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3030	REGULATOR ASSEMBLY
UNKNOWN	RMC3035	REGULATOR ASSEMBLY
UNKNOWN	RMC3036-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3036-2	REGULATOR ASSEMBLY
UNKNOWN	RMC3036-2R	REGULATOR ASSEMBLY
UNKNOWN	RMC3036-3R	REGULATOR ASSEMBLY
UNKNOWN	RMC3052	REGULATOR ASSEMBLY
UNKNOWN	RMC3053	REGULATOR ASSEMBLY
UNKNOWN	RMC3105	REGULATOR ASSEMBLY
UNKNOWN	RMC3106	REGULATOR ASSEMBLY
UNKNOWN	RMC3106-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3106-2	REGULATOR ASSEMBLY
UNKNOWN	RMC3106-3	REGULATOR ASSEMBLY
UNKNOWN	RMC3107-2	REGULATOR ASSEMBLY
UNKNOWN	RMC3108-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3116	REGULATOR ASSEMBLY
UNKNOWN	RMC3116R	REGULATOR ASSEMBLY
UNKNOWN	RMC3116-2	REGULATOR ASSEMBLY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	RMC3118-3	REGULATOR ASSEMBLY
UNKNOWN	RMC3119-3	REGULATOR ASSEMBLY
UNKNOWN	RMC3122	REGULATOR ASSEMBLY
UNKNOWN	RMC3122-3	REGULATOR ASSEMBLY
UNKNOWN	RMC3122-3R	REGULATOR ASSEMBLY
UNKNOWN	RMC3122-8	REGULATOR ASSEMBLY
UNKNOWN	RMC3122-8R	REGULATOR ASSEMBLY
UNKNOWN	RMC3126-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3126-2	REGULATOR ASSEMBLY
UNKNOWN	RMC3127	REGULATOR ASSEMBLY
UNKNOWN	RMC3127-3	REGULATOR ASSEMBLY
UNKNOWN	RMC3127-3R	REGULATOR ASSEMBLY
UNKNOWN	RMC3129	REGULATOR ASSEMBLY
UNKNOWN	RMC3129-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3130	REGULATOR ASSEMBLY
UNKNOWN	RMC3131	REGULATOR ASSEMBLY
UNKNOWN	RMC3135	REGULATOR ASSEMBLY
UNKNOWN	RMC3135-1	REGULATOR ASSEMBLY
UNKNOWN	RMC3131-2R	REGULATOR ASSEMBLY
UNKNOWN	RMC3136-2R	REGULATOR ASSEMBLY
UNKNOWN	RMC3140	REGULATOR ASSEMBLY
UNKNOWN	RMC3140R	REGULATOR ASSEMBLY
UNKNOWN	RMC3147	REGULATOR ASSEMBLY
UNKNOWN	RMC3148R	REGULATOR ASSEMBLY
UNKNOWN	755A0000-04	REHEATER
UNKNOWN	755B0000-02	REHEATER
UNKNOWN	755C0000-01	REHEATER
UNKNOWN	755D0000-01	REHEATER
UNKNOWN	7005819-202	DISPLAY CONTROLLER
UNKNOWN	7005819-506	DISPLAY CONTROLLER
UNKNOWN	B03AA1020	DUAL DISTRIBUTOR VALVE
UNKNOWN	B03AA1031	DUAL DISTRIBUTOR VALVE
UNKNOWN	B03AA1040	DUAL DISTRIBUTOR VALVE
UNKNOWN	B03AA1060	DUAL DISTRIBUTOR VALVE
UNKNOWN	35-0L0-1001-04	ECAM CONTROL PANEL
UNKNOWN	35-0L0-1002-05	ECAM CONTROL PANEL
UNKNOWN	35-0L0-1003-06	ECAM CONTROL PANEL
UNKNOWN	3289706-1	ECU ISOLATION VALVE
UNKNOWN	3290196-1	ECU ISOLATION VALVE
UNKNOWN	3290196-2	ECU ISOLATION VALVE
UNKNOWN	APE5100	ELECTRONIC CLOCK
UNKNOWN	APE5100-1	ELECTRONIC CLOCK

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	EVTA1925B	EXHAUST FAN
UNKNOWN	EVTA1926BA	EXHAUST FAN
UNKNOWN	EVTA1926CA	EXHAUST FAN
UNKNOWN	EVTA1926DA	EXHAUST FAN
UNKNOWN	EVTA1926DC	EXHAUST FAN
UNKNOWN	AE1012A00	FAN
UNKNOWN	AE1012B00	FAN
UNKNOWN	EVAC523G2	FAN
UNKNOWN	335TS08Y00	FIRE PANEL ENG/APU
UNKNOWN	335TS08Y01	FIRE PANEL ENG/APU
UNKNOWN	964A0000-03	FLOW CONTROL VALVE
UNKNOWN	964A0000-04	FLOW CONTROL VALVE
UNKNOWN	964A0000-05	FLOW CONTROL VALVE
UNKNOWN	964A0000-06	FLOW CONTROL VALVE
UNKNOWN	EVCTA325A	GASPER FAN
UNKNOWN	8260-121	GENERATOR STARTER DC
UNKNOWN	8260-123	GENERATOR STARTER DC
UNKNOWN	8260-124	GENERATOR STARTER DC
UNKNOWN	EVAC2423DC	GROUND COOLING FAN
UNKNOWN	EVAC2423EC	GROUND COOLING FAN
UNKNOWN	EVAC2423FC	GROUND COOLING FAN
UNKNOWN	EVAC2423FD	GROUND COOLING FAN
UNKNOWN	EVAC2423H	GROUND COOLING FAN
UNKNOWN	7003975-901	GUIDANCE CONTROLLER
UNKNOWN	CT2542AG01	HANDSET
UNKNOWN	CT2542AG02	HANDSET
UNKNOWN	CT2776	HANDSET
UNKNOWN	N40-1B10100-101	HANDSET WITH SUPPORT BRACKET
UNKNOWN	N40-1B20212-102	HANDSET WITH SUPPORT BRACKET
UNKNOWN	N40-1B20203-102	HANDSET WITH SUPPORT BRACKET
UNKNOWN	N40-1B20215-102	HANDSET WITH SUPPORT BRACKET
UNKNOWN	N40-1B20203-000	HANDSET WITH SUPPORT BRACKET
UNKNOWN	N40-1B30204-102	HANDSET WITH SUPPORT BRACKET
UNKNOWN	N40-1B40204-102	HANDSET WITH SUPPORT BRACKET
UNKNOWN	N40-1B10126-101	HANDSET WITH SUPPORT BRACKET
UNKNOWN	N40-1B20261-102	HANDSET WITH SUPPORT BRACKET
UNKNOWN	7005973-912	HEADING COURSE CONTROLLER
UNKNOWN	1046GT2102AY	HEADSET
UNKNOWN	1046GT2102F	HEADSET
UNKNOWN	1046GT2102G	HEADSET
UNKNOWN	2340356-1	HEAT EXCHANGER
UNKNOWN	2340356-3SR1	HEAT EXCHANGER

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	FE159-5-002	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE159-5-004	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE159-5-005	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE159-5-005B	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE159-5-006	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE159-5-006A	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE159-5-006B	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE159-5-007	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE159-5-007A	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE159-5-007B	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE159-5-008	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE201-5-002	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE201-6-001	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE201-6-001A	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE201-6-001B	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE201-6-002	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE201-6-002A	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE201-6-002B	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	FE201-6-003	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	3036107	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	3036795	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	3037250	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	3037470A	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	3037785	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	3120890-01	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	3120890-02	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	3037783	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	3038240	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	3120891-01	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	3120891-02	HYDROMECHANICAL BRAKE ASSEMBLY
UNKNOWN	0871DP5-1	ICE DETECTOR
UNKNOWN	215TS07Y	L/G CONTROL LEVER
UNKNOWN	215TS07Y00	L/G CONTROL LEVER
UNKNOWN	215TS07Y01	L/G CONTROL LEVER
UNKNOWN	S0041040000000	LEADING EDGE
UNKNOWN	S5741004600095	LEADING EDGE
UNKNOWN	S5741004600195	LEADING EDGE
UNKNOWN	S5741004600200	LEADING EDGE
UNKNOWN	S5741004600295	LEADING EDGE
UNKNOWN	S5741004600395	LEADING EDGE
UNKNOWN	S5741004600400	LEADING EDGE
UNKNOWN	S5741004600500	LEADING EDGE

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	S5741004600600	LEADING EDGE
UNKNOWN	S5741004600695	LEADING EDGE
UNKNOWN	S5741004600700	LEADING EDGE
UNKNOWN	S5741004600795	LEADING EDGE
UNKNOWN	S5741004601200	LEADING EDGE
UNKNOWN	S5741004601295	LEADING EDGE
UNKNOWN	S5741004601395	LEADING EDGE
UNKNOWN	S5741004601400	LEADING EDGE
UNKNOWN	S5741004601495	LEADING EDGE
UNKNOWN	S5741004601500	LEADING EDGE
UNKNOWN	S5741004601595	LEADING EDGE
UNKNOWN	S5741004601800	LEADING EDGE
UNKNOWN	S5741004601895	LEADING EDGE
UNKNOWN	S5741004601900	LEADING EDGE
UNKNOWN	S5741004601995	LEADING EDGE
UNKNOWN	S5741200600000	LEADING EDGE
UNKNOWN	S5741200600095	LEADING EDGE
UNKNOWN	S5741200600100	LEADING EDGE
UNKNOWN	S5741200600195	LEADING EDGE
UNKNOWN	S5741200600200	LEADING EDGE
UNKNOWN	S5741200600295	LEADING EDGE
UNKNOWN	S5741200600300	LEADING EDGE
UNKNOWN	S5741200600395	LEADING EDGE
UNKNOWN	S5741200600400	LEADING EDGE
UNKNOWN	S5741200600495	LEADING EDGE
UNKNOWN	S5741200600500	LEADING EDGE
UNKNOWN	S5741200600595	LEADING EDGE
UNKNOWN	S5741200600600	LEADING EDGE
UNKNOWN	S0041040100000	LEADING EDGE
UNKNOWN	S0041040200000	LEADING EDGE
UNKNOWN	S0041040200100	LEADING EDGE
UNKNOWN	S0041045000100	LEADING EDGE
UNKNOWN	S5741004200000	LEADING EDGE
UNKNOWN	S5741004200095	LEADING EDGE
UNKNOWN	S5741004200100	LEADING EDGE
UNKNOWN	S5741004200195	LEADING EDGE
UNKNOWN	S5741004200200	LEADING EDGE
UNKNOWN	S5741004200295	LEADING EDGE
UNKNOWN	S5741004200300	LEADING EDGE
UNKNOWN	S5741004200395	LEADING EDGE
UNKNOWN	S5741004200600	LEADING EDGE
UNKNOWN	S5741004200700	LEADING EDGE

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	S5741004200800	LEADING EDGE
UNKNOWN	S5741004200900	LEADING EDGE
UNKNOWN	S5741004201000	LEADING EDGE
UNKNOWN	S5741004201100	LEADING EDGE
UNKNOWN	S5741004201200	LEADING EDGE
UNKNOWN	S5741004201300	LEADING EDGE
UNKNOWN	S5741004201400	LEADING EDGE
UNKNOWN	S5741004201500	LEADING EDGE
UNKNOWN	S5741005000095	LEADING EDGE
UNKNOWN	S5741005600095	LEADING EDGE
UNKNOWN	S5741005600195	LEADING EDGE
UNKNOWN	S5741005600495	LEADING EDGE
UNKNOWN	S5741009300095	LEADING EDGE
UNKNOWN	S5741009300295	LEADING EDGE
UNKNOWN	S5741211400100	LEADING EDGE
UNKNOWN	S5741211400195	LEADING EDGE
UNKNOWN	S5741212100000	LEADING EDGE
UNKNOWN	S5741212100095	LEADING EDGE
UNKNOWN	S5741212100096	LEADING EDGE
UNKNOWN	S5741212100100	LEADING EDGE
UNKNOWN	S5741212100195	LEADING EDGE
UNKNOWN	S5741212100196	LEADING EDGE
UNKNOWN	S5741212100300	LEADING EDGE
UNKNOWN	S5741212100400	LEADING EDGE
UNKNOWN	S5741212100496	LEADING EDGE
UNKNOWN	S5741212100500	LEADING EDGE
UNKNOWN	S5741212100596	LEADING EDGE
UNKNOWN	S5741212100600	LEADING EDGE
UNKNOWN	S5741212100610	LEADING EDGE
UNKNOWN	S5741212100700	LEADING EDGE
UNKNOWN	S5741212100710	LEADING EDGE
UNKNOWN	S5741212100800	LEADING EDGE
UNKNOWN	S5741212100810	LEADING EDGE
UNKNOWN	S5741212100910	LEADING EDGE
UNKNOWN	S5741212101001	LEADING EDGE
UNKNOWN	S5741212101101	LEADING EDGE
UNKNOWN	S5741212500200	LEADING EDGE
UNKNOWN	S5741212500295	LEADING EDGE
UNKNOWN	S5741212500296	LEADING EDGE
UNKNOWN	S5741212500300	LEADING EDGE
UNKNOWN	S5741212500395	LEADING EDGE
UNKNOWN	S5741212500396	LEADING EDGE

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

UNKNOWN	S5741212500500	LEADING EDGE
UNKNOWN	S5741212500600	LEADING EDGE
UNKNOWN	S5741212500696	LEADING EDGE
UNKNOWN	S5741212500700	LEADING EDGE
UNKNOWN	S5741212500796	LEADING EDGE
UNKNOWN	S5741212500800	LEADING EDGE
UNKNOWN	S5741212500810	LEADING EDGE
UNKNOWN	S5741212500900	LEADING EDGE
UNKNOWN	S5741212500910	LEADING EDGE
UNKNOWN	S5741212501000	LEADING EDGE
UNKNOWN	S5741212501010	LEADING EDGE
UNKNOWN	S5741212501100	LEADING EDGE
UNKNOWN	S5741212501110	LEADING EDGE
UNKNOWN	S5741212700700	LEADING EDGE
UNKNOWN	S5741217000095	LEADING EDGE
UNKNOWN	S5741505600100	LEADING EDGE
UNKNOWN	S5741505600300	LEADING EDGE
UNKNOWN	S5741505600500	LEADING EDGE
UNKNOWN	S5741509300000	LEADING EDGE
UNKNOWN	S5741509300200	LEADING EDGE
UNKNOWN	S5741509300400	LEADING EDGE
UNKNOWN	S5741208000001	LEADING EDGE ASSY
UNKNOWN	S5741208000200	LEADING EDGE ASSY
UNKNOWN	S5741208000400	LEADING EDGE ASSY
UNKNOWN	S5741209000101	LEADING EDGE INTERMEDIATE
UNKNOWN	S5741209000300	LEADING EDGE INTERMEDIATE
UNKNOWN	S5741209000500	LEADING EDGE INTERMEDIATE
UNKNOWN	4321554	LOGO LIGHT
UNKNOWN	4321561	LOGO LIGHT
UNKNOWN	4321577	LOGO LIGHT
UNKNOWN	4321584	LOGO LIGHT
LIEBHERR AERSPACE	754A0000-03	MAIN HEAT EXCHANGER
LIEBHERR AERSPACE	754B0000-02	MAIN HEAT EXCHANGER
LIEBHERR AERSPACE	754C0000-01	MAIN HEAT EXCHANGER
LIEBHERR AERSPACE	754D0000-01	MAIN HEAT EXCHANGER
APPARATEBAU GAUTING	VD3820-01	MIXED FLOW FAN
APPARATEBAU GAUTING	VD3820	MIXED FLOW FAN
APPARATEBAU GAUTING	VD3820MOD01	MIXED FLOW FAN
Liebherr	6740F010000	OVER PRESSURE VALVE
Liebherr	6740G010000	OVER PRESSURE VALVE
Liebherr	6740E010000	OVER PRESSURE VALVE
ATA 35	RCF6701	PRESSURE REGULATOR TRANSMITTER

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

ATA 35	RCF6702	PRESSURE REGULATOR TRANSMITTER
ATA 35	RCF6703	PRESSURE REGULATOR TRANSMITTER
ATA 35	RCF6704	PRESSURE REGULATOR TRANSMITTER
ATA 35	RCF6705	PRESSURE REGULATOR TRANSMITTER
ATA 35	RCF6706	PRESSURE REGULATOR TRANSMITTER
ATA 35	RCF6707	PRESSURE REGULATOR TRANSMITTER
ATA 35	RCF6708	PRESSURE REGULATOR TRANSMITTER
ATA 35	RCF6709	PRESSURE REGULATOR TRANSMITTER
ATA 35	RCF6710	PRESSURE REGULATOR TRANSMITTER
ATA 35	RCF6711	PRESSURE REGULATOR TRANSMITTER
ATA 35	RCF6717	PRESSURE REGULATOR TRANSMITTER
ATA 21	753A0000-03	PRIMARY HEAT EXCHANGER
ATA 21	753A0000-04	PRIMARY HEAT EXCHANGER
ATA 21	753B0000-02	PRIMARY HEAT EXCHANGER
ATA 21	753B0000-03	PRIMARY HEAT EXCHANGER
ATA 21	753C0000-01	PRIMARY HEAT EXCHANGER
ATA 21	753C0000-02	PRIMARY HEAT EXCHANGER
ATA 21	753D0000-01	PRIMARY HEAT EXCHANGER

FACILITY MRO - WHEELS AND BRAKES

OEM	PART NUMBER	DESCRIPTION
SAFRAN	4305990020	WHEEL PRESSURE TRANSDUCER
SAFRAN	4305990040	WHEEL PRESSURE TRANSDUCER
HONEYWELL	2611205-2	NOSE WHEEL ASSY
BOEING	294W522-220	NOSE WHEEL ASSY
GOODRICH	3-1470	NOSE WHEEL ASSY
GOODRICH	3-1470 OPT1	NOSE WHEEL ASSY
GOODRICH	3-1470 OPT2	NOSE WHEEL ASSY
GOODRICH	3-1470 OPT3	NOSE WHEEL ASSY
GOODRICH	3-1470 OPT4	NOSE WHEEL ASSY
GOODRICH	3-1470-1 OPT1	NOSE WHEEL ASSY
GOODRICH	3-1470-1 OPT2	NOSE WHEEL ASSY
GOODRICH	3-1470-1 OPT3	NOSE WHEEL ASSY
GOODRICH	3-1470-1 OPT4	NOSE WHEEL ASSY
GOODRICH	3-1530-1	MLG WHEEL ASSY
GOODRICH	3-1530-1OPT2	MLG WHEEL ASSY
GOODRICH	3-1530-1OPT3	MLG WHEEL ASSY
GOODRICH	3-1530-1OPT4	MLG WHEEL ASSY
GOODRICH	3-1530-2	MLG WHEEL ASSY
GOODRICH	3-1530-2OPT2	MLG WHEEL ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

GOODRICH	3-1530-2OPT3	MLG WHEEL ASSY
GOODRICH	3-1530-2OPT4	MLG WHEEL ASSY
GOODRICH	3-1530-3	MLG WHEEL ASSY
GOODRICH	3-1530-3OPT2	MLG WHEEL ASSY
GOODRICH	3-1530-3OPT3	MLG WHEEL ASSY
GOODRICH	3-1530-3OPT4	MLG WHEEL ASSY
GOODRICH	3-1530-4	MLG WHEEL ASSY
GOODRICH	3-1530-4T2	MLG WHEEL ASSY
GOODRICH	3-1530-4T3	MLG WHEEL ASSY
GOODRICH	3-1530-4T4	MLG WHEEL ASSY
GOODRICH	3-1530-5	MLG WHEEL ASSY
GOODRICH	3-1530-5T2	MLG WHEEL ASSY
GOODRICH	3-1530-5T3	MLG WHEEL ASSY
GOODRICH	3-1530-5T4	MLG WHEEL ASSY
GOODRICH	3-1530-6	MLG WHEEL ASSY
GOODRICH	3-1530-6T2	MLG WHEEL ASSY
GOODRICH	3-1530-6T3	MLG WHEEL ASSY
GOODRICH	3-1530-6T4	MLG WHEEL ASSY
GOODRICH	3-1530-7	MLG WHEEL ASSY
GOODRICH	3-1530-7T2	MLG WHEEL ASSY
GOODRICH	3-1530-7T3	MLG WHEEL ASSY
GOODRICH	3-1530-7T4	MLG WHEEL ASSY
GOODRICH	3-1530OPT2	MLG WHEEL ASSY
GOODRICH	3-1530OPT3	MLG WHEEL ASSY
GOODRICH	3-1530OPT4	MLG WHEEL ASSY
SAFRAN	C20586120	MLG WHEEL ASSY
SAFRAN	C20586100	MLG WHEEL ASSY
SAFRAN	C20586101	MLG WHEEL ASSY
SAFRAN	C20586110	MLG WHEEL ASSY
SAFRAN	C20589000	NOSE WHEEL ASSY
SAFRAN	C20225310	BRAKE ASSY
SAFRAN	C20225310-1	BRAKE ASSY
SAFRAN	C20225410	CARBON BRAKE ASSY
SAFRAN	C20225410-1	CARBON BRAKE ASSY
SAFRAN	C20449000	CARBON BRAKE ASSY
SAFRAN	C20449099	CARBON BRAKE ASSY
SAFRAN	C20449100	CARBON BRAKE ASSY
SAFRAN	C20534000	CARBON BRAKE ASSY
SAFRAN	C20534000-1	CARBON BRAKE ASSY
SAFRAN	C20534049	CARBON BRAKE ASSY
SAFRAN	C20534099	CARBON BRAKE ASSY
SAFRAN	C20210601	CARBON BRAKE ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

SAFRAN	C20210602	CARBON BRAKE ASSY
SAFRAN	C20210603	CARBON BRAKE ASSY
SAFRAN	C20210604	CARBON BRAKE ASSY
SAFRAN	C20210605	CARBON BRAKE ASSY
SAFRAN	C20210606	CARBON BRAKE ASSY
SAFRAN	C20210607	CARBON BRAKE ASSY
SAFRAN	C20210608	CARBON BRAKE ASSY
SAFRAN	C20210609	CARBON BRAKE ASSY
SAFRAN	C202106010	CARBON BRAKE ASSY
SAFRAN	C20585710	CARBON BRAKE ASSY
SAFRAN	C20585711	CARBON BRAKE ASSY
SAFRAN	C20585712	CARBON BRAKE ASSY
GOODRICH	3-1530	MLG WHEEL ASSY
GOODRICH	2-1598	BRAKE ASSY.
GOODRICH	3-1724	MWA
SAFRAN	C20225508	CARBON BRAKE ASSY
SAFRAN	C20225509	CARBON BRAKE ASSY
SAFRAN	C20225510	CARBON BRAKE ASSY
SAFRAN	2-1705	CARBON BRAKE ASSY
GOODRICH	2-1663-2	CARBON BRAKE ASSY.
GOODRICH	2-1663-3	CARBON BRAKE ASSY.
GOODRICH	2-1663OPT1	CARBON BRAKE ASSY.
GOODRICH	2-1663OPT2	CARBON BRAKE ASSY.
GOODRICH	2-1549-2	MAIN BRAKE ASSY
GOODRICH	2-1549-3	MAIN BRAKE ASSY
GOODRICH	2-1728	MAIN BRAKE ASSY
GOODRICH	3-1559	NOSE WHEEL
GOODRICH	3-1559OPT1	NOSE WHEEL
GOODRICH	3-1559OPT2	NOSE WHEEL
GOODRICH	3-1559OPT3	NOSE WHEEL
GOODRICH	3-1559OPT4	NOSE WHEEL
HONEYWELL	2601042-3	BRAKE ASSY
HONEYWELL	2601042-4	BRAKE ASSY
HONEYWELL	2601042-5	BRAKE ASSY
HONEYWELL	2609472-4	MAIN BRAKE ASSY
HONEYWELL	2606672-1	MAIN BRAKE ASSY
HONEYWELL	2606672-2	MAIN BRAKE ASSY
HONEYWELL	2606672-3	MAIN BRAKE ASSY
HONEYWELL	2606672-4	MAIN BRAKE ASSY
HONEYWELL	2602202-1	HOUSING ASSY
GOODRICH	2-1474	MLG BRAKE
GOODRICH	2-1474-1	MLG BRAKE

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

GOODRICH	2-1474-2	MLG BRAKE
GOODRICH	2-1474-3	MLG BRAKE
GOODRICH	2-1474-4	MLG BRAKE
GOODRICH	2-1474-5	MLG BRAKE
GOODRICH	2-1474-5OPT1	MLG BRAKE
GOODRICH	2-1474-5OPT2	MLG BRAKE
GOODRICH	2-1474-5OPT3	MLG BRAKE
GOODRICH	2-1474-5OPT4	MLG BRAKE
GOODRICH	2-1474-7	MLG BRAKE
GOODRICH	2-1521	MLG BRAKE ASSY
GOODRICH	2-1521-1	MLG BRAKE ASSY
GOODRICH	2-1521OPT1	MLG BRAKE ASSY
GOODRICH	2-1521OPT2	MLG BRAKE ASSY
HONEYWELL	2609801-1	MAIN WHEEL ASSY
HONEYWELL	2608891-1	MAIN WHEEL ASSY
GOODRICH	2-1587-1	MLG BRAKE ASSY
GOODRICH	2-1587-2	BRAKE ASSY
HONEYWELL	2612302-1	MAIN BRAKE ASSY
HONEYWELL	2612311-1	MAIN WHEEL ASSY
HONEYWELL	2606671-2	MAIN WHEEL ASSY
HONEYWELL	2612312-1	MAIN BRAKE ASSY
GOODRICH	3-1674	MAIN WHEEL
GOODRICH	3-1674-1	MAIN WHEEL
GOODRICH	2-1740	MLG BRAKE
GOODRICH	2-1740-1	MLG BRAKE
GOODRICH	3-1597	MAIN WHEEL ASSY
GOODRICH	3-1479-2	MAIN WHEEL ASSY
GOODRICH	3-1438-1	NOSE WHEEL ASSY
GOODRICH	2-1515-1	MLG BRAKE ASSY
GOODRICH	2-1515-2	MLG BRAKE ASSY
BOEING	60B10062-11	MLG BRAKE ASSY
BOEING	60B10062-12	MLG BRAKE ASSY
GOODRICH	3-1670	WHEEL ASSY
HONEYWELL	2615902-1	BRAKE ASSY
HONEYWELL	2607092-1	BRAKE ASSY
HONEYWELL	2607092-2	BRAKE ASSY
HONEYWELL	2607092-3	BRAKE ASSY
HONEYWELL	2607092-4	BRAKE ASSY
HONEYWELL	2612412-1	MAIN BRAKE ASSY
HONEYWELL	2612412-1A	MAIN BRAKE ASSY
GOODRICH	3-1540	MAIN WHEEL
MEGGITT	5006586	MAIN WHEEL

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

MEGGITT	5006586-1	MAIN WHEEL
MEGGITT	5006586-2	MAIN WHEEL
MEGGITT	AHA2063	MAIN WHEEL ASSY
MEGGITT	9543476	NOSE WHEEL
MEGGITT	9550267-6	NOSE WHEEL
HONEYWELL	2609471-2	MAIN WHEEL
MEGGITT	3-1357-1	MAIN WHEEL
MEGGITT	5007397-1	MAIN WHEEL
MEGGITT	5007397-2	MAIN WHEEL
GOODRICH	2-1582	BRAKE ASSY.
GOODRICH	2-1582OPT2	BRAKE ASSY.
GOODRICH	2-1582OPT5	BRAKE ASSY.
GOODRICH	2-1582OPT6	BRAKE ASSY.
GOODRICH	2-1624	MAIN BRAKE ASSY
GOODRICH	2-1624 OPT2	MAIN BRAKE ASSY
GOODRICH	2-1624-1	BRAKE ASSY.
GOODRICH	2-1628	BRAKE
GOODRICH	2-1699-1	MLG BRAKE
GOODRICH	2-1699-1 OPT 2	MLG BRAKE
GOODRICH	2-1699-2	MLG BRAKE
GOODRICH	2-1699-3	MLG BRAKE
GOODRICH	2-1707	MLG BRAKE
GOODRICH	2-1707-1	MLG BRAKE
GOODRICH	2-1707-2	MLG BRAKE
GOODRICH	3-1531	NLG WHEEL ASSY
GOODRICH	3-1531-1	NLG WHEEL ASSY
GOODRICH	3-1531-2	NLG WHEEL ASSY
GOODRICH	3-1531-3	NLG WHEEL ASSY
GOODRICH	3-1535	NOSE WHEEL
GOODRICH	3-1535OPT1	NOSE WHEEL
GOODRICH	3-1550	MWA
GOODRICH	3-1550-1	MWA
GOODRICH	3-1551	NWA
GOODRICH	3-1631-1	MLG WHEEL ASSY
MEGGITT	90000583-1	MAIN BRAKE ASSY
MEGGITT	90000583-1PR	MAIN BRAKE ASSY
MEGGITT	90000583-2	MAIN BRAKE ASSY
MEGGITT	90000583-2PR	MAIN BRAKE ASSY
MEGGITT	90000583-3	MAIN BRAKE ASSY
MEGGITT	90000583-3PR	MAIN BRAKE ASSY
MEGGITT	90000583-5	MAIN BRAKE ASSY
MEGGITT	90000583-5PR	MAIN BRAKE ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

MEGGITT	90000583-6	MAIN BRAKE ASSY
MEGGITT	90000583-6PR	MAIN BRAKE ASSY
MEGGITT	90002340	MAIN BRAKE ASSY
MEGGITT	90002340-1	MAIN BRAKE ASSY
MEGGITT	90002340-1PR	MAIN BRAKE ASSY
MEGGITT	90002340-2	MAIN BRAKE ASSY
MEGGITT	90002340-2PR	MAIN BRAKE ASSY
MEGGITT	90002340-4	MAIN BRAKE ASSY
MEGGITT	90002340-4PR	MAIN BRAKE ASSY
MEGGITT	90002340-5	MAIN BRAKE ASSY
MEGGITT	90002340-5PR	MAIN BRAKE ASSY
MEGGITT	9544207-3	NOSE WHEEL
MEGGITT	9544207-4	NOSE WHEEL
MEGGITT	9544207-5	NOSE WHEEL
MEGGITT	9544207-6	NOSE WHEEL
MEGGITT	9544207-7	NOSE WHEEL
GOODRICH	3-1418	NOSE WHEEL
GOODRICH	3-1418 OPT 1	NOSE WHEEL
MEGGITT	9560685	BRAKE ASSY
MEGGITT	9560685-1	BRAKE ASSY
MEGGITT	5007898-1	BRAKE ASSY
MEGGITT	5007898-3	BRAKE ASSY
HONEYWELL	2609471-3	MAIN WHEEL
HONEYWELL	2608892-1	STEEL BRAKE ASSY
BOEING	001A610353-53	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1001	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1002	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1003	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1004	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1005	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1006	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1007	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1008	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1009	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1010	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1011	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1012	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1013	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1014	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1015	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1016	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1017	MLG WHEEL TIRE AND BRAKE INST

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

www.ticaerospace.com

BOEING	277A6000-1018	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1019	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1020	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1021	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1022	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1023	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1024	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1025	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1026	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1027	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1028	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1029	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1030	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1031	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1032	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1033	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1034	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1035	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1036	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1037	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-1038	MLG WHEEL TIRE AND BRAKE INST
BOEING	277A6000-2501	NLG WHEEL & TIRE INST
BOEING	277A6000-2502	NLG WHEEL & TIRE INST
BOEING	277A6000-2503	NLG WHEEL & TIRE INST
BOEING	277A6000-2504	NLG WHEEL & TIRE INST
BOEING	277A6000-2505	NLG WHEEL & TIRE INST
BOEING	277A6000-2506	NLG WHEEL & TIRE INST
BOEING	277A6000-2507	NLG WHEEL & TIRE INST
BOEING	277A6000-31	NLG WHEEL & TIRE INST
BOEING	277A6000-32	NLG WHEEL & TIRE INST
BOEING	277A6000-33	NLG WHEEL & TIRE INST
BOEING	277A6000-34	NLG WHEEL & TIRE INST
BOEING	277A6000-35	NLG WHEEL & TIRE INST
BOEING	277A6000-36	NLG WHEEL & TIRE INST
BOEING	277A6000-401	NLG WHEEL & TIRE INST
BOEING	277A6000-402	NLG WHEEL & TIRE INST
BOEING	277A6000-403	NLG WHEEL & TIRE INST
BOEING	277A6000-404	NLG WHEEL & TIRE INST
BOEING	277A6000-405	NLG WHEEL & TIRE INST
BOEING	277A6000-406	NLG WHEEL & TIRE INST
BOEING	277A6000-407	NLG WHEEL & TIRE INST
BOEING	277A6000-801	NLG WHEEL & TIRE INST

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	277A6000-802	NLG WHEEL & TIRE INST
BOEING	277A6000-803	NLG WHEEL & TIRE INST
BOEING	277A6000-804	NLG WHEEL & TIRE INST
BOEING	277A6000-805	NLG WHEEL & TIRE INST
BOEING	277A6000-806	NLG WHEEL & TIRE INST
BOEING	277A6000-807	NLG WHEEL & TIRE INST
MEGGITT	9560685-1	BRAKEASSY
HONEYWELL	2601042-3	BRAKEASSY
HONEYWELL	2601042-4	BRAKEASSY
HONEYWELL	2601042-5	BRAKEASSY
HONEYWELL	2612302-1	MAIN BRAKE ASSY
HONEYWELL	2612312-1	MAIN BRAKE ASSY
GOODRICH	2-1474	MLGBRAKE
GOODRICH	2-1474-1	MLGBRAKE
GOODRICH	2-1474-2	MLGBRAKE
GOODRICH	2-1474-3	MLGBRAKE
GOODRICH	2-1474-4	MLGBRAKE
GOODRICH	2-1474-5	MLGBRAKE
GOODRICH	2-1474-5OPT1	MLGBRAKE
GOODRICH	2-1474-5OPT2	MLGBRAKE
GOODRICH	2-1474-5OPT4	MLGBRAKE
GOODRICH	2-1474-7	MLGBRAKE
GOODRICH	3-1438	NOSEWHEEL ASSY
GOODRICH	3-1540	MAINWHEEL
GOODRICH	3-1666	MAIN WHELL
BOEING	S294W512-381	MAIN WHEEL
GOODRICH	3-1535	NOSEWHEEL ASSY
GOODRICH	3-1535OPT1	NOSEWHEEL ASSY
GOODRICH	2-1587-1	MLG BRAKEASSY
GOODRICH	3-1559	NOSEWHEEL
GOODRICH	3-1559OPT1	NOSEWHEEL
GOODRICH	3-1559OPT2	NOSEWHEEL
GOODRICH	3-1559OPT3	NOSEWHEEL
GOODRICH	3-1559OPT4	NOSEWHEEL
MEGGITT	5007397	MAINWHEEL ASSY
MEGGITT	5000757	MAIN WHEEL ASSY
MEGGITT	5000757-2	MAIN WHEEL ASSY
MEGGITT	5000757-3	MAIN WHEEL ASSY
MEGGITT	5000757-4	MAIN WHEEL ASSY
MEGGITT	5000757-5	MAIN WHEEL ASSY
MEGGITT	5000757-6	MAIN WHEEL ASSY
MEGGITT	5000757-8	MAIN WHEEL ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

SAFRAN	C20534000-1	CARBON BRAKE ASSY
MEGGITT	5000919	NOSEWHEEL
MEGGITT	5000919-1	NOSEWHEEL
MEGGITT	5000919-2	NOSEWHEEL
GOODRICH	2-1740	MLGBRAKE
GOODRICH	2-1740-1	MLGBRAKE
GOODRICH	3-1674	MAINWHEEL
MEGGITT	AHA1737	MAINWHEEL
MEGGITT	AHA1653	BRAKE
MEGGITT	AHA1653-10	BRAKE
MEGGITT	AHA1653-9	BRAKE
MEGGITT	5000758-10	MAIN BRAKE ASSY
HONEYWELL	2612412-1	MAIN BRAKE ASSY
HONEYWELL	2612412-1A	MAIN BRAKE ASSY
MEGGITT	5007898	BRAKEASSY
HONEYWELL	2609472-4	MAIN BRAKE ASSY
SAFRAN	C20210610	CARBON BRAKE ASSEMBLY
MEGGITT	AHA2331	BRAKE UNIT
MEGGITT	AHA2332	BRAKE UNIT
MEGGITT	AHA2334	BRAKE UNIT
MEGGITT	AHA2335	BRAKE UNIT
MEGGITT	AHA2331-2	BRAKE UNIT
MEGGITT	AHA2332-2	BRAKE UNIT
MEGGITT	AHA2334-2	BRAKE UNIT
MEGGITT	AHA2335-2	BRAKE UNIT
MEGGITT	AHA2331-4	BRAKE UNIT
MEGGITT	AHA2332-4	BRAKE UNIT
MEGGITT	AHA2334-4	BRAKE UNIT
MEGGITT	AHA2335-4	BRAKE UNIT
GOODRICH	2-1521	MLG BRAKEASSY
GOODRICH	2-1521-1	MLG BRAKEASSY
GOODRICH	2-1521OPT1	MLG BRAKEASSY
GOODRICH	2-1521OPT2	MLG BRAKEASSY
MEGGITT	9544207	NOSEWHEEL ASSY
MEGGITT	9544207-2	NOSEWHEEL ASSY
GOODRICH	2-1549-2	MAIN BRAKE ASSY
GOODRICH	2-1549-3	MAIN BRAKE ASSY
SAFRAN	C20225310-1	BRAKEASSY
SAFRAN	C20225410-1	CARBON BRAKE ASSY
GOODRICH	2-1624OPT2	MAIN BRAKE ASSY
GOODRICH	3-1631-1	MLG WHEEL ASSY
GOODRICH	2-1699-1	MLGBRAKE

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

GOODRICH	2-1699-1 OPT 2	MLGBRAKE
GOODRICH	2-1699-2	MLGBRAKE
GOODRICH	2-1699-3	MLGBRAKE
GOODRICH	2-1707	MLGBRAKE
GOODRICH	2-1707-1	MLGBRAKE
GOODRICH	2-1707-2	MLGBRAKE
MEGGITT	90000583-1	MAIN BRAKE ASSY
MEGGITT	90000583-1PR	MAIN BRAKE ASSY
MEGGITT	90000583-2	MAIN BRAKE ASSY
MEGGITT	90000583-2PR	MAIN BRAKE ASSY
MEGGITT	90000583-3	MAIN BRAKE ASSY
MEGGITT	90000583-3PR	MAIN BRAKE ASSY
MEGGITT	90000583-5	MAIN BRAKE ASSY
MEGGITT	90000583-5PR	MAIN BRAKE ASSY
MEGGITT	90000583-6	MAIN BRAKE ASSY
MEGGITT	90000583-6PR	MAIN BRAKE ASSY
MEGGITT	90002340-1	MAIN BRAKE ASSY
MEGGITT	90002340-1PR	MAIN BRAKE ASSY
MEGGITT	90002340-2	MAIN BRAKE ASSY
MEGGITT	90002340-2PR	MAIN BRAKE ASSY
MEGGITT	90002340-4	MAIN BRAKE ASSY
MEGGITT	90002340-4PR	MAIN BRAKE ASSY
MEGGITT	90002340-5	MAIN BRAKE ASSY
MEGGITT	90002340-5PR	MAIN BRAKE ASSY
MEGGITT	90002340PR	MAIN BRAKE ASSY
SAFRAN	C20509000	MAIN WHEEL ASSEMBLY
SAFRAN	C20633000	CARBON BRAKE ASSY
SAFRAN	C20637000	NOSEWHEEL
SAFRAN	C20637100	NOSEWHEEL
SAFRAN	C20626200	MLG WHEEL ASSY
MEGGITT	90000581	NOSE WHEEL ASSEMBLY
MEGGITT	90000581-1	NOSE WHEEL ASSEMBLY
MEGGITT	90002317	MAIN WHEEL ASSEMBLY
MEGGITT	90002317-1	MAIN WHEEL ASSEMBLY
MEGGITT	90002317-2	MAIN WHEEL ASSEMBLY
MEGGITT	5006856-5R	WHEEL
MEGGITT	5006858-2A	WHEEL
MEGGITT	5006856-5	WHEEL
MEGGITT	5012609	BRAKE
MEGGITT	5006857-2	BRAKE
SAFRAN	C20508000	CARBON BRAKE ASSEMBLY
BOEING	S160T400-510	CARBON BRAKE ASSEMBLY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

HONEYWELL	2611811-1	NOSE WHEEL ASSEMBLY
BOEING	285T0035-11	ELECTRONIC UNIT POWERSUPPLY ASSY
GOODRICH	3-1423-1	NLG WHEEL ASSEMBLY
GOODRICH	3-1423-2	NLG WHEEL ASSEMBLY
GOODRICH	3-1422	MAIN WHEEL ASSY
GOODRICH	3-1427	MAIN WHEEL ASSY
GOODRICH	3-1428	MAIN WHEEL ASSY
MEGGITT	5004563-5	SINGLE DISK BRAKE
GOODRICH	2-1523	DISK BRAKE
GOODRICH	2-1700	BRAKE
AEROCONTROLEX	880T100	ACTUATOR
HONEYWELL	102538-2-1	CONTROL
HONEYWELL	2611202-2	777 MAIN BRAKE ASSEMBLY
HONEYWELL	2611202-2A	777 MAIN BRAKE ASSEMBLY
HONEYWELL	2611202-2B	777 MAIN BRAKE ASSEMBLY
MEGGITT	9550616	MAIN WHEEL ASSEMBLY
ATOS	3-1486	MAIN WHEEL ASSEMBLY
DUNLOP	AHA2114	MAIN WHEEL ASSEMBLY
MEGGITT	AH55055	NOSE WHEEL ASSEMBLY
MEGGITT	AHA2396-1	BRAKE ASSEMBLY
MEGGITT	GAC1159SCL504-5	BRAKE ASSEMBLY
MEGGITT	1159L47003-5	MAIN WHEEL ASSEMBLY
MEGGITT	90001936	MAIN WHEEL ASSEMBLY
MEGGITT	1159SCL472-5	MAIN WHEEL ASSEMBLY
MEGGITT	90005587	NOSE WHEEL ASSEMBLY
MEGGITT	60P3241101A001	NOSE WHEEL ASSEMBLY
MEGGITT	90005586-1	MAIN WHEEL ASSEMBLY
MEGGITT	60P3242101A003	MAIN WHEEL ASSEMBLY
MEGGITT	90005585-4	CARBON BRAKE ASSEMBLY
MEGGITT	90005585-2	CARBON BRAKE ASSEMBLY
MEGGITT	90008563	NOSE WHEEL ASSEMBLY
MEGGITT	72P3241000A001	NOSE WHEEL ASSEMBLY
MEGGITT	90008561	MAIN WHEEL ASSEMBLY
MEGGITT	72P3242001A003	MAIN WHEEL ASSEMBLY
MEGGITT	90008562	CARBON BRAKE ASSEMBLY
MEGGITT	90010007	NOSE WHEEL ASSEMBLY
MEGGITT	90009605	MAIN WHEEL ASSEMBLY
MEGGITT	DAP00097-01	BRAKE UNIT
MEGGITT	DAP00097-02	BRAKE UNIT
MEGGITT	DAP00099-01	NOSE WHEEL
MEGGITT	DAP00099-02	NOSE WHEEL
MEGGITT	DAP00098-01	MAIN WHEEL

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

MEGGITT	DAP00098-02	MAIN WHEEL
MEGGITT	90005025	BRAKE ASSY
MEGGITT	90005025-1	BRAKE ASSY
MEGGITT	90005025-2	BRAKE ASSY
MEGGITT	90005025-3	BRAKE ASSY
MEGGITT	90005024	MAIN WHEEL ASSEMBLY
MEGGITT	90005023-1	NOSE WHEEL ASSY
MHIRJ	600-88101-23	MECHANISM ASSEMBLY - BRAKE CONTROL
MHIRJ	600-88101-25	MECHANISM ASSEMBLY - BRAKE CONTROL
MHIRJ	600-88101-29	MECHANISM ASSEMBLY - BRAKE CONTROL
MHIRJ	600-88101-125	MECHANISM ASSEMBLY - BRAKE CONTROL
MHIRJ	600-88101-127	MECHANISM ASSEMBLY - BRAKE CONTROL
MHIRJ	600-88101-129	MECHANISM ASSEMBLY - BRAKE CONTROL
MHIRJ	600-88101-133	MECHANISM ASSEMBLY - BRAKE CONTROL
MHIRJ	CC670-88101-1	MECHANISM ASSEMBLY - BRAKE CONTROL
MHIRJ	CC670-88101-5	MECHANISM ASSEMBLY - BRAKE CONTROL
MHIRJ	CC670-88101-7	MECHANISM ASSEMBLY - BRAKE CONTROL
MHIRJ	CC670-88101-9	MECHANISM ASSEMBLY - BRAKE CONTROL
MHIRJ	CC698-88101	MECHANISM ASSEMBLY - BRAKE CONTROL
MEGGITT	5003096	BRAKE ASSY
MEGGITT	5003096-1	BRAKE ASSY
MEGGITT	5003096-3	BRAKE ASSY
MEGGITT	5003096-4	BRAKE ASSY
MEGGITT	5003096-5	BRAKE ASSY
MEGGITT	5003096-6	BRAKE ASSY
MEGGITT	5003096-7	BRAKE ASSY
SAFRAN	C20195162	MAIN LANDING GEAR WHEEL ASSEMBLY
32-44-76	5012589-3	BRAKE ASSEMBLY
32-44-76	5012589-4	BRAKE ASSEMBLY
32-43-04	2608811-2	MAIN WHEEL ASSEMBLY
32-43-04	2608811-3	MAIN WHEEL ASSEMBLY
32-43-04	2608811-5	MAIN WHEEL ASSEMBLY
BOEING	S160N010-23	MAIN WHEEL ASSEMBLY
BOEING	S160N010-24	MAIN WHEEL ASSEMBLY
BOEING	S160N010-25	MAIN WHEEL ASSEMBLY
MEGGITT	AHA1648	MAIN WHEEL ASSEMBLY
BOEING	S160N020-6	MAIN WHEEL ASSEMBLY
BOEING	S160N010-30	NOSE LANDING GEAR WHEEL ASSEMBLY
BOEING	S160N010-31	NOSE LANDING GEAR WHEEL ASSEMBLY
HONEYWELL	2606735-1	NOSE WHEEL ASSEMBLY
HONEYWELL	2606735-2	NOSE WHEEL ASSEMBLY
GOODRICH	2-1457	MAIN LANDING GEAR CARBON BRAKE ASSEMBLY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

GOODRICH	2-1457-1	MAIN LANDING GEAR CARBON BRAKE ASSEMBLY
GOODRICH	2-1457-2	MAIN LANDING GEAR CARBON BRAKE ASSEMBLY
BOEING	S160N010-43	MAIN LANDING GEAR CARBON BRAKE ASSEMBLY
BOEING	S160N010-45	MAIN LANDING GEAR CARBON BRAKE ASSEMBLY
BOEING	S160N010-46	MAIN LANDING GEAR CARBON BRAKE ASSEMBLY
MEGGITT	AHA1884	BRAKE UNIT
BOEING	S160N020-14	BRAKE UNIT

FACILITY MRO - LANDING GEARS		
OEM	PART NUMBER	DESCRIPTION
BOEING	001A6103-1	MAIN LANDING GEAR LH
BOEING	001A6103-15	MAIN LANDING GEAR LH
BOEING	001A6103-16	MAIN LANDING GEAR RH
BOEING	001A6103-2	MAIN LANDING GEAR RH
BOEING	001A6200-5	NOSE LANDING GEAR
BOEING	161A1100-10	MAIN LANDING GEAR
BOEING	161A1100-100	MAIN LANDING GEAR
BOEING	161A1100-101	MAIN LANDING GEAR
BOEING	161A1100-102	MAIN LANDING GEAR
BOEING	161A1100-13	MAIN LANDING GEAR
BOEING	161A1100-14	MAIN LANDING GEAR
BOEING	161A1100-15	MAIN LANDING GEAR
BOEING	161A1100-16	MAIN LANDING GEAR
BOEING	161A1100-19	MAIN LANDING GEAR
BOEING	161A1100-20	MAIN LANDING GEAR
BOEING	161A1100-23	MAIN LANDING GEAR
BOEING	161A1100-24	MAIN LANDING GEAR
BOEING	161A1100-27	MAIN LANDING GEAR
BOEING	161A1100-28	MAIN LANDING GEAR
BOEING	161A1100-31	MAIN LANDING GEAR
BOEING	161A1100-32	MAIN LANDING GEAR
BOEING	161A1100-35	MAIN LANDING GEAR
BOEING	161A1100-36	MAIN LANDING GEAR
BOEING	161A1100-39	MAIN LANDING GEAR
BOEING	161A1100-40	MAIN LANDING GEAR
BOEING	161A1100-41	MAIN LANDING GEAR
BOEING	161A1100-42	MAIN LANDING GEAR
BOEING	161A1100-45	MAIN LANDING GEAR
BOEING	161A1100-46	MAIN LANDING GEAR
BOEING	161A1100-49	MAIN LANDING GEAR
BOEING	161A1100-5	MAIN LANDING GEAR
BOEING	161A1100-50	MAIN LANDING GEAR

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	161A1100-53	MAIN LANDING GEAR
BOEING	161A1100-54	MAIN LANDING GEAR
BOEING	161A1100-6	MAIN LANDING GEAR
BOEING	161A1100-63	MAIN LANDING GEAR
BOEING	161A1100-64	MAIN LANDING GEAR
BOEING	161A1100-67	MAIN LANDING GEAR
BOEING	161A1100-68	MAIN LANDING GEAR
BOEING	161A1100-71	MAIN LANDING GEAR
BOEING	161A1100-72	MAIN LANDING GEAR
BOEING	161A1100-75	MAIN LANDING GEAR
BOEING	161A1100-76	MAIN LANDING GEAR
BOEING	161A1100-83	MAIN LANDING GEAR
BOEING	161A1100-84	MAIN LANDING GEAR
BOEING	161A1100-87	MAIN LANDING GEAR
BOEING	161A1100-88	MAIN LANDING GEAR
BOEING	161A1100-9	MAIN LANDING GEAR
BOEING	161A1100-91	MAIN LANDING GEAR
BOEING	161A1100-92	MAIN LANDING GEAR
BOEING	161A1100-99	MAIN LANDING GEAR
BOEING	162A1100-10	NOSE LANDING GEAR
BOEING	162A1100-11	NOSE LANDING GEAR
BOEING	162A1100-12	NOSE LANDING GEAR
BOEING	162A1100-13	NOSE LANDING GEAR
BOEING	162A1100-14	NOSE LANDING GEAR
BOEING	162A1100-15	NOSE LANDING GEAR
BOEING	162A1100-4	NOSE LANDING GEAR
BOEING	162A1100-5	NOSE LANDING GEAR
BOEING	162A1100-6	NOSE LANDING GEAR
BOEING	162A1100-7	NOSE LANDING GEAR
BOEING	162A1100-8	NOSE LANDING GEAR
BOEING	162A1100-9	NOSE LANDING GEAR
BOEING	65-73761-107	MLG LH
BOEING	65-73761-108	MLG LH
BOEING	65-73761-119	LH MAIN LANDING GEAR
BOEING	65-73761-120	RH MAIN LANDING GEAR
BOEING	65-73761-121	MLG LH
BOEING	65-73761-122	MLG RH
BOEING	65-73762-20	NOSE LANDING GEAR
BOEING	65-73762-21	NOSE LANDING GEAR
BOEING	5930593-5501	MAIN LANDING GEAR
BOEING	5930593-5502	MAIN LANDING GEAR
BOEING	5930593-5503	MAIN LANDING GEAR

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	5930593-5504	MAIN LANDING GEAR
BOEING	5930593-5505	MAIN LANDING GEAR
BOEING	5930593-5506	MAIN LANDING GEAR
BOEING	5930593-5507	MAIN LANDING GEAR
BOEING	5930593-5508	MAIN LANDING GEAR
BOEING	5930593-5509	MAIN LANDING GEAR
BOEING	5930593-5510	MAIN LANDING GEAR
BOEING	5930593-5511	MAIN LANDING GEAR
BOEING	5930593-5512	MAIN LANDING GEAR
BOEING	5930999-5001	MAIN LANDING GEAR
BOEING	5930999-5002	MAIN LANDING GEAR
BOEING	5930999-5501	MAIN LANDING GEAR
BOEING	5930999-5502	MAIN LANDING GEAR
BOEING	5930999-5503	MAIN LANDING GEAR
BOEING	5930999-5504	MAIN LANDING GEAR
BOEING	5930999-5505	MAIN LANDING GEAR
BOEING	5930999-5506	MAIN LANDING GEAR
BOEING	5930999-5507	MAIN LANDING GEAR
BOEING	5930999-5508	MAIN LANDING GEAR
BOEING	5930999-5509	MAIN LANDING GEAR
BOEING	5930999-5510	MAIN LANDING GEAR
BOEING	5930999-5511	MAIN LANDING GEAR
BOEING	5930999-5512	MAIN LANDING GEAR
BOEING	5930999-5513	MAIN LANDING GEAR
BOEING	5930999-5514	MAIN LANDING GEAR
BOEING	5930999-5515	MAIN LANDING GEAR
BOEING	5930999-5516	MAIN LANDING GEAR
BOEING	5930999-5517	MAIN LANDING GEAR
BOEING	5930999-5518	MAIN LANDING GEAR
BOEING	5930999-5519	MAIN LANDING GEAR
BOEING	5930999-5520	MAIN LANDING GEAR
BOEING	5930999-5521	MAIN LANDING GEAR
BOEING	5930999-5522	MAIN LANDING GEAR
BOEING	5930999-5523	MAIN LANDING GEAR
BOEING	5930999-5524	MAIN LANDING GEAR
BOEING	5930999-5525	MAIN LANDING GEAR
BOEING	5930999-5526	MAIN LANDING GEAR
BOEING	5930999-5527	MAIN LANDING GEAR
BOEING	5930999-5528	MAIN LANDING GEAR
BOEING	5930999-5529	MAIN LANDING GEAR
BOEING	5930999-5530	MAIN LANDING GEAR
BOEING	5930999-5531	MAIN LANDING GEAR

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	5930999-5532	MAIN LANDING GEAR
BOEING	5930999-5533	MAIN LANDING GEAR
BOEING	5930999-5534	MAIN LANDING GEAR
BOEING	5930999-5535	MAIN LANDING GEAR
BOEING	5930999-5536	MAIN LANDING GEAR
BOEING	5930999-5537	MAIN LANDING GEAR
BOEING	5930999-5538	MAIN LANDING GEAR
BOEING	5930999-5539	MAIN LANDING GEAR
BOEING	5930999-5540	MAIN LANDING GEAR
BOEING	5930999-5541	MAIN LANDING GEAR
BOEING	5930999-5542	MAIN LANDING GEAR
BOEING	5930999-5543	MAIN LANDING GEAR
BOEING	5930999-5544	MAIN LANDING GEAR
BOEING	5930999-5545	MAIN LANDING GEAR
BOEING	5930999-5546	MAIN LANDING GEAR
BOEING	5930999-5547	MAIN LANDING GEAR
BOEING	5930999-5548	MAIN LANDING GEAR
BOEING	SR09320103-3	MAIN LANDING GEAR
BOEING	SR09320103-4	MAIN LANDING GEAR
BOEING	SR09320103-5	MAIN LANDING GEAR
BOEING	SR09320103-6	MAIN LANDING GEAR
BOEING	5935355-1	MLG STRUT ASSY
BOEING	5935355-501	MLG STRUT ASSY
BOEING	5935355-503	MLG STRUT ASSY
BOEING	5935355-505	MLG STRUT ASSY
BOEING	5935355-507	MLG STRUT ASSY
BOEING	5935355-509	MLG STRUT ASSY
BOEING	5935355-511	MLG STRUT ASSY
BOEING	5935355-513	MLG STRUT ASSY
BOEING	5935355-515	MLG STRUT ASSY
BOEING	5935355-517	MLG STRUT ASSY
BOEING	5935355-519	MLG STRUT ASSY
BOEING	5935355-521	MLG STRUT ASSY
BOEING	5935355-523	MLG STRUT ASSY
BOEING	SR09320063-5	MLG STRUT ASSY
BOEING	5910447-5001	NOSE GEAR ASSY
BOEING	5910447-5501	NOSE GEAR ASSY
BOEING	5910447-5503	NOSE GEAR ASSY
BOEING	5910447-5505	NOSE GEAR ASSY
BOEING	5910447-5507	NOSE GEAR ASSY
BOEING	5910447-5513	NOSE GEAR ASSY
BOEING	5910447-5515	NOSE GEAR ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	5910447-5517	NOSE GEAR ASSY
BOEING	5910447-5519	NOSE GEAR ASSY
BOEING	5910447-5523	NOSE GEAR ASSY
BOEING	5910447-5533	NOSE GEAR ASSY
BOEING	5910447-5539	NOSE GEAR ASSY
BOEING	5910447-5541	NOSE GEAR ASSY
BOEING	5910447-5543	NOSE GEAR ASSY
BOEING	5910447-5545	NOSE GEAR ASSY
BOEING	5910447-5547	NOSE GEAR ASSY
BOEING	5910447-5549	NOSE GEAR ASSY
BOEING	5910447-5551	NOSE GEAR ASSY
BOEING	5910447-5553	NOSE GEAR ASSY
BOEING	5910447-5557	NOSE GEAR ASSY
BOEING	5910447-5561	NOSE GEAR ASSY
BOEING	5910447-5565	NOSE GEAR ASSY
BOEING	5910447-5569	NOSE GEAR ASSY
BOEING	5910447-5573	NOSE GEAR ASSY
BOEING	5910447-5575	NOSE GEAR ASSY
BOEING	5910447-5577	NOSE GEAR ASSY
BOEING	5910446-5569	GEAR INSTAL-NOSE LANDING
BOEING	5910446-5567	GEAR INSTAL-NOSE LANDING
BOEING	5910446-5565	GEAR INSTAL-NOSE LANDING
LIEBHERR	1170S0000	NLG STRUT ASSY
LIEBHERR	1170S0000-01	NLG STRUT ASSY
LIEBHERR	1172C0000-02	MAIN DRAG STRUT ASSY
LIEBHERR	1173B0000	AUX DRAG STRUT
LIEBHERR	1173B0000-02	AUX DRAG STRUT
LIEBHERR	1173B0000-03	AUX DRAG STRUT
ELEB	2309-2005-003	SHOCK ABSORBER ASS
ELEB	2309-2600-503	SECOND. SIDE STRUT
ELEB	2309-3002-503	LEG STRUT ASSY
ELEB	2309-3002-504	LEG STRUT ASSY
ELEB	2309-3500-503	MAIN SIDE STRUT ASSY
CASA	212-41050-3-51	MAIN LANDING GEAR
CASA	212-41050-4-51	MAIN LANDING GEAR
CASA	212-41051-3-51	MAIN LANDING GEAR
CASA	212-41051-4-51	MAIN LANDING GEAR
CASA	212-41051	MAIN LANDING GEAR
CASA	212-42000-1-51	NOSE LANDING GEAR
CASA	212-42001-1-51	NOSE LANDING GEAR
CASA	212-42001-3-51	NOSE LANDING GEAR
CASA	212-42002-1-51	NOSE LANDING GEAR

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

MESSIER	D22685040	LEG ASSEMBLY
MESSIER	D22685040-1	LEG ASSEMBLY
MESSIER	D22685040-2	LEG ASSEMBLY
MESSIER	D22685040-3	LEG ASSEMBLY
MESSIER	D22685040-4	LEG ASSEMBLY
MESSIER	D22685040-5	LEG ASSEMBLY
MESSIER	D22685040-6	LEG ASSEMBLY
MESSIER	D22685040-7	LEG ASSEMBLY
MESSIER	D22685040-8	LEG ASSEMBLY
MESSIER	D22685040-9	LEG ASSEMBLY
MESSIER	D22685040-10	LEG ASSEMBLY
MESSIER	D22685040-11	LEG ASSEMBLY
MESSIER	D22685040-12	LEG ASSEMBLY
MESSIER	D22685040-13	LEG ASSEMBLY
MESSIER	D22685040-14	LEG ASSEMBLY
MESSIER	D22685040-15	LEG ASSEMBLY
MESSIER	D22685040-16	LEG ASSEMBLY
MESSIER	D22685040-17	LEG ASSEMBLY
MESSIER	D22685040-18	LEG ASSEMBLY
MESSIER	D22686040	LEG ASSEMBLY
MESSIER	D22686040-1	LEG ASSEMBLY
MESSIER	D22686040-2	LEG ASSEMBLY
MESSIER	D22686040-3	LEG ASSEMBLY
MESSIER	D22686040-4	LEG ASSEMBLY
MESSIER	D22686040-5	LEG ASSEMBLY
MESSIER	D22686040-6	LEG ASSEMBLY
MESSIER	D22686040-7	LEG ASSEMBLY
MESSIER	D22686040-8	LEG ASSEMBLY
MESSIER	D22686040-9	LEG ASSEMBLY
MESSIER	D22686040-10	LEG ASSEMBLY
MESSIER	D22686040-11	LEG ASSEMBLY
MESSIER	D22686040-12	LEG ASSEMBLY
MESSIER	D22686040-13	LEG ASSEMBLY
MESSIER	D22686040-14	LEG ASSEMBLY
MESSIER	D22686040-15	LEG ASSEMBLY
MESSIER	D22686040-16	LEG ASSEMBLY
MESSIER	D22686040-17	LEG ASSEMBLY
MESSIER	D22686040-18	LEG ASSEMBLY
MESSIER	D22691000	SHOCK ABSORBER
MESSIER	D22691000-1	SHOCK ABSORBER
MESSIER	D22691000-2	SHOCK ABSORBER
MESSIER	D22691000-3	SHOCK ABSORBER

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

MESSIER	D22691000-4	SHOCK ABSORBER
MESSIER	D22691000-5	SHOCK ABSORBER
BOEING	65B10917-25	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-26	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-27	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-28	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-29	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-30	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-35	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-36	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-37	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-38	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-39	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-40	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-41	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-42	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-43	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-44	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-45	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-46	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-49	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-50	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-61	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10917-62	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B10916-41	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-42	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-43	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-44	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-45	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-46	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-51	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-52	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-53	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-54	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-55	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-56	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-57	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-58	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-59	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-60	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-61	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-62	AFT MAIN LANDING GEAR INBOARD DOOR ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

BOEING	65B10916-63	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-64	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-67	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-68	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-75	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-76	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-77	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-78	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-79	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-80	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-85	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-86	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-97	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B10916-98	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B13296-3	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B13296-4	AFT MAIN LANDING GEAR INBOARD DOOR ASSY
BOEING	65B13297-11	AFT MLG OLEO STRUT DOOR ASSY
BOEING	65B13297-12	AFT MLG OLEO STRUT DOOR ASSY
ELEB	2309-2002	MAIN LANDING GEAR
ELEB	2309-3002	MAIN LANDING GEAR
ELEB	2309-3100	MAIN LANDING GEAR
ELEB	2309-4002	MAIN LANDING GEAR
CASA	212-41051-A9B91	MAIN LANDING GEAR
BOEING	5930999-5513LH	RHMAIN LANDING GEAR
BOEING	5910446-5569	NOSE LANDING GEAR
BOEING	5910447-401	NOSE LANDING GEAR
BOEING	5910447-5003	NOSE LANDING GEAR
BOEING	5910447-5005	NOSE LANDING GEAR
BOEING	5910447-5007	NOSE LANDING GEAR
BOEING	5910447-5071	NOSE LANDING GEAR
BOEING	5940337-5001	NOSELANDING GEAR
BOEING	5940337-5501	NOSELANDING GEAR
BOEING	5940337-5503	NOSELANDING GEAR
BOEING	5940337-5507	NOSELANDING GEAR
LIEBHERR	1170C0000	NOSE LANDING GEAR
LIEBHERR	1170C0000-01	NOSE LANDING GEAR
LIEBHERR	1170C0000-02	NOSE LANDING GEAR
SAFRAN	6100-1	MAIN LANDING GEAR ASSY
SAFRAN	6100-2	MAIN LANDING GEAR ASSY
SAFRAN	6100-5	MAIN LANDING GEAR ASSY
SAFRAN	6100-6	MAIN LANDING GEAR ASSY
SAFRAN	6100-7	MAIN LANDING GEAR ASSY

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

SAFRAN	6100-8	MAIN LANDING GEAR ASSY
SAFRAN	6100-9	MAIN LANDING GEAR ASSY
SAFRAN	6100-10	MAIN LANDING GEAR ASSY
SAFRAN	6100-11	MAIN LANDING GEAR ASSY
SAFRAN	6100-12	MAIN LANDING GEAR ASSY
SAFRAN	6100-13	MAIN LANDING GEAR ASSY
SAFRAN	6100-14	MAIN LANDING GEAR ASSY
SAFRAN	6100-15	MAIN LANDING GEAR ASSY
SAFRAN	6100-16	MAIN LANDING GEAR ASSY
SAFRAN	6100-17	MAIN LANDING GEAR ASSY
SAFRAN	6100-18	MAIN LANDING GEAR ASSY
SAFRAN	6100-19	MAIN LANDING GEAR ASSY
SAFRAN	6100-20	MAIN LANDING GEAR ASSY
SAFRAN	6100-21	MAIN LANDING GEAR ASSY
SAFRAN	6100-22	MAIN LANDING GEAR ASSY
SAFRAN	6100-23	MAIN LANDING GEAR ASSY
SAFRAN	6100-24	MAIN LANDING GEAR ASSY
SAFRAN	6100-207	MAIN LANDING GEAR ASSY
SAFRAN	6100-208	MAIN LANDING GEAR ASSY
SAFRAN	6100-209	MAIN LANDING GEAR ASSY
SAFRAN	6100-210	MAIN LANDING GEAR ASSY
SAFRAN	6100-217	MAIN LANDING GEAR ASSY
SAFRAN	6100-218	MAIN LANDING GEAR ASSY
SAFRAN	6100-219	MAIN LANDING GEAR ASSY
SAFRAN	6100-220	MAIN LANDING GEAR ASSY
SAFRAN	D22698100-8	NOSE LANDING GEAR
32-10-01	35-41050-0001	MAIN LANDING GEAR
32-10-01	35-41050-0002	MAIN LANDING GEAR
32-10-01	35-41050-0003	MAIN LANDING GEAR
32-10-01	35-41050-0004	MAIN LANDING GEAR
32-10-01	35-41050-0005	MAIN LANDING GEAR
32-10-01	35-41050-0006	MAIN LANDING GEAR
32-10-01	35-41050-0007	MAIN LANDING GEAR
32-10-01	35-41050-0008	MAIN LANDING GEAR
32-10-01	35-41050-0009	MAIN LANDING GEAR
32-10-01	35-41050-00010	MAIN LANDING GEAR
32-10-01	35-41050-00011	MAIN LANDING GEAR
32-10-01	35-41050-00012	MAIN LANDING GEAR
32-10-01	D22551020-3	NOSE LANDING GEAR
32-10-01	D22551020-5	NOSE LANDING GEAR
32-10-01	D22551020-6	NOSE LANDING GEAR
32-10-01	D22551030	NOSE LANDING GEAR

If you do not see a specific part number listed, please email us at operations@ticaerospace.com to verify capability, as this list is continuously being updated.

32-10-01	CA94300-0007	NOSE LANDING GEAR
32-10-01	CA94300-0009	NOSE LANDING GEAR
32-10-01	CA94300-0011	NOSE LANDING GEAR
32-10-01	CA94300-0013	NOSE LANDING GEAR
32-10-01	CA94300-0019	NOSE LANDING GEAR
32-10-01	CA-94300-0017	NOSE LANDING GEAR
32-12-77	10-451601 SERIES	MLG AXLE HARNESS 1M
32-12-77	10-451301 SERIES	MLG LEG HARNESS 1M & 2M
32-12-77	10-451401 SERIES	MLG LEG HARNESS 1M & 2M
32-12-77	10-451501 SERIES	MLG LEG HARNESS 1M & 2M
32-14-21	65B10919- all series	DOOR ASSY AFT MLG
32-14-21	65B13299-all series	DOOR ASSY AFT MLG
32-17-01	5935354-501	MAIN GEAR STRUT ASSY
32-17-01	5935354-503	MAIN GEAR STRUT ASSY
32-17-01	5935354-504	MAIN GEAR STRUT ASSY
32-25-30	D22551000-5	NOSE LANDING GEAR
32-25-30	CA94300-0005	NOSE LANDING GEAR
32-25-30	CA94300-0015	NOSE LANDING GEAR